

# Laser rangefinder operating instructions(Pro)

EN User's manual


1-21



# Laser rangefinder operating instructions(Pro)

## Feature:


21mm Objective Lens  
6x Magnification Power  
7.2° View Angle  
16mm Pupil Distance  
Precision To +/- 1 M  
Maximum Range :  
LW600PRO 600M  
LW1000PRO 1000M  
Closest distance :  
LW600PRO 4M  
LW1000PRO 5M  
Speed range:0-300KM/H  
3V Battery (CR2)  
Waterproof





## Size:

L: 97mm(dose not include eyepiece)  
106mm (include eyepiece)  
W: 35mm  
H: 73mm (front)  
68mm (rear)  
Weight: 152g

### 1、The boot screen




Press  key to boot.  
Boot default mode is "ranging"




2

### 2、Unit conversion



Long press **M** button to switch the unit of distance, M and Y. "ranging", "flagpole lock", "Golf distance correction", "fog" "Horizontal distance measurement", "Vertical height measurement" and "speed" modes, you can long press **M** button to switch M、Y unit, the unit switches will be used in seven modes unified. In the "speed" mode, the unit of the measured value needs to be converted separately.





### 3、Low voltage alarm



3

When the the products battery voltage is too low, the low pattern has been shown to remind replace the battery.

Battery Replacement indicate:




4


#### 4、 Mode Selection

Press **M** key in the "ranging", "flagpole lock", "Golf distance correction", "fog" "Horizontal distance measurement", "Vertical height measurement" and "speed" switch between.


##### 4-3 "Ranging "Mode




Principle:




5

Press  key to start ranging.

"Ranging" screen




4-2 "flagpole lock" Mode



6

Principle:




In the flagpole Scan mode, the point D may be isolated from a number of points in the background out and keep only the distance d1 to the point.


So as to achieve the automatic locking flagpole distance.

The other goals were shielded behind the flagpole.

"flagpole lock" Screen




7

When the flagpole Scan mode screen appears, press and hold  key to start the the flagpole scan function, the flag symbol in the screen box around the icon flashes. The ranging machine aiming point in the measured scan back and forth on both sides of the flagpole, the flagpole of the measured data to the data will be retained, and the screen banner around the box is no longer flashing, which means that the flagpole data is locked .


#### 4-3 "golf distance correction" mode :

Principle:




The measured distance values AB, the slope value is substituted into the equation in golf ball flight. Calculate the recommended distance.

**The slope is positive, long distance shots.**




- 1: Uncorrected parabola batting
  - 2: The actual distance the ball parabola
- Point B is the pole position


**The slope is negative, the distance to be close to hitting.**




- 1: The actual distance the ball parabola
  - 2: Uncorrected parabola batting
- Point B is the pole position

press  key to start scanning flagpole ranging. After the measured distance values and flagpoles flagpole slope value, the trajectory can be calculated. Distance and slope value turns the display.


The calculated results show




Slope value is displayed




#### 4-4 "fog" Mode



Principle:




Fog mode screen appears, press  key ranging. Fog mode can handle the interference caused by fog.

Fog screen




4-5 "horizontal distance measurement" Mode




12

Principle:




Measure distance: AC or AB

Horizontal distance: AD


Press  key to start measuring the distance and slope. After obtaining measurements, calculates and displays the horizontal distance and measuring slope.

Horizontal distance




13


## Slope




### 4-6 "vertical height measurement" mode



## Principle:



Measuring distance between two points (Bottom and Top) in the vertical direction, and the angle ( $a$ ) between the two points, to calculate the vertical height between the two VH.

The aiming point is aligned at the bottom of the measured object, hold down the  key.


The screen appears "Scan" and "Bottom", and starts measuring a distance to the object at the bottom.

When the measured distance to the bottom, and then displays the "Scan" and "Top" to find top tips and altimetry,


At this point the object from the start to the top, and continuously display the current point and the vertical height of the bottom.



Found at the bottom




Found at the top and Vertical height




16

4-7 "speed" Mode




Principle:




17

Method:




In the speed mode, long press **M** button to switch KM / H and M / H.  
Press  key to start the measurement speed.

Kilometers Unit screen: Kilometers / hour




Miles unit screen: miles / hour





4-7"scan" mode

Principle:



In scan mode, the laser will emit a continuous, each distance to be measured will be displayed one by one.

In "ranging" mode, press and hold  key to activate the Scan mode.




Automatically exit after 20 consecutive ranging.


## **NEW!!!**


In our new products, customers can select the corresponding function according to the use environment.

### **User-defined functions:**

1. Make sure the machine is turned off.
2. Hold down the **M** button, then hold the  button, the machine turned on, the display shows the word "FUN";




**FUN**

3. Press  key several times until the display shows the 1st function on / off status:



Function NO. :

- 1) "flagpole lock"
- 2) "golf distance correction"
- 3) "fog"
- 4) "horizontal distance measurement"
- 5) "vertical height measurement"
- 6) "speed"

4. Release all buttons (before this you must ensure that the  key has been press and hold)
5. Press  key switch this function: (d=CLOSE E=OPEN)
6. Press **M** key to select the next function;
7. Hold down the  key and hold it shut down, exit the programming mode after completion;