

## Table of Contents

<b>Chapter1 General Information</b> .....	2
1.1 Brief introduction.....	2
1.2 Safety Precautions.....	2
1.3 General notices.....	2
1.4 Notice for phone operation.....	2
1.5 Notice for use of battery.....	3
1.6 Caution for using charger.....	4
1.7 Cleaning and Maintenance.....	4
1.8 General Precautions.....	4
<b>Chapter2 Before Use</b> .....	5
2.1 SIM card.....	5
2.1.1 Insert and pull out the SIM card.....	5
2.2 Battery.....	5
2.2.1 Disassembly and installation for battery.....	5
2.2.2 Charge the Battery.....	5
2.3 Power on.....	6
2.4 Install and pull out T-flash card.....	6
<b>Chapter3 Basic Description</b> .....	6
3.1 About the Keypads.....	6
3.1.1 Basic Keys.....	6
3.2 Call functions.....	7
3.2.1 Make a call.....	7
3.2.2 Answer a call.....	8
3.2.3 Reject a call.....	8
3.2.4 Menu available during a call.....	8
3.3 Handfree function.....	8
<b>Chapter4 Menu Introduction</b> .....	8
4.1 Contacts.....	8
4.1.1 Quick search.....	8
4.1.2 Search contact.....	8
4.1.3 Add new contact.....	9
4.1.4 Caller groups.....	9
4.1.5 Others.....	9
4.2 Message.....	9
4.2.1 Write Messages.....	9
4.2.1.1 New SMS.....	9
4.2.1.2 New MMS.....	9
4.2.2 Inbox.....	9
4.2.3 Outbox.....	9
4.2.4 Draftbox.....	9
4.2.5 Sentbox.....	9
4.2.6 Templates.....	9
4.2.7 Voice mail server.....	9
4.2.8 Settings.....	10
4.2.8.1 SMS Settings.....	10
4.2.8.2 MMS Settings.....	10
4.2.9 Message capacity.....	10
4.3 Call logs.....	10

## Chapter1 General Information

### 1.1 Brief introduction

Appreciate you so much for purchase of this mobile phone. From which you can enjoy the perfect functions, and convenient operation after reading the manual carefully.

The multimedia screen is designed for GPRS network circumstance. Besides the rudimental communication functions, this mobile phone adopts individuation man-machine interface to meet your different demands by perfect function design. What's more, in order to make your work and life fallow more convenient, this mobile offers you the following functions detailed as: double cards mode, phone book with calling card style, individuation in-coming ring and picture, message, camera and video camera, MP3 and player for film, recorder, Bluetooth, FM radio, alarm clock, calculator, calendar, STK, and some other practical functions.

Some service and function described in this user manual are up to network and scheduled service. Therefore, not all menus in users' phone maybe usable and shortcuts for menu and functions in different phones may also be different.

The company reserves the right for any modification under the manual without any beforehand notice.

### 1.2 Safety Precautions

In order to protect you from any economy loss by phone with hostility, please inform telecommunication department or agent immediately to prohibit the use of mobile phone and SIM card if your mobile phone has been lost or stolen.

The IMEI number (marked on the label at the back of mobile, drawing the battery out to check) is needed when you contact the telecommunication department or agent, so please copy and keep it carefully for future demand.

In order to prevent your mobile phone from misuse, please take precaution detailed as the follows:

—Setup the number of SIM and PIN card, and make modification before others awareness.

—You'd better carry mobile phone with you or lock it in your trunk. Do not leave it at the place easy to see and reach when leaving your car.

—Call restricted setting.

### 1.3 General notices

You have to use battery and charger appointed by the firm, otherwise the liquid leak of battery, superheat, detonation and fire may be caused.

Please don't bump, shake or chuck your mobile phone violently to prevent it from fault and fire.

Please don't place battery, mobile phone and charger near the microwave-oven or high-voltage equipment.

Please don't use phone at the flammability and explosive place, or else the malfunction and fire may be caused.

Please don't place phone at the place of high temperature, abundant humidity or mass dust, or else the malfunction may be caused.

Please place mobile phone out of kid's reach to protect them from hurt by playing it as toys by mistake.

Please don't place mobile phone at an-even or flabby table-board to prevent it from malfunction or break attributing to dropping.

### 1.4 Notice for phone operation

Please power off your mobile phone in some places such as: in the plane, hospital, etc, where the mobile phone may affect the electronic equipment and medical instrument, so please conform to the relative regulations. To make sure your phone won't turn on

automatically, please check your alarm clock function in your alarm setup.

For radio wave interference may cause electronic equipment malfunction and some other problems, please don't use phone near the equipment of feeble signal or high precision. Especially when next to the following ones: acoustic on, pacemaker, other medical electronic equipment, fire detector, automatic gate and some other automatic servomechanism. Please consult local equipment manufacturer or distributor for mobile phone's effect to pacemaker and other medical electronic equipment.

Please hold LCD softly and don't use phone to beat other things, or else it will cause LCD's dilapidation and liquid leak, which may cause the blindness when the liquid enters one's eyes. If so, please rinse(don't massage your eyes)them with clean water, then promptly sees the doctor.

Please don't disassemble or refit mobile phone, or else the break, creepage, and fault may be caused.

Some type of mobile phones may accidentally affect the electronic equipment in car, if so, please stop for your security.

> Please don't press the key with needle, writing skill and some other speculate things, otherwise, it will cause mobile phone's damage or malfunction.

> Please don't use phone if the antenna has been broken, or else it will hurt you.

> The radiation wave of phone may eliminate the information stored in the soft disk, bank card and credit card when the phone is so near magnetic substances.

> Keep stud and some other small metal far away from the headphone, for the speaker will pull them because of its magnetism, thus hurt you or damage your mobile phone.

> Keep your phone from damp, water or other liquid, if not, superheat, creepage and fault may be caused.

### 1.5 Notice for use of battery

> Don't throw battery into fire; otherwise it will induce fire and explosion.

> Don't press in force when installing battery. Or else it will induce liquid leak, superheat and fire.

> Please neither cause battery to be short by wire, needle and some other metal, nor blend the battery with necklace. Or else it will induce liquid leak, superheat and fire.

> Don't seal battery end. Or else it will induce liquid leak, superheat and fire.

> Blindness will be caused when the liquid from battery enters one's eyes. If so, please rinse (don't massage your eyes) them with clean water, then promptly sees the doctor.

> Please don't dismantle or refit battery, or else it will lead to liquid leak, superheat explosion or fire.

> Please don't use or place batteries near fire or heater, or else it will lead to liquid leak, superheat, explosion or fire.

> Please replace new battery if temperature rising, color changing or distortion occur during the process of operation, charging or conservation.

> Burn will be caused when the liquid from battery enters one's skin or clothes. If so, please rinse them with clean water, then promptly sees the doctor.

> Please promptly move the battery away from fire if liquid leakage or oddball odor occurs to prevent from explosion or fire.

> Please don't keep the battery away from damp. or else it will lead to superheat, fume and erosion.

> Please don't use or place battery when exposure to direct sunlight or high temperature, or else it will induce liquid leakage, superheat, thus decreasing

performance and shortening longevity.

> Please don't charge more than 24 hours continually.

### 1.6 Caution for using charger

> Please connect to 220V AC, if not, the creepage, fire and damage to mobile phone and charger will be induced.

> Do not make the charger to be short, or else it will induce electric shock, smoke and damage to charger.

> Please don't use the charger if the wire of power has been broken, or else it will cause electric shock or fire.

> Please remove the dust accumulated around the power socket in time.

> Please don't place container full of water beside charger, so as to prevent from superheat, creepage and fault.

> Please draw the power socket out quickly to escape from superheat, fire, electric shock and charger's damage if the charger has reached water and other liquid.

> Please don't dismantle or refit charger, or else it will induce hurt, electric shock, fire and charger's damage.

> Please don't use battery near bathroom and some other places of high temperature, or else it will induce hurt, electric shock, fire and charger's damage.

> Please don't hold charger, wire and power supply socket with humid hands, or else it will induce electric shock.

> Please don't put clog over power supply wire or refit wire, or else electric or fire will be induced.

> Please draw the pin out of socket before clean and maintenance.

> Please hold the charger to draw pin out to escape from damage of wire, electric shock or fire.

### 1.7 Cleaning and Maintenance

> Please keep mobile phone, battery and charger away from high humid and rain when in use.

> Please tidy the mobile phone, battery and charger with soft and dry cloth.

> Please don't cleanse mobile phone with alcohol, thinner or benzene.

> Please wipe the bilge in the socket to prevent from loosen contact, electricity dropping and failure of charge.

### 1.8 General Precautions

> Mobile phone:

Please use mobile phone under the situation with temperature range from 5°C~40°C and humid from 35% to 85%.

In order not to weaken the effect of these equipment and mobile phone, you'd deep a little far away from common telephone, TV, radio and automatic office equipment.

> Battery:

Please keep battery away from direct exposure and sunlight, locate it in the ventilated places.

Please replace the appointed battery when fast in vain after charging for many times, because the working period will gradually shorten after frequent charge, finally to the end.

> Please don't throw worn battery into trash. Just do it under the relative regulations.

**CAUTION: Risk of explosion if battery is replaced by an incorrect type**

**Dispose of used batteries according to the instructions.**

> Charger:

Please don't charge at the places detailed as follow: direct exposure to sunlight,



temperature lower than 5°C or higher than 40°C, humid, dirty, heavy vibrancy (induce fault), near TV, radio and some other appliances. (Affect image and sound).

## Chapter2 Before Use

### 2.1 SIM card

> In order to use the mobile phone, you should insert the valid SIM card, which is the key to enter the GSM network.

> All the information related to the creation of the connection to the network and initial call records will be recorded in the metal plane area of the SIM card as well as the names, telephone numbers and SMS stored in the phone book on the SIM card. The SIM card can be taken out from your mobile phone and can be placed in any one of the GSM mobile phones for use (the new mobile phone will read the SIM card automatically).

> To prevent losing and damaging of the information in the SIM card, please DO NOT touch the metal plane area and the SIM card should be kept far away from electromagnetism. Once the SIM card is damaged, you can not enter into the GSM network.

**\*Note: Please do power off your mobile phone before pulling out the SIM card. It is forbidden to insert or pull out the SIM card with the mobile phone connected to the external power supply; otherwise, the SIM card is most likely to be damaged.**

#### 2.1.1 Insert and pull out the SIM card

> Power off your mobile phone and then remove the battery and other external power supply.

> Insert the SIM card into the SIM card slot, make sure the SIM is fixed accurately.

> When you need to pull out your SIM card, please power off your mobile phone firstly, remove the battery, and then pull out your SIM card by moving down.

**\*NOTICE: The card slot on the left is SIM1 card, the one on the right is SIM 2 card.**

#### 2.2 Battery

> The battery can run immediately after taken apart for it has charged for about 50% volume; In order to reach the optimum operation, please make use under the situation of fully charging after complete consumption. The new battery should be charged at least for 14 hours. Only when the initial battery is exhausted thoroughly (the electricity quantity runs out and the mobile phone can not power on) can the battery be fully recharged for use, so does the second time charging. Only when recycled for three times in this way, the battery works in the best condition easily.

##### 2.2.1 Disassembly and installation for battery

Please draw out the battery under the following directions: 1.Unbolt the back cover 2.withdraw when lifting from the back.

Install under the following directions: 1. Insert from the up of battery downwards 2.Shut the back cover of mobile phone.

##### 2.2.2 Charge the Battery

Connect the charger to power supply.

Insert the connector of the charger to the hole or to the USB port at bottom.The indicator at the right-up will bicker circularly; the symbol of charging will occur to show charging just in execution under power off state. The symbol of charging will occur after a while if the phone is overspent when it is in serious lack.

Charging has been finished when the indicating symbol at the right-up corner is in full state and without twinkling. The picture will display in the screen when charging completed if charging under power off state. This process usually takes about 3-4

hours. It's normal if battery, mobile phone and charger get hot during charging.

Cut off the power supply and make mobile phone and charger disconnected when charging completed.

#### Notes:

**Please charge with the charger supplied by manufacturer at the temperature range from +5°C ~ +40°C in the ventilation place. The use of non-ratified charger will induce both danger and disobey of certification and repair guaranteed terms.**

**Please charge promptly when mobile phone automatically powers off or shows the warning "charge warning".**

**The standby and talk time provided by manufacturer is based on ideal situation.**

**Practical working time will change with network status, operation environment and operation manner.**

**The right installation of battery should be insured before charging, in which it can't be drawn out.**

**The charger must be disconnected from mobile phone and power supply after charging completely.**

**Charging will re-start when the volume has consumed to some extent after about 5 to 8 hours if charger doesn't disconnect from phone and power supply. We strongly advice you not to do so for the performance and life span of your battery.**

#### 2.3 Power on

Press the power on/off key for a while to switch on/off the mobile phone, which will give you a cue to insert SIM card if it hasn't been done. Then the mobile phone will automatically examine SIM card after inserting SIM card.

Then cues will occur on the screen ordinal detailed as follows:

-- Input mobile phone password if phone unlock password has been set.

-- Input PIN1 if SIM card password has been set.

Then the phone will search network until finding available network.

**\*Notice: If the screen displays "Emergency", it means you are out of the scope of service, but you can dial Emergency Number.**

#### 2.4 Install and pull out T-flash card

This mobile phone supports T-flash card, which is a kind of multimedia memory card used to increase memory of the mobile phone. It is so small that you should take cautions to install or pull it out in order to avoid damage. The method to install/ pull out T-flash card as the follows:

1. Power off the mobile phone, insert the T-flash to the memory card slot with the metal plane down.

2.To pull out the memory card, power off the mobile phone, take out the T-flash by moving down.

**Note: The mobile phone does not support hot-plug function of T-FLASH in "power on" mode. Only when the mobile phone is powered off can T-FLASH be pulled out.**

## Chapter3 Basic Description

### 3.1 About the Keypads

#### 3.1.1 Basic Keys

This mobile phone possesses perfect functions. Following is the introduction of the basic key:

> Dial Key 2: Dial and receive incoming call by using card 2; draw out dialed record in standby state.

> Dial Key 1: Dial and receive incoming call by using card 1; draw out dialed record in standby state.

> Left soft key: Execute the functions displayed in the inducting symbol at the left corner, and press it to enter Menu in standby interface

> Right soft key: Execute the functions displayed in the inducting symbol at the right corner, and press it to enter phone book in standby interface

> Power on/off key: Press the key for 2 or 3 seconds to power off, during a call you can close talk by the key, and press this key to return to standby state in other situation.

> OK key: press this key to the main menu in standby interface.

> MP3 key: Press the MP3 key on standby screen to enter MP3 quickly.

> Keypad lock: Press the Left key first and then "\*"key to lock the keypad and screen. Press the Left key first and then "\*"key to unlock the keypad and screen.

> UP/Down navigation key: switch menu

> Left/right navigation key: switch menu

> Numeric key 0-9: Enter corresponding character.

> \* key: input corresponding character.and adjust volume in mode of MP3 ,Video and FM.

> # key: input corresponding character ,switch input means. and adjust volume in mode of MP3 ,Video and FM.

> MP3 play key: Open the function of Mp3 via press it in standby mode Switch play, pause, previous and next

> Multimedia: press this key to enter Multimedia

#### 3.2 Call functions

You can dial or receive call if the symbol of network supplier is displayed on the screen (intensity of network signal shown at left up corner). Move in small region may improve calling effect, which is has too much with the barrier.

##### 3.2.1 Make a call

> Dial call:

Input telephone numbers, and then press the dial key to make call. Use right soft key to delete number if modification is needed. The picture of dialing will appears on the screen during dialing, then call status information will appears after the pick up of phone ,additionally together with a alert sound(network support needed) if it is opened. If you want to end the call, please press the end key. If the number does not belong to the Phone Book List, the screen of your device only displays the number. Otherwise, the name would be displayed.

> Dial fixed branch phone:

You should firstly dial telephone exchange, then branch for some branch phones which can't be got through directly. The phone will press \* key (now "p" displaying on screen)for you if pulse character "p" is entered between host and branch number when dialing.

Region no. Host no. p Branch no. Dial key

Dial international call:

Please press \* key twice until prefix "+"of international call appears on the screen, which will allow you to dial to any country without knowing of the local international call prefix(for instance,0086 for china).

Firstly enter prefix, then enter the country area number and complete phone numbers.

The country area number is in accordance with general routine, such as 49 for Germany, 44 for UK, 46 for Sweden and so on.

Please delete "0" before city number, which is the same as dialing international call.

For example, please dial service phone of other countries as: +86 21 114

+ Country code Integrated no. dialing key

Emergency call:

You are able to make emergency call in the range covered by network (please refer to signal intensity displayed in left up corner).Emergency call will be shown on the

screen if your network supplier doesn't provide ramble function. Emergency call can be made without SIM card if you are in the network range

#### 3.2.2 Answer a call

You can Press the call key to receive the call when call coming. Display "SIM1 incoming call" with the phone number or name if SIM 1 has been called. Display "SIM2 incoming call" with the phone number or name if SIM 2 has been called.

If you set any key to receive the call, you may use the any key to receive call besides the end key and the right soft key.

You also can press the key in the earphone to receive calls if it has been connected.

#### 3.2.3 Reject a call

> When you do not want to answer a call, you can press the end key to end the call.

#### 3.2.4 Menu available during a call

Under call mode, press "options" to enter call options, which is operated the same as function menu.

The calling menu can be shown only during calling. Furthermore, call wait, call forward and multi-talk etc need network support from your network supplier.

You can operate as the follows in the calling options menu:

> Turn on handfree/Hand on: Select this option to activate/ disabled the handfree.

> Switch: Keep current call or recover call kept.

> Phonebook: Enter phone book browsing mode.

> Message: Enter message browsing mode.

> Call record: Enter call history browsing mode.

> Record/Stop to record: Record/stop recording call voice.

> Turn on mute/Turn off mute: Not send / send local tone.

You can operate the options of multiparty call as the follows:

--Turn on handfree/Hand on: Select this option to activate/ disabled the handfree.

--Switch: Keep current call and recover call kept

--Phonebook: Enter phone book browsing mode.

--Message: Enter message browsing mode.

--Call record: Enter Call record browsing mode.

--Record/Stop to record: Record/stop recording call voice

--Turn on mute/Turn off mute: Not send / send local tone.

--Release: You may end the call which you want to tend

--Release all: You may end the all calls

--Release active: You may end the active call.

#### 3.3 Handfree function

> Under call mode, via press right soft key to activate/ disabled the handfree.

**\*note: Under call mode, press the up direction key or down direction key to adjust the volume.**

## Chapter4 Menu Introduction

### 4.1 Contacts

You may save the information of contacts including names and telephone numbers in the phonebook, which can save as much as 100 entries. The storable entries of SIM card depend on the type of the card.

You may select to edit, delete, mark, copy contacts and etc.

#### 4.1.1 Quick search

Select this option and you can access Phonebook browsing interface. There is an input box at the bottom of this window and you can input corresponding information to filter the Phonebook. Exchange input way by press # key.

#### 4.1.2 Search contact



Search for records in Phonebook according to input names.

#### 4.1.3 Add new contact

Add new contact in the Phonebook. You may select to save it in SIM card1, SIM card2 or phone.

**Note: The format of saving a contact is different between in SIM card and mobile phone.**

#### 4.1.4 Caller groups

Provide eight Caller groups in the phone, you may change their names, add and delete contracts with every Caller group

#### 4.1.5 Others

Include speed dial setting, own number, memory query and display settings

- Speed dial settings: The function enables you to keep pressing a numeric key to make quick dialing of the corresponding preset telephone number.
- Caller ID: You may edit or delete the own number
- Memory status: You may view the memory of contacts in SIM1, SIM2 and phone.
- Single line display: You may select single line display or double line display.

Note: The mobile phone may store 100 contacts at most. SIM card1 and SIM card2 of contacts store capacity according to itself.

#### 4.2 Message

##### 4.2.1 Write Messages

##### 4.2.1.1 New SMS

Create a new short message. You can insert template, vCard, Phiz., message body. You may select multiple receivers to send the message to more than 1 person, 100 receivers at most.

##### 4.2.1.2 New MMS

Create a new multimedia message. You may edit the receiver, cc, bcc, title and Content.

**Note: send MMS on time needs to be supported by network operator.**

You may select to send the finished message from SIM card 1 or SIM card 2. Sending and receiving MMS need T card.

##### 4.2.2 Inbox

When you receive a message, you enter the inbox to read it. You can reply, delete, lock, mark and sort the message, and call the sender.

##### 4.2.3 Outbox

You can enter the outbox to read it, when the message is sent unsuccessfully. Also you may send, delete, mark the message and other functions of message.

##### 4.2.4 Draftbox

When you save a message, you may enter the draftbox to read it. Also you may send, edit, delete the message and other functions of message.

##### 4.2.5 Sentbox

You can enter the sentbox to read it, when the message is sent successfully. Also you may forward, delete the message and other functions of message.

##### 4.2.6 Templates

Templates: Use defined message. You can edit and delete them.

##### 4.2.7 Voice mail server

The functions of voice mail as follows:

Retrieve message: you can receive the voice mail via dial the number of voice mail

Number settings: you can set the number of voice mail

**Note: you can directly dial the number of SIM1 voice mail via press the number 1 long time, and dial the number of SIM2 voice mail via press the number 2 long**

#### time.

**This function needs to be supported by network operator.**

#### 4.2.8 Settings

##### 4.2.8.1 SMS Settings

SMS center number: validity and sending format for SMS center number  
Message validity period: period of validity may set 1hour, 6hours, 24hours, 72hours, 1week or Maximum

Status Setting: set whether enable message report

**Note: This function needs to be supported by network operator.**

Save sent messages: Prompt to save sent messages, save or not save

Preferred storage: save messages in mobile phone or SIM card

##### 4.2.8.2 MMS Settings

MMS Settings: Set the parameters of sending and receiving multimedia message

—MMS count: Refer to network operator.

—Arrive report: Activate/Deactivate arrive report

—Read report: Activate/Deactivate read report

—Anonymity: Activate/Deactivate anonymity

—Priority: You may select high priority, medium priority or low priority.

—Retrieve MMS: You may select retrieve manual or retrieve auto.

—Play sound: Activate/Deactivate play sound

—Adverting: Activate/Deactivate adverting

—Message validity period: may set 12hours, 1day, 1week or Maximum

—Storage location: Set the storage location to save picture, music and video

—Restore to default: Restore to default of MMS setting

**Note: Some functions above need to be supported by network operator.**

##### 4.2.9 Message capacity

View the message memory of SIM1, SIM2 and the mobile phone.

#### 4.3 Call logs

##### 4.3.1 Call history

SIM card 1 and SIM card 2 Call history include dialed calls, received calls, missed calls, rejected calls, delete all, call timers, call cost, GPRS counter

—Rejected calls: The incoming call of the contact is in the group blacklist. And the call has not call interface. You can view the detail of the call log in rejected calls.

—Call timer: View the time of the last call, received calls, dialed calls and all calls.

—Call costs: View all costs, max costs and cost rate, also can edit max costs, edit cost rate and reset costs.

**Note: This function needs to be supported by network operator.**

—GPRS counter

Count last sent, last received, total sent, total received volume.

#### 4.4 Settings

##### 4.4.1 Standby mode

You can select SIM1 enable, SIM2 enable, SIM1and SIM2 enable, or Flight mode.

##### 4.4.2 Call setting

—Dual-SIM

Set dual sys call forward: when only one card enable, the other card will call forward to the enable card after network connect successfully.

SIM settings: Can set call, SMS, prompt dial, and original SIM reply.

Set SIM name: Can edit the name of SIM1 and SIM2.

Dual SIM settings wizard: Enter the settings of Dual-SIM.

Help: view the help if required.

—Call divert

Unconditional: All the incoming calls will be diverted to the number you set unconditionally.

If Busy: The incoming calls will be diverted to the number you set when you are busy. If no Answer: The incoming calls will be diverted to the number you set if your mobile phone isn't answer the call.

If unreachable: The incoming calls will be diverted to the number you set if the call can not reach for some reason such as network.

Cancel all diverts: cancel all settings of call diverting

—Call barring

All outgoing calls: Bar all outgoing calls.

All incoming calls: Bar all incoming calls.

Incoming when roam: Bar incoming calls when you are roaming.

All intl outgoing: Bar all intl outgoing calls.

Outgoing intl roam: Bar outgoing calls when you are international roaming.

Cancel all barring: cancel barring (need to input the PIN2 code).

—Call waiting: There will be a cue when a call incoming in call mode if the function of call waiting is activated.

—Hide ID: select hide, display id, display id by network.

—Line selection: select Line 1 or Line 2.

—Network selection: select Auto or Manual

—Other settings

—IP shortcut key: Can active or cancel, modify IP number, and there are 5 IP numbers.

—50 sec warning: Select activate or off.

—Vibration when connected: Select activate or off.

—Answer/Reject mode: You may use the any key to receive call besides the end key and the right soft key if this option is checked / you can reject call via SMS.

—Auto redial: It will automatically re-dial call when the called party is busy or no answer if this function is activated.

#### 4.4.3 Phone Settings

Refer to settings of basic functions, including time and date, select language, shortcut settings, Auto power on/off, power management.

—Restore factory setting: The default password is 1122.

**\*Note: parts of the functions need supplier's support.**

#### 4.4.4 Display setting

Refer to settings of basic functions, including wallpaper settings, idle display settings, contrast, backlight, keypad backlight time, connection management-power on/off display.

#### 4.4.5 Security settings

➢ PIN

PIN code can protect you're the unlawful use of SIM card.

Please choose 'on' to start your PIN code protection if it is 'off' at present, and the PIN code is needed to power on your phone next. Please choose 'off' to switch off if it is 'on' at present; And please choose change PIN code to modify it, input old one and new one then repeat according to clew.

**\*Note: If you input invalid PIN code for three times continuously, the SIM card is locked and you need the PUK code to unlock the SIM card. The PIN code and PUK code may be provided together with SIM card. Please contact your network operator if not. The default PIN code is 1234. Please change it into your own**

**private password as soon as possible.**

➢ PIN2

Please choose 'on' to start your PIN2 code protection if it is 'off' at present. Please choose 'off' to switch off if it is on at present. The PIN2 code is used for special functions

**\*Note: If you input invalid PIN2 code for three times continuously, the PIN2 card is locked and you need the PUK2 code to unlock the PIN2 code. Please contact your network operator if not.**

➢ Privacy

Set the call record, message, camera, video recorder, phonebook, File management, calendar, Udisk protection.

**Note: Please change the default password. Usually 1122 is your default private password.**

➢ Auto keypad lock

Set the waiting time of key lock, after which the key will be locked automatically when the mobile phone is out of use in the appointed time.

➢ Lock screen by end-key

Can activate or deactivate the Red key locks keypad.

➢ Power-on password

Can set and change the power on password.

**\*Note: When the phone is lost, the replacement SIM card is switched on, it will be prompted for input a password, if entered correctly, the phone can be used normally, if input the wrong password three times, the phone will turn into the illegal use of state.**

#### 4.4.6 Profiles

##### 4.4.6.1 Normal

General mode: You can choose active or settings or rename.

➢ Active: Choose it to enter Normal mode.

➢ Customize: Choose it to set Normal mode. The content includes ring set, adjust volume, call alert, message alert, alarm & calendar remind, keypad tones, battery low alert, Power on/off tone.

—Ring set: Set the ring of incoming call. Set the ring of incoming message.

—adjust volume: Adjust volume caller ringtone, message ringtone, call volume, alarm & calendar volume, power ringtone

—Call alert: Set the incoming call style.

—Message alert: Set the incoming message style.

—Alarm remind: Choose a alert type (Ringtone, vibrate, silent, ring and vibrate)

—Key tone: Can set silent or ringtone 1 or ringtone 2.

—Battery low alert: Can activate or off the Battery low alert.

—Power on/off tone: Can activated or off

➢ Rename: Rename the mode.

##### 4.4.6.2 Silent

The operation is the same as normal mode.

##### 4.4.6.3 Meeting

The operation is the same as normal mode.

##### 4.4.6.4 Indoor

The operation is the same as normal mode.

##### 4.4.6.5 Outdoor

The operation is the same as normal mode.

##### 4.4.6.6 Headset



Insert headset to start this mode automatically. The operation is the same as general mode.

#### 4.4.6.7 Bluetooth

Open Bluetooth headset and auto open this mode when activating phone Bluetooth. The operation is the same as general mode.

#### 4.4.7 Connection management

##### 4.4.7.1 Network account

Network account:

In the options, we can set these below.

—Build a new link setting: Can set security connect, user name, password, APN, gateway IP address, port, rename, homepage, advance settings.

—add a new link setting: Can add if required.

—Search: Can search a link.

—Delete a setting list: Can delete the setting list. (The default data can't be delete)

—Edit: edit what you choose. (The default data can't be delete)

##### 4.4.7.2 GPRS settings

—GPRS settings: You can choose connect when needed or always connect

#### 4.5 Multimedia

##### 4.5.1 Camera

In the options of camera interface, You may set shutter, banding, delay timer, cont. shot, image size, image quality, white balance, scene mode, effect settings, storage and etc. you may enter the photos to view the photos. Press the middle (OK) key to take photos.

##### 4.5.2 Video recorder

In the options of the video recorder interface, you may set white balance, avoid coruscate, effect settings, storage and etc. you may enter the video list to play the video. Press the middle (OK) key to begin recording. Your phone can recorder 3GP formats file.

##### 4.5.3 Audio player

The music player is used to play music files in supported formats in the current player's list. You may view details of the music files and set the current music file as the ring signal for incoming call. You may connect the Bluetooth earphone to enjoy the music.

##### 4.5.4 Video player

Enter the video player to playing the video file.

Note: You phone supports 3GP, MP4 formats file.

##### 4.5.5 FM radio

Touch the middle icon can switch FM broadcast's mode (speaker mode or earphone mode), and you may press the up and Down direction key to change search type. Press the left and right key to change the channel. Via press \* key, # key to adjust the volume.

\* Note: You need to insert an earphone to listen to the radio.

##### 4.5.6 Recorder

You can record file and play it.

##### 4.5.7 Image browser

View the pictures in the memory card.

##### 4.6 File management

For the memory card, you may establish a data file folder, change the folder name, delete a folder, sequence the files and etc.

Use as: For the picture use as wallpaper, For the video use as power on/off.

Rename: Change the name of a file/folder.

Copy a file: To copy any file in the memory card.

#### 4.7 Internet

Your mobile phone support the service based on wireless application protocol (WAP). You can access all the service supported by your network supplier.

➢ Homepage: Login home, which is the WAP station for you to start connection setup. If not, you will use the station set by supplier.

➢ Bookmarks: Display each bookmark existed. Choose the website directly linked the bookmark.

➢ Histories: Record all the websites you have browsed.

➢ Input URL: put the address which you want.

➢ Pushbox: Store the message sent by service provider.

➢ WAP settings

—Browser settings: Can clear cache, set network count, set image download, play background sound, accept pushmsg.

—Preferred storage: Can set picture, music, and movie preferred storage.

—GPRS settings: To set GPRS open always or open required.

—Restore to default: Can restore to default.

**Note: GPRS service needs network support and it is available only when you apply this service and locate in GPRS network coverage.**

##### 4.8 Games

You can play Sokoban game and enter Facebook, Msn, Google, Ebuddy, YaHoo, Twitter, menu.

##### 4.9 Tools

###### 4.9.1 Alarm

Switch: activate/deactivate the alarm clock

Time: set the time of alarm clock.

Repeat:

—Once: the clock alarms only once.

—Everyday: alarm at specified time everyday.

—Custom: set the time that the alarm rings in a week.

Alarm Ring: set the fixed ring tones or more ring tones to alarm ring.

###### 4.9.2 Bluetooth

This mobile phone via Bluetooth wireless link, you can exchange data with other Bluetooth device or voice communications via Bluetooth earphone.

➢ Open/Close Bluetooth: Can open or close Bluetooth.

➢ Bluetooth visibility: Can show or hidden phone.

➢ Paired device: Can add new device.

➢ Set shared files: Can set directory sharing authority, sharing directory.

➢ My Bluetooth name: Can set Bluetooth name.

➢ Bluetooth file location: Can set memory card

➢ Address info: check BT address.

➢ Help: Can view the help information.

###### 4.9.3 Calendar

Enter calendar interface, Press the left key and right key or up/down direction key to choose 'data' and 'week'. Press 'options' to enter submenu.

—Go to date: From present date to the date you set.

—By month (week) view: View by monthly (weekly).

###### 4.9.4 Calculator

Input 0-9 numbers and Press the Direction keys to input the four operators +, -, ×, ÷.

➢ Press the Right soft key to clear last number or result; press the Right soft key 'Back' to exit calculator and press or OK to calculate.

**Note: The precision of the calculator is limited and there are errors, especially when it is indivisible.**

##### 4.9.5 E-book

Enter to read TXT which stored in memory card.

##### 4.9.6 STK

STK is SIM Tool Kit. It is a new GSM service which provides you flexible information services, e.g. stocks, traffic, weather, etc. The functions of STK depend on the network operator. This service needs the support of SIM card and network operator.

#### Chapter5 Input method illustrations

English input Method

This mobile phone provides input methods for capital, small letters and smart English. Numbers input Method

Press the Number keys to input corresponding numbers.

Other language input Method

You can press # key to change the different language input methods.

Press the direction key to select need of characters.

#### Chapter6 Common problems and solutions

##### 6.1 When the mobile phone displays "Insert SIM"?

1. Contact between SIM card and mobile phone is bad or the SIM card is not inserted.
2. Change the SIM card and try again. The SIM card may have fault if the mobile phone operates normally. Please contact your network operator.
3. If there is oxidation on the surface of SIM card or SIM card slot of the mobile phone, please wipe with alcohol or clean cloth.
4. Please contact Sales Service Center or Maintenance Department if the above methods are invalid.

##### 6.2 Checking and precautions of PIN, PIN2, PUK, PUK2 and password

1. Please consult local network operator.
2. The SIM card is locked if you input invalid PIN code for three times continuously.
3. Please consult SIM card operator for PUK code.

##### 6.3 Network connection fails

1. The signals in your local place are weak or have shielding. Please move to other places and try again.
2. Please contact Sales Service Center or Maintenance Department to do phone test.

##### 6.4 You can't be heard

1. Make sure whether it is network problem and try again.
2. The communication lines in some places are bad. Please move to other places and try again.
3. The trunk line of network operator is bad.
4. Please contact Sales Service Center or Maintenance Department if the above methods are invalid.

##### 6.5 Can't charge the battery

1. The contact between charger and mobile phone is bad. Make sure whether the installation is proper.
2. Check whether the battery is valid. The battery performance drops after several years.

##### 6.6 Weak signal

1. If the local network signals are unstable, the signals of the mobile phone receives won't be stable. Please move to other places and try again.
2. Please contact Sales Service Center or Maintenance Department if the above

method is invalid.

##### 6.7 Can't make a call

1. The local network signals are weak and please move to places with strong signals and try again.
2. Local network operator is busy. Please try again later.
3. Check whether Hide ID is enabled. You can't make a call if the local network operator doesn't support this function and you have enabled it.
4. Please contact Sales Service Center or Maintenance Department if the above methods are invalid.

##### 6.8 Standby time becomes short

1. The standby duration depends on the intensity of local network signal.
2. It is affected by environment temperature, base station distance, etc.

Appendix

Abbreviation and Explanation

GSM	Global System for Mobile Communications
GPRS	General Packet Radio Service
SMS	Short Messaging Service
WAP	Wireless Application Protocol
SIM	Subscriber Identity Module
PC	Personal Computer
PIN	Personal Identification Number. Usually refer to PIN1. It is provided with SIM card and the code to access SIM card.
PIN2	Personal Identification Number 2, provided by network operator. It is used for special functions, e.g. SIM supported FDN.
PUK	Personal Unlock Key, provided along with SIM card. It is used to unlock the SIM card if you input invalid PIN code for three times continuously, or used to change PIN code.
PUK2	Personal Unlock Key 2. Provided along with specific SIM card and is used to change or enable PIN2.
IMEI	International mobile Equipment Identity. It is made up of 15-digit number. Call Waiting It is a network service that you can answer a call without ending current call. Different from multi-party conference, you can only talk to one party at the same time.
Call Diverting	It is a network service that you can divert the incoming calls to specified number. The options include All Call, If not Available, If not Answered, If Busy, and Transfer All
Roaming	Use the mobile phone beyond the home network. It includes international roaming and domestic roaming, while it refers to international roaming in this manual.
STK	SIM tool kit. It is GSM service, which provides you flexible information, including stocks, traffic and weather. The functions of STK depend on the network operator. This service needs the support of SIM card and network operator.
Dual Card Mode	The mobile terminal supports two GSM SIM cards and the cards subscribe to network simultaneously and stand by at the same time.