

Diameter: 3.5CM

I. Preface  
Thank you for purchasing this product. Under the guidance of this manual, you may use this item and the anti-spy investigation procedures properly. Please read the manual carefully before using, so that you can operate it correctly and freely.

## II. Functions summary:


- Video Format: AVI
- Photograph Dimension: 640\*480
- Memory: 512MB/1 GB/2GB/4GB/8GB (Optional)
- Video Recording Function
- USB2.0 (H+)
- Built-in Li-Battery working 2 hours continuously (Max)
- No need for driver installation if the operating system is Windows ME/2000/XP/Mac OS 9.2.2 or above (Windows98 is excepted)

## III. Charging:

1. Built-in rechargeable Li-Battery. Please insert the USB cable to the DVR wrist with charger or inserted into the USB port of PC. Once connected with charger or correctly, the green light of this USB watch will be in work. When green light is off and red light is on, which means the battery is in full. When green light is off and red light is on, which means the battery is in full. When green light is off and red light is on, which means the battery is in full. When green light is off and red light is on, which means the battery is in full.
2. If there is not enough power supply while photographing, the camera order will be power off automatically. The screen will store the photography files automatically before power off to ensure their safety.

## IV. Appearance & Keys:

# The Instruction of Spy DVR Watch




1. Power on: long press the PLAY button about two seconds. Enter into the recording mode when the red light is twinkling once, then the green light will be on. About eight seconds the player is recording videos. Once the off which means the player is recording videos.
2. Power off: long press PLAY button for three seconds to save the video and then power off. At the moment the red light twinkles quickly for three times.
3. Reset Key: The player will automatically turn off when lack of disk space. (P.S: The player will automatically turn off when lack of disk space.)
4. Driver Installation: Please press the Reset Key to restart when the player crash. Needed for Windows 98. Install the driver CD to your computer, and it will take effect after restart computer.

- No need for Windows ME/2000/XP/Mac OS 9.2.2 or other system above.
- VII. PC Connection
1. Please insert the USB cable to the watch firstly and then connect it to the PC. (The USB port after connect correctly, can find "removable disk" in "my computer")
  2. When the camera watch connect to the PC, the camera watch begins to work as the removable hard disk of the PC. You can view video files, transfer, copy, paste and delete data (audio and video files etc) conveniently, non-miscellaneous files can be stored also.
  3. Disconnect the USB watch from the PC.
  4. Double click the icon of "delete the hardware safely" delete the hardware safely, you want to stop, and confirm, there will be a hint "The hardware storage device can be removed safely".
  5. Choose "stop" in the dialog frame of "delete the hardware safely".
  6. Disconnect the player from the PC.

VIII. Trouble-shooting	Check if the battery is short of power. Please charge the player.
Can not turn on	1. Check if the USB cable between the player and the PC is connected correctly and connect.
Can not download files	2. Check if the condition of the drive is proper (under Windows 98).
Can not upload files normally	3. Check if the player has enough space to store music files.

# 摄像手表使用说明书



1. 开机/关机/休眠/唤醒/充电
2. 摄像头
3. USB接口
4. 扬声器
5. 充电口
6. 表带
7. 表冠

## 七、操作方法：

1. 开机：长按P/AN键两秒左右，直到P/AN键下方指示灯亮起，表示正在开机。
2. 关机：长按P/AN键三秒，直到手表关机，此时手表会自动关机。
3. 充电：将手表放入充电底座，手表会自动充电。

仅对Windows 98的用户，将摄像头驱动程序安装到您的电脑上，并重新启动。Windows 98/XP/Mac OS 9.2.2或以上版本的操作系统无需安装驱动程序。

## 七、连接电脑：

## 一、前言

感谢您购买本产品，本产品是一款集摄像、录音、通话、数据传输于一体的智能手表。本产品采用先进的摄像技术，能够拍摄清晰的照片和视频。本产品还支持录音功能，能够录制清晰的语音。本产品还支持通话功能，能够接听和拨打电话。本产品还支持数据传输功能，能够将拍摄的照片和视频传输到电脑上。

## 二、功能概述

- 摄像模式：AVI格式
- 摄像尺寸：640\*480
- 内存容量：1GB/2GB/4GB/8GB
- 视频录制功能
- 录音功能
- 通话功能
- 数据传输功能

## 三、充电

1. 本产品支持快充功能，充电速度非常快。当电量不足时，请及时充电。充电时，请将手表放入充电底座。充电底座采用先进的快充技术，能够在短时间内充满电量。
2. 在充电过程中，请勿使用手表。充电完成后，请及时取出手表。

## 四、外观与按键

1. 使用本产品时，请确保手表电量充足。当电量不足时，请及时充电。
2. 本产品支持多种语言，您可以根据需要切换语言。
3. 本产品支持多种分辨率，您可以根据需要切换分辨率。
4. 本产品支持多种帧率，您可以根据需要切换帧率。
5. 本产品支持多种码率，您可以根据需要切换码率。
6. 本产品支持多种格式，您可以根据需要切换格式。
7. 本产品支持多种分辨率，您可以根据需要切换分辨率。
8. 本产品支持多种帧率，您可以根据需要切换帧率。
9. 本产品支持多种码率，您可以根据需要切换码率。
10. 本产品支持多种格式，您可以根据需要切换格式。

## 八、注意事项

1. 请勿在高温或低温环境下使用本产品。
2. 请勿在潮湿环境下使用本产品。
3. 请勿在强磁场或强电场环境下使用本产品。
4. 请勿在易燃易爆环境下使用本产品。
5. 请勿在高压电附近使用本产品。
6. 请勿在强辐射环境下使用本产品。
7. 请勿在强震动环境下使用本产品。
8. 请勿在强噪音环境下使用本产品。
9. 请勿在强光线环境下使用本产品。
10. 请勿在强磁场环境下使用本产品。

## 九、常见问题

不能开机	1. 检查摄像头与PC之间的USB连接是否正确。 2. 确认摄像头是否正常工作。 3. 确认摄像头驱动程序是否正确安装。 4. 确认摄像头是否正常工作。
不能正常录像或上传图片	1. 检查摄像头与PC之间的USB连接是否正确。 2. 确认摄像头是否正常工作。 3. 确认摄像头驱动程序是否正确安装。 4. 确认摄像头是否正常工作。