

Contents

1. Basic information	4
1.1 Introduction	4
1.2 Safety notice	4
1.3 Safety warning and precautions	4
1.3.1 General precautions	4
1.3.2 Precautions of using mobile phone	5
1.3.3 Precautions of using battery	6
1.3.4 Precautions of using charger	6
1.3.5 Cleaning and maintenance	7
1.3.6 Common precautions	7
2. Before using	8
2.1 Parts and functions	8
2.1.1 Icon	8
2.2 Key description	9
2.3 Introduction of touch screen	9
2.4 Battery	9
2.5 Charging the battery	10
2.6 Connecting to the network	10
2.6.1 SIM card	10
2.6.2 Insert and remove the SIM card	11
2.6.3 Switch on/off	11
2.6.4 Unlocking SIM card	11
2.6.5 Unlocking the phone	11
2.6.6 Connecting to the network	12
2.6.7 Making a call	12
2.6.8 Making a DDD	12
2.6.9 Calling extension of fixed telephone	12
2.6.10 Making an IDD	13
2.6.11 Calling the number in the list	13
2.6.12 Emergency call	13
2.6.13 Answering a call	13
2.6.14 Call log	13
2.6.15 Call timer	13
3. Function Menus	14
3.1 Using function menus	14
Send to search and select	14
List	14
3.2 Structure menu of function menus	14
3.1 Message	19

Meeting	34
Outdoor	35
Indoor	35
Headset	35
3.27 World Clock	35
3.28 Network Service	35
3.28.1 STK Service	35
3.28.2 WAP	35
3.28.3 Data Accounts	35
3.28.4 Connection Management	36
3.29 Unit Conversion	36
3.30 Currency Calculator	37
3.31 Fax Mailbox	37
3.32 Fax Sound Recording	37
3.33 SMSCB	37
3.34 Filter Recorder	37
3.35 Answering Machine	38
3.36 Repairer	38
3.37 Recorder	38
3.38 Slide	38
3.39 E-book	39
3.40 Bluetooth	40
3.41 TV	40
3.42 New Content	40
3.43 Internet	41
3.44 Stopwatch	41
3.45 Radio	42
3.46 Alarm Clock	42
3.47 Phone Book	43
3.48 Open	43
3.49 Misc	44
4 Input Method Description	44
4.1 Input Method Description	44
4.2 Handwriting Input	44
5 Flash Card Introduction	44
5.1 Flash Card Introduction	44
5.2 Installation and Initialization of Flash Card	45
5.3 Use of Flash card	45
6 Troubleshooting	45

3.3.1 New message	19
3.3.2 Create message	20
3.3.3 View received and saved SMS	20
3.3.4 Template	21
3.3.5 SMS setting	22
3.4 Calendar	22
3.5 Album	22
3.6 Camera	23
3.7 Cinema	23
3.8 Memo	23
3.9 Email	24
3.10 Create message	24
3.11 Calculator	25
3.12 eStudy	25
3.13 Map	25
3.14 Settings	25
3.14.1 Mute setting	25
3.14.2 Coordinate	25
3.14.3 Acceleration sensor calibration	25
3.14.4 Acceleration sensor settings	25
3.14.5 Phone ic settings	26
3.14.6 Network settings	26
3.14.7 Security Settings	29
3.14.8 Residual Factory Settings	29
3.14.9 Sound Effects	29
3.15 Call History	29
3.16 Wallpaper	29
3.17 Wireless Network	29
3.18 Jaw Entertainment	30
3.19 3015	31
3.20 Chatting	31
3.21 Games	32
3.22 Dynamic Game	32
A game named "Dynamic Disc" is provided	32
3.23 Fast Search	32
3.24 Call Center	32
3.24.1 Call History	33
3.24.2 Call Settings	34
3.25 File Management	34
3.26 Profile	34
General	34

other magnetic objects. The radiative wave of the mobile phone may also cause information saved in floppy disk, prepaid card and credit card.

Put the drawing pins and other small metal objects away from the headphone of the mobile phone. The loudspeaker is magnetic during working and will magnetize these small metal objects; it may hurt human body or damage the mobile phone.

Do not make the mobile phone moistened; it may cause overheat, electricity leakage and fault if water or other liquids enter the mobile phone.

1.3.3 Precautions of using battery

- Do not put the battery in fire; otherwise it may cause fire and explosion.
- Do not push by force when installing battery; otherwise it may cause liquid leakage, overheating, explosion and fire.
- Do not use electric wire, needle or other metal objects to short circuit the battery, and also do not put the battery together with necklace and other metal objects, otherwise it may cause liquid leakage, overheating, explosion and fire.
- Do not weld the battery; otherwise it may cause liquid leakage, overheat, explosion and fire.
- It may cause blindness if the battery liquid comes into eyes. Do not knead your eyes at this moment. Please use clean water to clean and go to see your doctor immediately.
- Do not use the battery if it is damaged, exploded and fire. Please do not deal with it by yourself.
- Do not use or put the battery near fire; otherwise it may cause liquid leakage, overheating, explosion and fire.
- If the battery has temperature rising, discoloration, distortion or other abnormal phenomenon in the process of using, charging or storage, please stop using the battery and change a new one.
- It may burn your skin if the battery liquid contacts your skin or clothes. Please use clean water to clean and go to see your doctor immediately.
- If there is liquid leakage or abnormal smell from the battery, please take it away from fire to avoid from fire and explosion.
- Do not make the battery moistened; otherwise it may cause overheating, smoking and erosion of the battery.
- Do not use or put the battery at places where it is irradiated by sunshine directly or near car, otherwise it may cause liquid leakage and overheating, and debase its performance and shorten its service life.
- Do not charge continuously for more than 24 hours.

1.3.4 Precautions of using charger

Please use 217V AC power supply. It may cause electricity

leakage, fire and damage the mobile phone and charger if you use other voltage.

Overheating is prohibited; otherwise it may cause electric shock, smoking and damage the mobile phone.

Do not use the charger if the power cord is damaged, otherwise it may cause fire and electric shock.

Please clean the dust on the outlet in time.

Do not put water container beside the charger to avoid overloading, electricity leakage and fault of the charger caused by water.

If the charger contacts water or other liquids, please cut off the power supply immediately to avoid overheating, fire, electric shock and charger fault.

Do not disassemble or refill the charger; otherwise it may cause body hurt, electric shock, fire and damage the charger.

Do not use the charger in places with high humidity; otherwise it may cause electric shock, fire and damage the charger.

Do not touch the charger, power cord and outlet with wet hands, otherwise it may cause electric shock.

Do not put heavy objects on the power cord or refill the charger; otherwise it may cause electric shock and fire.

Please pull out the plug from outlet before cleaning and maintenance.

Please hold the charger when pulling out the plug and it may damage the power cord and cause electric shock and fire if you pull the power cord.

1.3.5 Cleaning and maintenance

- The mobile phone, battery and charger are not waterproof. Do not use them in bathroom or other places with high humidity and also avoid being drenched with rain.
- Use soft cloth to clean the mobile phone, battery and charger.
- Do not use alcohol, diluents or benzene solution to clean the mobile phone, battery and charger.
- Out let with dirt may cause bad contact and power off, and can't charge thereby. Please clean regularly.

1.3.6 Common precautions

Please use this mobile phone in the environment with humidity between 35% and 85% and lower than 1700hPa.

Try to use this mobile phone at places away from normal telephone, TV set, radio and OA equipment to avoid affecting the performance of these devices and mobile phone.

Put the battery at places with good ventilation and no direct sunshine irradiation in temperature between 5°C-40°C.

- The service life of mobile phone battery is limited. The using time of battery will be shortened gradually after frequent charging. If the charging frequency is too high, the service life of the battery has reached its end and you need to change a new battery of appointed model.
- Do not drop used battery into common domestic refuse. Please follow local regulations if the disposal of used battery is stipulated clearly.
- Do not charge at the following places: with direct sunshine irradiation; environment temperature is lower than 5°C or higher than 40°C; With moisture, too much dust or vibration (may cause fault); near TV set, radio or other electric apparatus (may affect video and audio quality).

Charger:

2.1 Parts and functions.

The icons that may be displayed in standby interface and their meanings are as follow:

Icons	Description
	Indicate the intensity of network signal.
	You can use GPRS service.
	Vibrator is activated.
	New SMS.
	New MMS.
	Alarm clock is set and activated.
	Display when earphone is inserted.
	Enable call diverting function.
	Keypad unlocked.
	Keypad locked.
	Indicate battery status.
	Display missed calls.
	Enable chat function.

	Enable common stopwatch.
	New service message.
	Bluetooth earphone is activated.
	Bluetooth earphone matched.

2.2 Key description.

1. In the top of the mobile phone; press this key to lock or unlock the keypad; press and hold this key to switch on/off the mobile phone.
2. End key: End a call or reject an incoming call; press this key (center) to return to standby in other conditions.
3. Dial key: hold this key in dialing interface to switch among *, P and W. If key; press this key in dialing interface to input #; press and hold this key to switch between silent and general profiles.
- Dial key 1: call the number with SIM1.
- Dial key 2: call the number with SIM2.
- The key on the left of Dial key 1: Press this key to access Contacts.
- The key on the left of Dial key 2: Press this key to access Favorites.
- The last row of small icons in the dialing interface have the following functions from left to right:
 - First (pentagon): Call center (Log and Call settings)
 - Second: Access message interface
 - Third: Contacts list
 - Fourth: Return to standby
 - Fifth: Show list of Contacts

2.3 Introduction of touch screen

This mobile phone supports touch screen function.

1. Press the four icons in the bottom of the touch screen from left to right to access Dial, Contacts, Open and Music function respectively.
2. You can also click the icon on the touch screen to access the menu.
3. If you click and hold the menu icon in standby interface, all the icons will shake. It is mainly to avoid entering the menu by mistake. In this case, you can drag the icons to different positions, but can't enter the menu. Click the center key to stop the shaking and then you can enter the menu.

The battery in original state has about 50% electricity quantity and you can use it after unpacking. It performs best after full charge/discharge for the first three times.

To remove and install the battery

- To remove the battery: ① Push the back cover upside; ② lift the

battery, on the downwards and remove it.
To remove the battery, ① insert the battery in the bottom, ② put on the mobile phone cover.

2.5 Charging the battery

Connect the power supply of the charger.
Insert the plug of the charger into the bottom of mobile phone (keep the surface with arrow upwards).
The battery indicator on the screen will be flashing circularly, if the battery is being charged, a charging indicator image will appear on the screen when the battery is being charged. If the mobile phone is still used when battery is low, the charging indicator appears after the charging has started for a while. If the battery status indicator on upper right corner of the screen is not lit, the charging is finished. If the mobile phone is powered on, the charging indicator indicates that charging is finished will be displayed on the screen. This corner will be lit. It is normal that the battery, mobile phone and charger get warm in charging process.

Disconnect the AC outlet from mobile phone and charger when the charging is finished.

Note:
Use charger approved by manufacturer to charge at ventilated places with temperature between 5°C and 40°C. It may be dangerous if you use unauthorized charger and you will also violate the warranty clause. Please charge the battery in time if the mobile phone is power off automatically or indicates "Low battery". If the electricity hasn't been automatically recharging, the charging time will be shortened.

The standby and talk time provided by manufacturer are based on ideal working environment. The working time of battery depends on network status, environment and operating method in practice.

Make sure the battery is installed properly before charging and you disconnect the charger from mobile phone and power supply after charging.

If you don't disconnect the charger from power supply and mobile phone, the mobile phone will be charged again after a long time (about 1 to 8 hours) and the energy of the battery is wasted to a certain degree. It is not recommended because it will do harm to the performance and service life of the battery.

2.6 Connecting to the network

You must insert a valid SIM card before using your mobile phone. SIM card is the key for you to access digital GSM network.
For information about network connection and call initialization, as well as the numbers to dial for messages you have received and saved in SIM card phone book are recorded in the manual. After the insertion of the SIM card, you can remove the SIM card from your mobile phone and use the other GSM mobile phone (the new mobile phone will read the SIM card automatically).

Do not touch the metal surface area and keep the SIM card away from electricity and magnetism to avoid losing or damaging the information saved in SIM card. You can't access GSM network if the SIM card is damaged.

Warning: Please switch off the mobile phone before removing SIM card. Inserting the SIM card with external power supply is prohibited, otherwise the SIM card may be damaged.

2.6.2 Insert and remove the SIM card

The SIM card is usually stored in a card and you need to take it out carefully before installing.

- Turn off the mobile phone and remove battery and external power
- This mobile phone supports dual-card mode. Looking at the rear side of the phone, SIM1 is in the top slot and SIM2 is in the bottom slot. (Refer to mobile phone)
- Please turn off the mobile phone and remove the battery before removing the SIM card.

2.6.3 Switch off

Long press the Power key to switch on the mobile phone; to switch off the phone, also press this key.

If you switch on the mobile phone before inserting the SIM card, it will prompt you to insert the SIM card. The mobile phone checks whether the SIM card is valid automatically after it is inserted.

Input PIN if the SIM card is locked and the screen set.
Input phone password if the password of the phone has been set.
Searching - The mobile phone is searching for available network.

2.6.4 Unlocking SIM card

By setting PIN1 (personal identification number) code of the SIM card, you can protect your SIM card from illegal operation. If this function is enabled, you can't use the SIM card every time you switch on the mobile phone, then you can unlock the SIM card and use it. For details, users can click the code (refer to "Security settings" in Chapter 3.14.7). In this condition, the SIM card cannot be protected from illegal operation.

- Long press End Key to switch on the phone;
- Input OKNI code, click the Clear key to clear characters and click OK to finish. For example, if the PIN1 is 1234, you can input 1234.

If you input invalid password for three times continuously, the SIM card will be locked and you need to input PUK1 code. Contact your network operator if you don't know PUK1 code. Refer to Chapter 3.14.7 "Security settings" for details.

Note: your network service provider will set a standard PIN1 code (4-8 digits) for your SIM. SIM card will change it with your private password as soon as possible. Refer to Chapter 3.14.7 "Security settings" for details.

2.6.5 Unlocking the phone

Phone lock can prevent your mobile phone from illegal operation. You need to input the phone password when the PIN1 code (when PIN code is enabled) is input every time you switch on the mobile phone if this function is enabled. Then, you can unlock the phone and make or answer calls. Users can clear the code (refer to Chapter 3.14.7 "Security settings"). In this condition, the mobile

operator for details.

- You can perform the following operation in call options:
 - Hold single line
 - Hold the call or resume the held call.
 - Transfer single line call
 - End the current call
 - New call
 - Make a new call.
 - Access Contacts
 - Message center
 - Create and send a short message.
 - Create and DTMF
 - Press Left soft key to enable/disable DTMF.
 - Hands-free
 - Activate loudspeaker to enlarge call volume.

3. Function Menu

(※The application of following functions is dependent.)

3.1 Using function menus

Scroll to search and select

- In standby state, select to enter Main menu.
- In all menus and submenus, you can enter or exit the menu by touching the touch screen and following the prompts on the screen.

Exit Generally, you can click Back to return to previous menu; press Center key to return to Standby.

3.2 Structure menu of function menus

The default structure of function menus is as follow when SIM card is inserted and the power is switched on.

1. Messages
 - 1-1 Short message
 - 1-1-1 New message
 - 1-1-2 Inbox
 - 1-1-3 Outbox
 - 1-1-4 Drafts
 - 1-1-5 SMS settings
2. Calendar
 - 2-1 View
 - 2-2 View all
 - 2-3 Add event
 - 2-4 Edit event
 - 2-5 Go to date
 - 2-6 Week view
 - 2-7 Print
 - 2-8 Lunar
3. Album
 - 3-1 View

3-2 Lantern

- 3-2-1 Play
- 3-2-2 Settings

3-3 Edit

- 3-3-1 Auto resizing
- 3-3-2 Cutting out main screen
- 3-3-3 Manual cutting
- 3-3-4 Help

3-4 Print

- 3-4-1 Browse mode
- 3-4-2 Wallpaper
- 3-4-3 Screen saver
- 3-4-4 Power on image
- 3-4-5 Power off image
- 3-4-6 Caller image

3-7 Send

- 3-7-1 In MMS
- 3-7-2 In e-mail
- 3-7-3 In Bluetooth

3-8 Rename

- 3-10 Delete all
- 3-11 Sort
- 3-12 Storage position

4. Camera

- 4-1 Album
- 4-2 Camera settings
- 4-3 Lens switch
- 4-4 Photo settings
- 4-5 White balance
- 4-6 Scene modes
- 4-7 Special good effect
- 4-8 Image frame
- 4-9 Storage position
- 4-10 Reset

5. Gallery

- 5-1 Play
- 5-2 Sort
- 5-2-1 In e-mail
- 5-2-2 In Bluetooth
- 5-3 Rename
- 5-4 Delete
- 5-5 Delete all
- 5-6 Sort
- 5-7 Streaming media website
- 5-8 Network settings
- 5-9 Storage position
- 5-9-1 Phone

5-9-2 Memory card

6. Memo

7. E-mail

7-1 Send and receive

7-2 Edit e-mail

7-3 Inbox

7-4 Outbox

7-5 Sent

7-6 Drafts

7-7 Outbox marked e-mail

7-8 Delete marked e-mail

7-9 E-mail accounts

7-10 Template

8. New message

8-1 Send in SIM1

8-2 Send in SIM2

8-3 Select template

8-4 Insert object

8-5 Text format

8-6 Insert contact number

8-7 Insert contact name

8-8 Insert bookmark

8-9 Insert method

9. Calculator

10. eBuddy

11. Map

12. Settings

12-1 Mode setting

12-1-1 SIM1 Card

12-1-2 SIM2

12-1-3 SIM?

12-1-4 Flight mode

12-2 Coordinate

12-3 Acceleration sensor calibration

12-4 Acceleration sensor settings

12-5 Phishing protection

12-5-1 Time and date

12-5-2 Schedule power on/off

12-5-3 Language

12-5-4 Select input method

12-5-5 Select input method

12-5-6 Call

12-5-7 Standby menu display

12-5-8 Greetings

12-5-9 Auto update time

12-5-10 Handwriting settings

12-5-11 UART settings

12-5-12 User settings

12-6 Network settings

12-7 Security settings

12-7-1 SIM1 security settings

12-7-2 SIM2 security settings

12-7-3 Phone lock

12-7-4 Keypad lock

12-7-5 Chang password

12-7-6 Banglar tracing

12-7-7 Incoming call firewall

12-7-8 MMS firewall

12-7-9 Remote control

12-8 Restore factory settings

12-9 Sound effect

13. Call log

14. Wallpaper

15. Wireless network

15-1 Wireless LAN

15-2 Status of wireless network

15-3 Access point settings

15-4 Scan network

16-1 Java

16-2 Java settings

16-3 Default security of Java

17. MMS

17-1 New message

17-2 Inbox

17-3 Outbox

17-4 Drafts

17-5 Template

17-6 MMS settings

17-6-1 Editing setting

17-6-2 Sending setting

17-6-3 Receiving setting

17-6-4 Filter

17-6-5 Status settings

17-6-6 Memory state

18. Chat

19. Games

19-1 Mah-jong

19-2 Jigsaw puzzle

19-3 Mahjong

19-4 Mahjong

19-5 Game center*

19-6 Mobile QQ*

19-7 Game settings

20. Dynamic games

21. Quick search

21-1 IP Call

21-2 IP call

- 21-3 Send SMS
- 21-4 Send MMS
- 21-5 View
- 21-6 New
- 21-7 Delete
- 21-8 Copy
- 21-9 Move
- 21-10 Send contact
- 22 Call log
 - 22-1 Print
 - 22-2 Call log
- 23 File manager
 - 23-1 Phone
 - 23-2 Memory card
- 24 Profiles
 - 24-1 General
 - 24-2 Meeting
 - 24-3 Outdoor
 - 24-4 Indoor
 - 24-5 Earphone
 - 24-6 Bluetooth
 - 24-7 Book
- 25 Services
 - 26-1 STK service (SIM1)*
 - 26-2 STK service (SIM2)*
 - 26-3 WAP*
 - 26-4 Data accounts
 - 26-5 Location management
- 27 Unit converter
 - 27-1 Weight
 - 27-2 Length
- 28 Currency converter
- 29 Voice mail
- 30 Fax sending
- 31 Cell broadcast
 - 31-1 Receiving mode
 - 31-2 Read message
 - 31-3 Language
- 32 Video capture
 - 32-1 Video order settings
 - 32-2 Video settings
 - 32-3 Lens switch
 - 32-4 Special good effect
 - 32-5 Storage position
 - 32-6 Reset
- 33 Answer machine
 - 33-1 Message

- 33-2 Settings
- 34 Repeater
 - 35-1 New recording
 - 35-2 List
 - 35-3 Settings
- 36 Lantern slide
- 37 E-book
- 38 Bluetooth
 - 38-1 Activate Bluetooth
 - 38-2 Search for hands-free device
 - 38-3 My device
 - 38-4 My device
 - 38-5 Online device
 - 38-6 Settings
 - 38-7 My Bluetooth
- 39
 - 39-1 My channel
 - 39-2 Scan channels
 - 39-3 Channels list
 - 39-4 Area settings
 - 39-5 Add to my channel
- 40 New contact
- 41 Incoming Q*
- 42 Incoming*
- 43 Stopwatch
- 44 Radio
 - 44-1 Channels list
 - 44-2 Manual input
 - 44-3 Auto scan
 - 44-4 Scan
 - 44-5 Sound recording
 - 44-6 Appendix
 - 44-7 Files list
 - 45 Alarm clock

Note: The menus with "*" appear in specific conditions only.

3.3 Message
 Select "SMS" to enter the submenu.
 If the network supports and you have subscribed this service, you can send or receive Chinese and English SMS and MMS through service center.
3.3.1 New Message
 When you receive a new message, the mobile phone will vibrate (vibration is activated) or send alert tone (sound prompt is activated) on the screen. If you don't read the message, a prompt of new message will be displayed on home screen and the message will be saved in SIM card automatically. The number of messages (received and saved) saved in SIM card is dependent on SIM card capacity.

To read the message, enter submenu Inbox and press OK.

3.3.2 Create message

The SMS service enables you to send SMS to other mobile phones that can receive SMS.

Make "SMS setting" number of SMS center has been set before write SMS (refer to "SMS setting").

Enter submenu Create SMS to write SMS (refer to Chapter 4.2 "Input methods"). Click options menu in input interface to perform the following operations:

OK: Select this option to finish this SMS and enter next operation.

Templates: Insert preset template into the message.

Send: Send the message to the recipient.

Text format: Define the text format of the SMS.

Insert contact number: Insert the telephone number of the entry in Contacts.

Insert bookmark: Insert the web address of selected message.

Input method: Change the input method when editing message, and you can click Send, Save, and send.

Send: Send the SMS to multiple numbers, and you can click Send, Save, and send.

Send to group: Select a group and send the SMS to every member of the group.

Note: Short messages centers in some cities and areas don't support long short messages of more than 70 Chinese characters (or 160 English characters).

3.3.3 View received and saved SMS

Enter submenu Inbox to view received SMS; enter Outbox to view the SMS you have saved in SIM card.

When you view the SMS list of Inbox, the receiving time and date, and the other party's number or name (if the tel number is saved in Contacts) will be displayed.

When you view the SMS list, you can select previous or next SMS. When the messages list of Inbox is empty, you can press OK to read the message. You can press Option to perform the following operations:

Reply: Send SMS to the sender of this message.

Forward: Delete this SMS.

Copy: Forward this SMS.

Move to phone (SIM): Copy the SMS from SIM card (mobile phone) to mobile phone (SIM card).

Delete all: Delete all SMS in phone (SIM card).

Move all: Copy from SIM card or mobile phone (mobile phone) to mobile phone (SIM card).

Use numbers: Pick up the phone number of the sender and you can dial or call in Contacts.

Use USSD: Pick up the web address in the message.

Use web address: Pick up the web address in the message.

Use email: Pick up the e-mail.

Chat: Enter chat.

Print: You need to activate Bluetooth to match Bluetooth device.

When the messages list in Outbox appears, you can press OK to read the messages. You can press Option to perform the following operations:

Send in SIM1 (SIM): Copy the SMS from SIM card (mobile phone) to mobile phone (SIM card).

Send in SIM2 (SIM): Copy the SMS from SIM card (mobile phone) to mobile phone (SIM card).

Copy: Copy the SMS from SIM card (mobile phone) to mobile phone (SIM card).

Delete all: Delete all SMS in Outbox.

Move all: Copy from SIM card or mobile phone (mobile phone) to mobile phone (SIM card).

Use numbers: Pick up the phone number of the recipient and you can dial or call in Contacts.

Use USSD: Pick up the web address in the message.

Use email: Pick up the e-mail.

Print: You need to activate Bluetooth to match Bluetooth device.

3.3.4 Template

Enter submenu Templates to match Bluetooth device. Frequently used sentences in Templates to avoid repeated input of same contents. You can edit or delete the templates.

3.3.5 SMS setting

You need to perform necessary settings before using SMS function. Enter submenu SMS setting.

Mode setting: Select a suitable mode for mobile phone SMS. Enter the mode and you can set the name, SMS center

To read the message, enter submenu Inbox and press OK.

3.3.2 Create message

The SMS service enables you to send SMS to other mobile phones that can receive SMS.

Make "SMS setting" number of SMS center has been set before write SMS (refer to "SMS setting").

Enter submenu Create SMS to write SMS (refer to Chapter 4.2 "Input methods"). Click options menu in input interface to perform the following operations:

OK: Select this option to finish this SMS and enter next operation.

Templates: Insert preset template into the message.

Send: Send the message to the recipient.

Text format: Define the text format of the SMS.

Insert contact number: Insert the telephone number of the entry in Contacts.

Insert bookmark: Insert the web address of selected message.

Input method: Change the input method when editing message, and you can click Send, Save, and send.

Send: Send the SMS to multiple numbers, and you can click Send, Save, and send.

Send to group: Select a group and send the SMS to every member of the group.

Note: Short messages centers in some cities and areas don't support long short messages of more than 70 Chinese characters (or 160 English characters).

3.3.3 View received and saved SMS

Enter submenu Inbox to view received SMS; enter Outbox to view the SMS you have saved in SIM card.

When you view the SMS list of Inbox, the receiving time and date, and the other party's number or name (if the tel number is saved in Contacts) will be displayed.

When you view the SMS list, you can select previous or next SMS. When the messages list of Inbox is empty, you can press OK to read the message. You can press Option to perform the following operations:

Reply: Send SMS to the sender of this message.

Forward: Delete this SMS.

Copy: Forward this SMS.

Move to phone (SIM): Copy the SMS from SIM card (mobile phone) to mobile phone (SIM card).

Delete all: Delete all SMS in phone (SIM card).

Move all: Copy from SIM card or mobile phone (mobile phone) to mobile phone (SIM card).

Use numbers: Pick up the phone number of the sender and you can dial or call in Contacts.

Use USSD: Pick up the web address in the message.

Use web address: Pick up the web address in the message.

Use email: Pick up the e-mail.

Chat: Enter chat.

Print: You need to activate Bluetooth to match Bluetooth device.

When the messages list in Outbox appears, you can press OK to read the messages. You can press Option to perform the following operations:

Send in SIM1 (SIM): Copy the SMS from SIM card (mobile phone) to mobile phone (SIM card).

Send in SIM2 (SIM): Copy the SMS from SIM card (mobile phone) to mobile phone (SIM card).

Copy: Copy the SMS from SIM card (mobile phone) to mobile phone (SIM card).

Delete all: Delete all SMS in Outbox.

Move all: Copy from SIM card or mobile phone (mobile phone) to mobile phone (SIM card).

Use numbers: Pick up the phone number of the recipient and you can dial or call in Contacts.

Use USSD: Pick up the web address in the message.

Use email: Pick up the e-mail.

Print: You need to activate Bluetooth to match Bluetooth device.

3.3.4 Template

Enter submenu Templates to match Bluetooth device. Frequently used sentences in Templates to avoid repeated input of same contents. You can edit or delete the templates.

3.3.5 SMS setting

You need to perform necessary settings before using SMS function. Enter submenu SMS setting.

Mode setting: Select a suitable mode for mobile phone SMS. Enter the mode and you can set the name, SMS center

number, validity and sending format.
State setting: Set whether enable message report or reply picture.
Memory state: View the status of SIM card or mobile phone memory.
Storage positions: Save in mobile phone or SIM card.
SMS center number setting: Please contact your local network operator to get the number of SMS service center. For example, one of +8613802110506. The specific operation is: Select a new setting in SMS submenu, enter the number of SMS center and press OK to save the setting.
Report: If the message report is enabled, the SMS center will send report when the other party receives or doesn't receive the SMS.
Note: This function needs network support.

3.4 Calendar

Enter submenu Calendar and press OK to display the date.
 Click the Left/Right key to select date and month.
 Press Options to enter submenu.

Today: Click Today with the stylus to view the schedule of today (if edited), click the blank area below to have Edit and Calendar menu, and you can create new schedule and return to List.
List: List all schedules; click Options menu to perform operations like View, Add, Edit, Delete, Send (in SMS, MMS, e-mail or Bluetooth), and Save as file (in SIM card or mobile phone).
Week view: Activate Week view and the calendar will be displayed in week.

3.5 Album

Access the Album to perform operations like View, Play lantern slide, Fill, Print, browse mode, Use as, Send, Rename, Delete, Delete all, Sort and Storage.
3.6 Camera
 This mobile phone is integrated with camera function. Click the camera icon at the bottom of screen to enter. Click the icons in the interface to perform operations like Special good effect, White balance, Shooting mode, Sequence setting, Scene mode, Image quality and Image size. You can also press Options to access:

Album: Access Album.
Camera settings: Set corresponding parameters of taking pictures.
Lens switch: Select Lens 1 or Lens 2.

Image settings: Set the size and quality of images.
White balance: Set the color temperature light.
Scene mode: Set the shooting mode.
Special good effect: Select viewing style.
Storage: Select a frame for picture.
Sort: Sort the files in mobile phone or memory card.
Reset: Restore the default settings.
Note: In viewing interface, click the icon to set corresponding image effect.

3.7 Cinema

Enter video playing.
 Press Options to enter.
Non explanation:
Play: Play the selected file.
Sort: Sort the files in mobile phone or memory card.
Remove: Remove the name of selected file.
Delete: Delete all selected file.
Delete all: Delete all selected file.
Sort: Sort the files (according to name, Type, Time, Size, or Name).
Streaming media website: Inhibit websites, history websites or new websites.

3.8 Memo

Storage positions: Five options are available.
Note: The default storage position of video player is memory card and the folder name is Video.
 You can save 50 entries of memo in this mobile phone. Select Memo in the submenu and perform operations like View, Add, Edit, Delete, Delete expired schedule, Delete and to date, Send schedule and Save as file.
3.9 E-mail

Select E-mail to enter the menu and the submenus are:
Send and receive: After setting and enabling e-mail account, you can select the options to send and receive e-mail.
Edit: Create new e-mail. You can add recipient, cc, bcc, subject, content and attachment. Then, you can select Send, Send and save, Save in Drafts or Exit.
Inbox: View received e-mail. You can perform operations like View, Sort, Mark to delete, Delete and Forward.
Outbox: Save the e-mail that hasn't been sent successfully. (The operation is one to inbox)
Deleted: Save e-mail which will be sent later. You can perform operations like View, Sort, Mark to delete and Delete.
Clear e-mail: Five submenus are available: Inbox, Outbox, Sent, Drafts and All.

You can select to clear certain list, or select All to clear all lists.
Delete marked e-mail: Five submenus are available: Inbox, Outbox, Sent, Drafts and All.
 You can select to clear certain list, or select All to clear all marked e-mails.

■ **E-mail account:** Press Options to enter a new account. Click Options to select Next, input method or Cancel. After inputting, enter next step.

1. **New account:** Enter your e-mail address (e.g. A@126.com) to create a new account. Click Options to select Next, input method or Cancel. After inputting, enter next step.

2. **Communication protocol:** Select the communication protocol (IMAP4 or POP3) for e-mail. (the protocol provided by your e-mail server, e.g. POP3) Click Options to enter next step and set data account.

3. **Data account:** Select the GPRS account of sending e-mail (e.g. CHINA MOBILE GPRS) or select your network operator. Click Options to enter next step and set receiving server.

4. **Receiving server:** Set the pop3, address of receiving server (e.g. pop3.126.com). After setting, enter next step and set sending server.

5. **Sending server:** Enter the smtp address of e-mail server (e.g. smtp.126.com). Then, enter next step and set User name (e.g. A before @). Then, enter next step and set Password.

6. **User name:** Enter the user name and password and then enter the chat room.

7. **Password:** Enter the password of the e-mail (e.g. B). Then, enter next step and set Account name.

8. **Account name:** pop3.126.com by default.

You can create a new account by default. You can also create a new account like Start, Edit, New account and Delete. You can also create a new account like Start, Edit, New account and Delete.

The second option, Display name, the name displayed when the recipient receives the e-mail (e.g. A) can enter any name here.

Account setting: after setting the parameters of e-mail, enter:

Services - Data account - GPRS, select the sending account (e.g. CHINA MOBILE GPRS). Then, change the GPRS connection point from "enwap" to "enmet" (note: Max size: The maximum size of each e-mail).

Sending server settings: Scaling port: 25 by default.

Authentication: "On" by default.

Receiving server: the receiving port is 110 by default.

Signature: display the signature at the end of the e-mail.

3.1.0 Create messages. The pre-stored messages; you can perform operations like Edit, Delete and Edit e-mail.

Refer to Section 3.3.2 Create message

3.1.1 Calculator. This mobile phone provides a calculator with four basic functions. Select Calculator and press OK to enter. Click the screen to enter the numbers to calculate. Click the arrow to clear the last character and click "Back" to exit the calculator.

Note: This calculator features limited accuracy due to

3.1.3 eBuddy. The mobile phone provides wireless LAN instant message tool. You can add and perform the following operations.

First, select language. Several languages are available.

Second, create an eBuddy ID. You need to enter eBuddy account, eBuddy ID, password, e-mail address, gender, age, etc.

Third, select the network and log in the chat room. You can select MSN, Yahoo!, AIM, Gtalk, ICQ or Facebook as the network for chatting. Enter the user name and password and then enter the chat room.

3.1.3 Map. You can check in Google Maps through wireless LAN. Use this map to consult road names, check in view map and record favorites.

3.1.4 Mode setting. You can select Dual-card, SIM1, SIM2 or Flight mode.

4 Flight mode: The communication function of the phone is disabled in flight mode, i.e. you can't make or answer calls, or send short messages, and the phone won't receive signals from base station or try to search for base station.

In this mode, the functions related to signals are disabled, but you can still use other functions, e.g. view Camera, read documents or watch movies in the mobile phone.

Although the civil aviation department bans regulations on "Flight mode", passengers should still follow the rules in aircraft (e.g. in the night) to save power. You can switch to this mode in some times when signals are weak or you are in a crowded place.

3.1.4 Coordinate. Adjust the coordinates to make it more accurate through Coordinate.

3.1.4.3 Acceleration sensor calibration. By calibrating the acceleration sensor, you can make the interface faster, smoother and more accurate.

3.1.4.4 Acceleration sensor settings. The screen provides the specific menu to use acceleration sensor. You can select or cancel the specific menu to realize gravity sense function.

The functions that the sensor can realize in music player interface, shake left and right to switch to previous or next track, in TV interface, shake left and right to switch channel, in TV interface, shake left and right to select channel, in video interface, shake and right to switch video. You can rotate the mobile phone in different directions and watch video in different angles.

In Album, you can rotate the mobile phone in different directions and view pictures in different angles.
Rotate the phone 180° in incoming call interface to make the incoming call silent.
In games interface, shake the mobile phone left and right to play games.

3.14.5 Phone settings

- Time and date: Set time and date.
- Standby: Select a city for the time setting of the mobile phone.

- Time/date setting: Set current time and date.

- Format setting: Set the display format of time and date: 12-hour or 24-hour.

- Blending time zone and time: Select On or Off. If On is selected, the time zone will be set according to the current location.

- Schedule power on/off: Set the time at which the mobile phone will power on/off.

- Language: Set the displaying language of mobile phone menus.

- Input method: Select to activate or deactivate the input method of corresponding language.

- Input method: Select default input method.

- Coding: BIG5 and GB2312 are available.

- Standby menu display: Wallpaper: Select standby interface wallpaper.

- Screen saver: Choose a screen saver picture for main standby interface and set waiting time.

- Power on image: Select pictures for power on image.

- Power off image: Select pictures for power off image.

- Screen switch effect: It has different effects when you select menu and enter.

- Greetings: Display greetings in the displaying process of power on image.

- Screen Off to disable: Enable/disable auto update time.

- Handwriting Setting: Set handwriting style and stylus color.

- UART setting: Select UART of SIM1 or SIM2.

- Other settings: Set LCD brightness and delay.

3.14.6 Network settings

- Network selection: Search: Press OK to access new network.

- Search network: Search for and access network.

- Scan mode: Auto: Scan the network of this SIM card automatically.

- Manual: Search for all available network and register manually.

3.14.7 Security Settings

- SIM Lock: You can set the security options under this menu to prevent the mobile phone or SIM card from unauthorized usage.

- PIN Code: PIN code can prevent the SIM card from unauthorized usage.

If PIN code has been disabled, you can enable the PIN protection and PIN. When the phone is powered on, the phone will prompt you to enter the PIN code. If you have disabled the PIN code, you can enable it. Also you can change the PIN code by selecting "Change PIN". Please enter the old PIN, the new PIN, and repeat the new PIN as prompted.

Attention: If you enter the invalid PIN code for three times, the SIM card will be locked, and then you need PUK code to unlock it. PIN and PUK code are supplied with the SIM code. If they are not, you can contact the operator. The default PIN code is 1234, and you'd better change it as soon as possible.

- Phone Lock: Phone lock can prevent your cell phone from unauthorized usage.

- Phone lock can enable the cell phone protection. The password will be required when the phone is powered on the next time, and you can disable the protection by pressing the bottom again.

- Attention: the default cell phone password is 1122, and you'd better change it as soon as possible.

- Keypad lock: You can set the latency time of the keypad lock. If the phone is not be used within the specified time, the keypad will be locked automatically.

- Passwords Changing: You can change the PIN, PIN2, and cell phone lock passwords. All operations need the support of network operator.

- Anti-Theft Tracking: When your mobile phone has been lost, it will send SMS to a specified number when the SIM card has been replaced. You can find who is using your phone through the SMS, so it is helpful for you to return it.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

- Anti-Theft Tracking Number: Input the tracking number, which is the number to receive the anti-theft SMS.

- Anti-Theft Tracking Setting: ON/OFF. You can choose ON to enable this function.

This phone has the function of remote control. You can control your phone by sending SMS from your phone to your own phone when it is away from you.

Notes: The default password to enter remote control interface is 0000, and you can change it.

1. Remote Control Settings: options available are:

- 1 Remote Control Setting
- 2 Call Phone Lock
- 3 Call Phone Lock
- 4 Disk Formatting
- 5 SMS Forwarding
- 6 Name card Formatting

Attention: 1. Remote control of a specific function is valid after you have enabled it. 2. Call diverting needs network support.

2. Controlling Number Settings: you can choose optional number or specified number to the controlling number.

- 1 Pre-wait phone from specified number (controlling SMS to your own phone from a specified number)
- 2 Specified Number (sending SMS to your own phone from a specified number)

3 Password Changing: To change the factory default password of entering remote control interface.

4 Remote Control Commands Presetting: The remote control commands are default. You just send SMS to your own phone after you have entered the corresponding proper command.

1. Remote Power-off Command
Command: POWER OFF
2. Call Forwarding Command
Command: CALL DIVER
3. Call Phone Lock Command
Command: PHONE LOCK
4. Disk Formatting Command
Command: DISK RESUME
5. SMS Forwarding Command
Command: SMS DIVER
6. SMS Forwarding Command Canceling
Command: CANCEL SMS DIVER
7. Name card Formatting Command
Command: PHONEBOOK DIVER

Attention: The options for changing the remote control commands include numbers, letters, and symbols, and the amount of them can be 19 or less than 19.

2. When you send SMS with default commands to your own phone, you will be automatically forwarded to your own phone. You enter the specified phone number to receive the call or SMS will be automatically answered when you receive the call or SMS. You will be automatically answered when you enter the needed name after the command and send the SMS to your phone.

3.14.R. Restore Factory Settings

The default password for restoring factory settings is 1122.

3.14.S. Sound Effects

You can adjust the sound effects by choosing the audio equalizers of resound effect, atrophy sound effect, or disable it.

3.15. Call Center

The phone displays all the call times and you can see the date, calling time, calling number, calling time, and calling duration of each time to the "Call Center" menu. You can click the "Call Center" button to delete, save the number to the phonebook, call, call with IP, edit, send SMS, or send MMS.

Notes: call history includes the card 1 and card 2, both of which have all the call history.

3.16. Wallpaper

In this interface, you can choose from various wallpapers. When the keypad is unlocked, you will see the wallpaper you have chosen.

3.17. Wireless Networks LAN

The process of using WiFi Function

- Step 1: click "Network Service" from the interface of standby.
- Step 2: click "Data Account".
- Step 3: click "Wireless LAN".
- Step 4: click "Start Wireless".
- Step 5: click "Search" search with powerful signal (such as WIFIALO) or networks available.
- Step 6: choose "Definition Access Point" of corresponding network.
- Step 7: click "Definition Access Point" and choose the sixth item.
- Step 8: enter "Entry Point Setting" and choose the sixth item.
- Step 9: enter "WEP Key Setting".

WEP Key: change it to "128 digits" (according to actual settings of wireless route).

WEP Key Mod: change it to "ASCII" (according to actual settings of wireless route).

WEP Key: enter the password (if router has no password, you can select it).

WEP Key: click "Connect".

3.18. Java Entertainment

You should download games supported by the phone from the Internet.

- **Java:**
 - Game lists
 - Java settings
 - Java Audio Equalizer: set the volume.
 - Java Vibration: ON/OFF.
 - Java Virtual D-Pad: Upper/lower/Permit For Once only Permit at all times.
- **SIM Card Chaining:** SIM 1/SIM 2.
- **Java SIM Card 1 Settings:** choose the network operator website.
- **Java SIM Card 2 Settings:** supply the network operator websites.
- **Capacity of Memory:** display the capacity of memory.
- **Java Default Security:**
 - The **Third Party:** you can set some parameters, such as network access, automatical execution, information, multimedia, subscriber data reading, subscriber data writing, local on-line, and so on.
 - Distraint Scope:** you can set some parameters, such as network access, automatical execution, information, multimedia, subscriber data reading, subscriber data writing, local on-line, and so on.
 - Restore Default:** restore default setting.
 - Scope Options:** the third party and distraint scope can be chosen ON/OFF.
- **3.19 MMS**
 - **Create MMS:** you need to write the receiver, copies, secret copies, title, text, and CC when you create a new MMS.
 - **Inbox:** you can read MMS from inbox. (the process is same to that of SMS)
 - Read: read the current MMS.
 - Reply: reply with MMS to the sender.
 - Reply with SMS: send SMS to the sender.
 - Reply MMS to all the receivers: send MMS to all the MMS receivers.
 - Forward: forward the MMS to others.
 - Delete: delete the current MMS.
 - Delete All: delete all the MMS in the inbox.
 - Save MMS as Stamp: you can save the MMS to the user definition of the pressing MMS.
 - MMS Details: you can read all the detail information about the MMS.
 - Usage Details: you can send SMS to the MMS sender, call it, or save the number to the phonebook.
 - **Outbox:** the outbox saves the MMS failed to be sent out (the process is same to that of SMS)
 - Read: read the current MMS
 - Send: send the current MMS
 - Delete: delete the current MMS
 - Delete All: delete all the MMS in the inbox.
 - Save MMS as Stamp: you can save the MMS to the sender of the pressing MMS.
 - MMS Details: you can read all the detail information about the MMS.

- **Usage Details:** you can send SMS to the MMS sender, call it, or save this number to the phonebook.
- **Send:** you can send MMS to the MMS sender, call it, or save this number to the phonebook.
- **Read:** you can read the current MMS.
- **Edit:** edit the current MMS.
- **Delete:** delete the current MMS.
- **Delete All:** delete all the current MMS.
- **Save MMS as Stamp:** you can save the MMS to the user definition of the pressing MMS.
- **MMS Details:** you can read all the detail information about the MMS.
- **Usage Details:** you can send SMS to the MMS sender, call it, or save this number to the phonebook.
- **Template:** you can customize the MMS or use the default MMS. User can create a new MMS based on it, and also you can delete it or read the detail information of it.
 - **Default:** you can read the default MMS and create a new MMS based on it or to read the detail information about it.
 - **MMS Settings:** you can set the sending parameters about the MMS.
 - **Editing Settings:** you can set the editing parameters about the MMS. For example, the editing mode, the size of pictures, the best playing time, automatic signature, signature and so on.
 - **Sending Settings:** you can set the parameters about sending the MMS, such as duration of use, sending report, receiving report, and so on.
 - **Receiver Settings:** you can set the parameters about receiving the MMS, such as main network, roaming network, reading report, and sending report.
 - **Filter:** filter parts of MMS.
 - **Server Settings:** choose the server corresponding to SIM1 and SIM2.
 - **State of Memory:** you can check the memory state of MMS.

3.20 Chatting

- **Chatting Settings:** you can choose a chat room and set a pet name of yourself and the number you want to chat with.
 - **Begin Chatting:** enter required information and begin chatting with the specified games.

3.21 Games

- **Game Background Sound Effect:** ON/OFF
- **Sound Effect:** ON/OFF

Game Vibrating: ON/OFF
volume: 1 to 7 available

3.2.2 Dynamic Game
3.2.3 IP Dialing

- **Fast Search:** select this item to enter "Phonebook Browsing" interface, a searching frame is displayed in the window. You can enter corresponding message into the frame to search for the numbers you want. There are many searching methods provided, such as pinyin, letters, numbers and so on.
- **Names Search:** search the number you want by entering the name. You can call or IP call the number, and you can send SMS and MMS to the number, and also read, delete, copy, remove, send or print the name card.

3.2.4 Call Center

3.2.4.1 Call History

It includes the history of SIM 1 and SIM 2, respectively. Here we take SIM 1 as an example, as the operation of SIM 2 is the same as that of SIM 1.

- **Missed Calls:** press OK to view the list of missed calls.
- **Dialled Numbers:** press OK to view the list of dialled numbers.
- **Answered Calls:** press OK to view the list of answered calls.
- **Call Log:** press "OK" to view the detailed information of an entry, including date, time of call, number and duration of information. You can press "Option" to perform the following operations for current selected call record.
 - **Delete:** delete this record.
 - **Save to Phone Book:** save this number to SIM or phone memory.
 - **Call:** dial this number.
 - **IP Dialing:** use IP dialing to dial.
 - **Edit:** edit this number and save it to phone book.
 - **Send SMS:** send SMS to this number.
 - **Send MMS:** send MMS to this number.

There are four submenus in "Call History": "Missed Calls", "Dialled Numbers", "Answered Calls", and "Delete All".

Users can select to clear certain record list. Once you select "Delete All", you will delete all the record lists from the call history.

Call Duration

There are four submenus in "Call Duration": "Last Call Duration", "Dialled Calls Duration", "Answered Calls Duration", and "Reset All".

Users can select to clear certain record list. Once you select "Reset All", you will delete all the record lists from the call history.

Call Timers: view the total received calls' time.

Reset All: clear timers and restart timing.

Item: save total call charges for you.

Last Call Charge

Enter the submenu "Last Call Charge" to view last call charge.

Total Calls Charge: view the total calls' charge.

Reset Call Charge: reset the total calls' charge.

Charge Limit: you can clear call meters and restart billing.

Prepaid: you can view, modify or cancel this function.

Pin2: you can view, modify or cancel this function. PIN2 is required for function "Modify" and "Cancel".

Attention: You need to input PIN2 for part of the operations. Please contact our network providers for passwords.

SMS Counter: record the number of sent SMS.

Received: record the number of received SMS.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

Reset Counter: you can clear call meters and restart billing.

- **Divert All Data Calls:** divert when it is data call.
- **Cancel Divert:** cancel all divert.
- **Call Barring Service:**
 - **Barring Out-going Calls:** bar the out-going calls.
 - **Barring All Incoming Calls:** bar the incoming calls, as well as incoming calls (Passwords are required).
 - **Cancel All:** cancel the barings set by you. (Passwords are required).
- **Modify Passwords:** modify it.
- **Line for Outgoing Calls:** select one 1 or the 2.

2. **Advanced Settings**
- **Blacklist:** the numbers in the blacklist would be screened out.
 - **Automatic Redial:** enable it, it will redial automatically after call fails.
 - **Speed Dialing:** enable it, press the related key for a long time to set speed dialing in standby. You can set 2-9 as the key for speed dialing.
 - **IP Dialing:** set and enable it, you can perform the function of "IP Dialing" through your phone book.
 - **Background Sound:** you can choose to enable or disable Background Sound when you are dialing.
 - **Display of Life Time:** enable it, the calling time would be displayed, vice versa.
 - **Prompt Life Timer:** set up frequency; you would be reminded by the warning tone when time is over.
 - **Automatic Time Limit:** enable it and set the time. Your call will be cut off when the time you set is up.

3.25 **File Management**
 Store the files saved by users (phone or memory card). Enter options of the folder:

- **Open:** display the contents in the folder.
- **New folder:** create a new file folder in this folder.
- **Formatting:** format this folder.

Note: rename the memory card and view its capacity.
 3.26 **Profile**
 Users can choose different profiles and define several profiles at the same time. There are six profiles in this phone: **General, Meeting, Outdoor, Indoor, Headset and Bluetooth.**

General
 You can select "Activate" or "Personalize".
 ■ **Activate:** select "Activate" then you have to set the "Personalize" option.
 ■ **Personalize:** select "Personalize" and enter you can define the "Prompting Type", "Ringling Tone", "Ringling Volume", "Prompting Type", "Prompting Type", "Other Warning Tone" and "Answer Mode".

Meeting
 Its operation is the same as that of "General".

Outdoor
 Its operation is the same as that of "General".
Indoor
 Its operation is the same as that of "General".

Headset
 Insert the earphone then this profile will be activated automatically. The operation of personalization is the same as that of "General".
Bluetooth
 Start your Bluetooth earphone and activate Bluetooth. To enter this profile, the operation of personalization is the same as that of "General".

3.27 **World Clock**
 Touch the screen to select the time of each country in the world. Select "Options", you can enable or disable the time of other countries to enable the daylight saving time.

3.28 **WAP Service**
 This function is provided by network provider, such as the following value-added brand service: M-portal, M-zone, VIP Zone of Global Service.

3.28.2 **WAP**
 Your phone can support WAP service, so you have access to the service provided by the network provider. You could use the following information through the WAP service: weather forecast and flight information.
Attention: Network support is required for GPRS service. You must subscribe to GPRS service and in the coverage of GPRS, and then you can use this service.

- **Homepage:** visit homepage. Homepage is the first website you set in the connection of network you have. Select one of them, you can browse the website directly.
- **Webpage History:** this item would record the entire website you browsed before.
- **Saved Webpage:** this item records the web pages you saved before.
- **Want to surf:** select this item you can input any website, WAP, other websites.
- **Service Inbox:** save message sent by service operator.
- **Settings:** set to surf the internet.

3.28.3 **Data Accounts**
GSM Data: select one account number to enter.

1. **Name of Account:** you can select "Edit" to modify.
2. **Number:** the number of this account.
3. **User Name/ID:** the account name of dial-up server (not the gateway of WAP).
4. **Password:** password of dial-up server (not the gateway of WAP).
5. **Type of Line:** select the type of line, analog or digital.
6. **Speed:** speed of transmission.

7. **Primary DNS Address:** display its primary address.
 8. **Secondary DNS Address:** display the secondary address.
- GPRS Data:** select one account number to enter.
1. **Account:** you can select "Edit" to modify this name.
 2. **Connecting Point of GPRS:** input APN (not the gateway of WAP)
 3. **User Name/ID:** the account name of dial-up server
 4. **Password:** password of dial-up server (not the gateway of WAP)
 5. **Type of Authentication:** select the type of code to authenticate.
 6. **Primary DNS Address:** display its primary address.
 7. **Secondary DNS Address:** display the secondary address.
- Wireless LAN:** select wireless LAN to realize WIFI function.
- Step 1: click "Network Service" to enter.
 - Step 2: select "Data Accounts".
 - Step 3: select "Wireless LAN".
 - Step 4: select "Start Wireless LAN".
 - Step 5: select "Search Network".
 - Step 6: select one of the website you have searched with peak signal (such as BUFFALO).
 - Step 7: select the corresponding entry point of router.
 - Step 8: enter "Settings of Entry Point", select the sixth item "WEP Key Setting".
 - Step 9: select "WEP Key Mode: change to "128 bits".
 - Step 10: select "WEP Key Mode: change to "ASCII".
 - Step 11: input password (leave a blank if no password in the router).
 - Step 12: click "Complete".
- Step 9: select "Connection" this menu, and then enter "WAP Settings/Profile/SIM 1/Create". Change the data accounts into wireless LAN and finish.
- Step 11: Activate this newly set network settings.
- Step 12: Input address, then you can surf the internet.

3.28.4 Connection Management

You can view the connecting status through this menu.

3.29 Unit Conversion

The function of unit conversion is provided for you by your phone. It is convenient to convert, including weight unit and length unit.

Weight: conversion of weight unit includes Kilogram to Pound and Kilogram to Ounce. Input the corresponding figures to "Edit Box", and then press the left soft key to confirm, you will get the answer you need in another "Edit Box".

Box".

Length: conversion of length unit includes Kilometer to Mile, Meter to Yard, and Meter to Foot, Centimeter to Inch. Input the corresponding figures to "Edit Box", and then press the left soft key to confirm, you will get the answer you need in another "Edit Box".

3.30 Currency Calculator

You are required to input exchange rate and then input monetary value of your country. Press the left soft key to confirm, you will get the answer you need in another "Edit Box".

3.31 Voice Mailbox

The voice messages you received have been saved in the network. You must call the mailbox to listen to the message left.

Call the Voice Mailbox:

call the number you set for your voice mailbox to listen to the message left.

Edit:

you can add/edit the number of the voice mailbox, so it is easier and faster for you to use this function.

3.32 FM Sound Recording

Sound recording is set related param.

Enable/Disable:

select Enable, it begins to record the sound when it is the time.

Time:

set the period of time to record.

Repeat:

select the frequency of regular recording. Once, Daily, Self-style, Weekly, Monthly.

Channel Settings:

includes two menus: "Channel List" and "Manual Input".

Channel List:

in the channel list of FM, press "Select" to choose current channel.

Manual Input:

you can input the channel of FM you like.

Record Settings:

set the related param of recording. You can set the following items: Recording Format, Quality of Sound, Memory Storage, Storage location.

3.33 SMS/SCB

Receive Mode: select "Enable", then you enter "receive Mode", while select "Disable" to reject the message from SMS/SCB.

Read:

enter this menu to read the message you have subscribed.

Channel Settings:

set the channel of SMS/SCB.

Note:

the service of SMS/SCB and voice mailbox is provided by the provider. Please contact your provider.

3.34 Video Recorder

Your phone is provided with the function of recording animation. Memory.

Enter:

select the menu "Camera" to enter and press the red button in the middle start recording.

Note:

the brightness of recording can be adjusted by the keys on the left and right.

Select Options to Enter:

Video Recorder Settings: select this menu to set the related the param of camera.

required to download files by USB cable and save it to the folder named "E-book". If there is no such a folder, you must create one named "E-book".

- **E-book:** you can read the content in e-book.
- **System Settings:** you can set page display of the e-book (font, page curl, automatic page curl, speed of page curl, full-screen, and so on)
- **Information:** view the current detailed information in e-book.
- **Refresh:** delete the current e-book.
- **Delete All Files:** delete all the items in the list of e-book.
- **Type of Sorting:** sort the list of e-book, (according to name, type, time, size or no sorting)
- **Operating System Settings:** restore previous settings to default.
- **Help:** prompt help information

Note: enter the list of e-book, you can use point-touch pen to click the soft keypad to set.

3.40 Bluetooth

- **Activate Bluetooth:** Activate or deactivate Bluetooth function by this switch.
- **Search:** Search for nearby Bluetooth devices. (Generally, the default password of Bluetooth headset is 0000. See user manual for Bluetooth headset for details.)
- **Remote Control:** Remote Control function can be realized.
- **My Device:** You can search for the nearby Bluetooth device automatically by searching for name of your device name will be shown on the screen. You can set matching following the prompt.
- **Connecting Device:** Menu setting after connecting the Bluetooth headset.
- **Setting:**
 - **Allow To Be Searched:** If this function is opened, other Bluetooth devices can find this phone, otherwise, it can't be searched.
 - **Device Name of This Unit:** You can set this device name all by yourself.
 - **Authentication Requirement:** If this function is opened, the unit will be prompted to enter Bluetooth password when it is searched, otherwise, there is no prompt when it is searched.
 - **Set Voice Pair:**
 - **Only in Phone:** If you select this function, you can only use phone to call but can't use Bluetooth headset to call.
 - **Directed to Hands-free Device:** If you select this function, you can only use Bluetooth headset in call but can't use phone.

Video Settings: set the following related param: Quality of Video, Limit of File Size, Record Effect and Time of Record.

- **Camera:** you can select camera 1 or camera 2.
- **Effect Settings:** you could choose an effect for this record.
- **Storage Location:** select to store in phone or memory card.
- **Restore Default:** restore all the settings to factory settings.

3.35 Answering Machine stores all the message of received calls.

1. **Message:** you can view/play this message. If there is any new message, press one short-cut key (OK in general) to view in the standby interface.
2. **Settings:** enable or disable the answering machine.

Enable/Disable: select to enable and disable the answering machine.

Storage Location: select phone or memory card.

Time of Answering: it is the time to enter message mode after the time you set is over.

Recording Time: set the time of recording.

Welcome Note: you can select your favorite welcome note and also you can select it from phone or memory card.

Repeat Answer: select Enable/Disable to enable it.

Repeat: You can realize the function of A-B repeat for the stereo files. Enter and select one file, select the options "Select" in the main interface press the button of "Play" in the main interface of the number from 0 to 9 to begin to playing could be cut to several sections. When recording, you can enable the function of repeat by and click again to time. After recording, you can enable the function of repeat by clicking "Setting" and then clicking one point of the section you set when you are recording.

Logo Settings: set the style of repeat.

Left and Right Arrow: switch front 0 to 9.

Plus and Minus Signs: modify the volume.

3.37 Recorder

Select this function to record.

New Record: record a new stretch of voice.

Play: play the current selected record.

Also, it could rename, delete, use and send the recorded files.

3.38 Slide

The files of photos or images could be stored in the folders of the phone or T-flash card and also can be played by slide show.

Explanation:

- **Play:** play the images in the selected folder.
- **Settings:** you can set the play mode, speed, special effects, background effects, level play and so on.

3.39 E-book

The storage location of e-book files is memory card. You are

Blocked Device: Display the blocked device.
Storage Location: You can select Phone, Memory card or Always Ask.

File Transfer Setting:
File On: Directory Authority: Set the transfer authority.
(1) Storage Folder: Select the path of shared folder.
My Bluetooth: Display the related information of Bluetooth.

3.41 TV
The built-in handheld video broadcast receiver can receive television broadcasts, providing function of receiving TV programs. Select Mobile TV in playing interface, you can click the corresponding button icon to adjust volume, video brightness and other operations according to your need. You can also do the following settings:

- My Channel:** Add the favorite TV channel to my channel list; you can play, rename, delete or do other operations to this channel.
- Channel Search:** Search channel automatically.
- Regional Setting:** Select the local position.
- Add to My Channel:** Add the selected channel to my channel list.

Attention: The video effect received by mobile TV depends on the TV signal coverage of your location to a certain extent.

3.42 New Contact
You can use this function to add the contact person to the contact easily and quickly without opening the contact menu.

Tip: This unit can store 800 phone numbers.

Use the touch pen to click New Contact in the main interface, then select the storage. You can choose To SIM 1 or To SIM 2, there will be a "Save" dialog box after you finish editing the name and number. Select "Yes" to save, select "No" if you after phone can save additional information such as home phone, company name, address, company phone, fax number, call prompting photo, call prompting.

3.43 Internet
Your mobile phone supports WAP service. You can visit the service supported by your network provider. This function can get you information such as news, weather forecast and flight schedule.

Tip: GPRS service should be supported by network; you must subscribe GPRS service and stay in coverage of GPRS network to use the service.

Home: Loud home page. Home, network to use the service. In the connection setting you start, it will be the site preset by you.

Bookmark: Display all the existing bookmarks. You can select connecting to website of this bookmark directly.

Page History: This item records websites you browsed.

Saved Page: This item records websites you saved.

Input URL: Select this item; you can enter my WAP or other sites.
Services: Save messages sent by service provider.
Settings: Set for online browsing. Such as Set My SIM Card, Set File, Browser Option, Service Information, Service Empty Cache, Empty Personal Information and Trust certification.

3.44 Stopwatch
To realize the function of stopwatch.

General Stopwatch:
General stopwatch has two types of separate timer and circle timer. Click left arrow to reset it and right arrow to separately timer. Separate timer can't clear the time record automatically. If it had a record, it will reset record for less than 20 persons. (Such as a class timer can clear the time record automatically after it is a record. It suits a person (such as professional athlete) to record and each circle result when he circles in long-distance. It records not more than 20 circles.)

Check Record: Check the saved records of separate timing and circle timing.

All-round Stopwatch: All-round stopwatch has four directions; you can click with the direction to record. Tip: The method to reset the stopwatch, I first, suspend the operating stopwatch then click left arrow to reset it.

3.45 Radio
This unit supports receiving FM without inserting headset.

Option: Back Select "option" to enter channel list, manual input, automatic search, setting, reception, addition, file list and other functions.

Channel List: In the FM radio channel list, press "Option" key to edit manual input. You can input up to 9 channels.

Automatic Search and Setting: Select this item to search channel automatically and find the best channel.

Description of small icon:
The First Small Icon: Press this icon to play or suspend FM radio.
The Second Small Icon: Search channel (Press continuously to start or stop search, if search starts, press left or right arrow to search channel automatically. Press left and right arrows, these two icons to search, list and next channel automatically.)
The Fifth Icon: Press this icon to enter menu setting.

Plus or Minus Symbol: Adjust the volume.

Setting: Do setting for the FM radio.

1. **Background play:** Select ON/OFF. If you enable this function, the FM radio will continue playing when the menu exits.
2. **Mobile Phone Loudspeaker:** FM radio can sound by the loudspeaker. If you start this item, press the key in the FM radio interface to enter the corresponding channel.
3. **Record Format:** You can select the record formats of AMR, WAV or AWB.
4. **Sound Quality:** Select high or low.
5. **Storage Location:** Select storage location of mobile phone or memory card.

Record: Press OK key to start the record function, you can record the current program and save the record file to Audio files.

Addition: Add an additional record to the saved record.
File List: For saved recorded FM radio list, you can press "Option" key to do the operations of play, use as, send, detail information, rename, delete, all, save mode and so on.

3.46 Alarm Check

This unit can set 5 alarm checks. You can edit and set any one of them after selecting it.

3.47 Phone Book

You can use Contact to save some important persons' information such as name, mobile phone, home phone, company phone and so on. Select Contact from Menu.

Tip: This mobile phone can save 800 phone numbers.

In the contact, there are options of fast search, name search, add numbers, copy all, delete, groups of accepted calls, other numbers, setting, call prompting photo, call prompting music, call prompting movie and so on.

Fast Search: Select this item to enter the contact browsing interface, there is a search method where you can input the corresponding information to filter the call records. Optional search methods: 1. English, 2. Number.

Name Search: Search records in the contact by searching name.

Add Contact: You can add a new phone record to the contact and select saving it to SIM card or phone. SIM card and phone memory have some differences in file format.

Copy All: You can copy all the contacts between phone and SIM card or between card 1 and card 2.

Delete: Select this item to delete the phone contacts. You can delete all the phone contacts from SIM card or from phone or delete them one by one. (Tip: When deleting the call records of SIM 1, SIM 2 and phone, you should enter password, the default password is 1122.)

Accepted Call Go: You can change name, ringing tone, call prompting picture, call prompting animation and personalized settings for group members.

Other Numbers: You can check and edit other numbers saved in the SIM card (My number/ Service number/ Emergency number).

Contact Setting: The setting function of contact has 5 menus: storage state, the card storage location, column, my business card and business card.

Storage State: Storage state of phone record in SIM card and phone.

Preferred Storage Location: Select the preferred storage location from phone, card 1 and card 2.

Column: Set the content recorded in the phone contact (8 settings as home number, company name, email and so on.)

My Business Card: You can add your business card and send it by SMS, MMS or Bluetooth and also you can refer to the document.

Business Card Version: You can choose business card of version 2.1 or version 3.0.

Call Prompting music: You can choose music for call prompting.

3.48 Opera

Use the LAN, you can search for JAVA games available for downloading and log in to the Internet. In this function, please pay attention to synchronizing phone time and actual time. You can refer to "Time and Date" in "3.14.5 Phone Setting" for specific operation.

3.49 Music

There are two icons on the top of music player screen: The left is function of file list, the right is Music List. Below the list, you can select "Option" to do the operations of play, Check Detail, Add Ring Library, Update Play List, Setting and so on.

Now Interpretation: Play the current selected music.

Detail Information: Check the detail information of this music.

Ring Library: Add the current music to the ring library of profile.

Update Play List: Update the music in ring library.

Tip: The model supporting touch screen function can realize the following functions:

Touch Key: You can use the scroll bar at the bottom to turn up and turn down the music volume.

Music Play: Press this icon to enable, disable and suspend the music playing.

Next Music: Press these two icons to switch to the last or the next music.

Setting: Set the multimedia playing.

Playing Setting: Set the phone memory or memory card.

Automatically Play: Start or stop music automatically or deactivate.

Repeat: Start this item to repeat play music.

Random: Start this item to play in random.

Background Play: If you start this item, the music won't stop when the menu exits.

Panel Setting: Start this item to display lyrics when Lyrics Display, playing MP3.

3. Audio Effect Setting: enable or disable audio effect.

4. Bluetooth Setting:
Bluetooth Stereo Output: enable or disable it.
Bluetooth Stereo Headset: Start the Bluetooth Stereo Output and connect the Bluetooth headset after the Bluetooth device is turned on. Then you can listen to the music through the headset.

Tip: The default corresponding file name of music player is My music (phone and memory card).

4 Input Method Description

This unit supports Simplified Chinese input method, the input methods provided for you are: English input (upper and lower cases), figure input, Pinyin input, Punctuation (common symbol).

In the mobile phone, the function items allowing Chinese character input are:

- Input, edit short message
- Input, edit contact name
- Select phone number and name
- Customize greeting and owner name
- Name the record in toolbox and so on.

4.1 Input Method Description

The general operation sequence of input method:

Select and Confirm Pinyin: Touch screen to choose the letters, use the touch pen to click "X" (at the top right of the enter key) to clear the list and return to the main screen.

Select and Confirm Input Character: Touch left or right arrow to search the character and turn over the screen, press left soft key to select the character.

Select Associated Character: Association input method can give a word phrase; you can touch the screen to select the word phrase you want, then press soft key to confirm it.

Touch and Confirm Input Character: Touch to move cursor to click "X" (at the top right of the enter key) to clear character.

Input Symbol: Click the leftmost icon to input symbol, you can also click the option item to enter symbol interface.

4.2 Handwriting Input

This function is used in the item allowing character input; you can use the touch pen to write characters on the phone prompt. Click the center of screen to clear the character. ABC means capital letter input method, abc means lowercase input method, 123 means figure input method. You can use the touch pen to touch the Clear on the screen to clear the error input. This unit supports continuous strokes input.

5 T-Flash Card Introduction

This unit supports T-Flash memory card to external storage space. Specific operation is as follows:

5.1 Installation and Uninstallation of T-Flash Card

The port for T-Flash card is at the top of battery on the phone back. You can insert T-Flash card according to the marks.

Tip: This unit supports Plug and Play but in power-on state, in order to ensure the normal use of playing information, restarting the phone manually is recommended when you insert or take out the T-Flash card.

Generally, installation and uninstallation of T-Flash card is only allowable when necessary.

5.2 Use of T-Flash card

As one of phone's external storage space, T-Flash card is set as default memory in factory, you can use it directly without any setting. When you use the T-Flash card as phone memory. The first time you input the T-Flash card, you should set the default memory of music player, video player, the recorder, camera and sound recorder as memory card, then you can use the storage space and content of T-Flash card. (The corresponding setting method is mentioned in the above manual.) With USB line, it can copy the computer data directly. For specific use method, you can refer the use of U-disk.

6 Troubleshooting

If the phone has abnormal situation, please read it according to the following table.

Frequent Problem	Cause	Solution
	When using this phone in the area of high building such as high building or basement, the radio wave can't reach effectively.	Try to avoid it.
Bad reception	Use phone in period of intensive call, such as at the working station, congestion will make you fail to call.	Try to avoid it.
	Relate with the distance of network station.	Ask your network service provider to provide service area chart.
Echo or noise	Caused by bad network link, regional problem. Connection is bad in some area.	Hang up and redial the phone in another place better connection.
Standby time is shorter.	Standby time has something to do with the system setting of network. Need to change battery. If it can't get the signal, the phone will shut down.	Please temporarily turn off your phone in a power-off area. Change new battery. Please use phone in

4. Bluetooth Setting:

Bluetooth Stereo Output: enable or disable it.

Bluetooth Stereo Headset: Start the Bluetooth Stereo Output and connect the Bluetooth headset after the Bluetooth device is turned on. Then you can listen to the music through the headset.

Tip: The default corresponding file name of music player is My music (phone and memory card).

4 Input Method Description

This unit supports Simplified Chinese input method, the input methods provided for you are: English input (upper and lower cases), figure input, Pinyin input, Punctuation (common symbol).

In the mobile phone, the function items allowing Chinese character input are:

- Input, edit short message
- Input, edit contact name
- Select phone number and name
- Customize greeting and owner name
- Name the record in toolbox and so on.

4.1 Input Method Description

The general operation sequence of input method:

Select and Confirm Pinyin: Touch screen to choose the letters, use the touch pen to click "X" (at the top right of the enter key) to clear the list and return to the main screen.

Select and Confirm Input Character: Touch left or right arrow to search the character and turn over the screen, press left soft key to select the character.

Select Associated Character: Association input method can give a word phrase; you can touch the screen to select the word phrase you want, then press soft key to confirm it.

Touch and Confirm Input Character: Touch to move cursor to click "X" (at the top right of the enter key) to clear character.

Input Symbol: Click the leftmost icon to input symbol, you can also click the option item to enter symbol interface.

4.2 Handwriting Input

This function is used in the item allowing character input; you can use the touch pen to write characters on the phone prompt. Click the center of screen to clear the character. ABC means capital letter input method, abc means lowercase input method, 123 means figure input method. You can use the touch pen to touch the Clear on the screen to clear the error input. This unit supports continuous strokes input.

5 T-Flash Card Introduction

This unit supports T-Flash memory card to external storage space. Specific operation is as follows:

5.1 Installation and Uninstallation of T-Flash Card

The port for T-Flash card is at the top of battery on the phone back. You can insert T-Flash card according to the marks.

phone will continuously to search for power and cause the standby time become shorter.	The power of battery runs out.	Check the battery power or charge it.	area of strong signal or turn off phone for a while.
Fail to start	SIM card is damaged.	Contact with your network service provider.	
SIM card error	SIM card is not installed.	Ensure SIM card is installed.	
Unable to connect network	There is dirt on the metal surface of SIM card.	Wipe the metal contact point of SIM card with clean cloth.	
	SIM card is invalid.	Contact your network service provider.	
	Beyond the GSM service area.	Check service area with network service provider.	
	Signal is weak.	Retry in area with stronger signal.	
Fail to call.	Use call limited function.	Cancel setting of call limited function.	
PIN error	Input wrong PIN number continuously for three times.	Cancel setting of fixed dial function.	
Fail to charge battery.	The battery or charger is damaged.	Contact your network service provider.	
	Charge temperature lower than -10°C or higher than 55°C.	Check the battery power or charge it.	
	Poor contact.	Change to proper charging environment.	
Fail to add new entry in phone book.	The storage space of contact is full.	Check whether the plug has good contact.	
Fail to set some functions.	The network provider doesn't support this function or you didn't apply this function.	Delete part of phone records.	Contact with your network service provider.