

**Contents**

<b>1. Basic Information</b> .....	4
1.1 Introduction .....	4
1.2 Safety notice .....	4
1.3 Safety warning and precautions .....	4
1.3.1 General precautions .....	4
1.3.2 Precautions of using mobile phone .....	4
1.3.3 Precautions of using battery .....	4
1.3.4 Precautions of using charger .....	5
1.3.5 Cleaning and maintenance .....	6
1.3.6 Common precautions .....	6
2. Before using .....	7
2.1 Parts and functions .....	7
2.1.1 Icon .....	8
2.2 Key description .....	8
2.3 Introduction of touch screen .....	8
2.4 Battery .....	9
2.5 Charging the battery .....	9
2.6 Connecting to the network .....	9
2.6.1 SIM card .....	10
2.6.2 Insert and remove the SIM card .....	10
2.6.3 Switch on/off .....	10
2.6.4 Unlocking SIM card .....	11
2.6.5 Unlocking the phone .....	11
2.6.6 Connecting to the network .....	11
2.6.7 Making a call .....	11
2.6.8 Making a DDD .....	12
2.6.9 Calling extension of fixed telephone .....	12
2.6.10 Making an IDD .....	12
2.6.11 Calling the number in the list .....	12
2.6.12 Emergency call .....	13
2.6.13 Answering a call .....	13
2.6.14 Call log .....	13
2.6.15 Call menu .....	13
<b>3. Function Menu</b> .....	13
3.1 Using function menu .....	14
Scroll to search and select .....	14
Exit .....	14
3.2 Structure menu of function menu .....	14
Exit .....	14
Exit .....	14

General.....	34
Meeting.....	34
Outdoor.....	35
Indoor.....	35
Headset.....	35
3.27 World Clock.....	35
3.28 Network Service.....	35
3.28.1 SIP Services.....	35
3.28.2 Wi-Fi.....	35
3.28.3 Data Accounts.....	36
3.28.4 Connection Management.....	37
3.29 Unit Converter.....	37
3.30 Currency Calculator.....	37
3.31 Voice Mailbox.....	37
3.32 FM Sound Recording.....	37
3.33 SMSCB.....	38
3.34 Video Recorder.....	38
3.35 Answering Machine.....	38
3.36 Repeater.....	38
3.37 Recorder.....	38
3.38 Slide.....	39
3.39 E-book.....	40
3.40 Bluetooth.....	40
3.41 TV.....	40
3.42 New Contact.....	41
3.43 Internet.....	41
3.44 Stopwatch.....	42
3.45 Radio.....	42
3.46 Alarm Clock.....	43
3.47 Phone Book.....	43
3.48 Opera.....	44
3.49 Music.....	44
4 Input Method Description.....	44
4.1 Input Method Description.....	44
4.2 Handwriting Input.....	44
5 Flash Card Introduction.....	45
5.1 Installation and Uninstallation of Flash Card.....	45
5.2 Use of Flash card.....	46
6 Troubleshooting.....	46

3.3 Message.....	19
3.3.1 New message.....	19
3.3.2 Create message.....	20
3.3.3 View received and saved SMS.....	20
3.3.4 Template.....	21
3.3.5 SMS setting.....	21
3.4 Calendar.....	22
3.5 Album.....	22
3.6 Camera.....	23
3.7 Cinema.....	23
3.8 Memo.....	24
3.9 E-mail.....	24
3.10 Create message.....	25
3.11 Calculator.....	25
3.12 eBuddy.....	25
3.13 Map.....	25
3.14 Settings.....	25
3.14.1 Mode setting.....	25
3.14.2 Coordinate.....	25
3.14.3 Acceleration sensor calibration.....	26
3.14.4 Acceleration sensor settings.....	26
3.14.5 Phone settings.....	26
3.14.6 Network settings.....	29
3.14.7 Security Settings.....	29
3.14.8 Restore Factory Settings.....	29
3.14.9 Sound Effects.....	29
3.15 Call History.....	29
3.16 Wallpaper.....	29
3.17 Wireless Network.....	30
3.18 Java Entertainment.....	31
3.19 MMS.....	31
3.20 Chatting.....	31
3.21 Games.....	32
3.22 Dynamic Game.....	32
A game named "Dynamic Dice" is provided.....	32
3.23 Fast Search.....	32
3.24 Call Center.....	32
3.24.1 Call History.....	33
3.24.2 Call Settings.....	34
3.25 File Management.....	34
3.26 Profile.....	34



other magnetic objects. The radiative wave of the mobile phone may erase the information saved in floppy disk, prepaid card and credit card.

Put the drawing pins and other small metal objects away from the headphone of the mobile phone. The loudspeaker is magnetic during working and will magnetize these small metal objects; it may hurt human body or damage the mobile phone.

Do not make the mobile phone mistreated; it may cause overheat, electricity leakage and fault. If water or other liquids enter the mobile phone.

### 1.3.3 Precautions of using battery

- Do not put the battery in fire; otherwise it may cause fire and explosion.
- Do not push by force when installing battery, otherwise it may cause liquid leakage, overheating.
- Do not use electric wires, needle or other metal objects to short circuit the battery, and also do not put the battery together with necklace and other metal objects, otherwise it may cause liquid leakage, overheating, explosion and fire.
- Do not weld the battery, otherwise it may cause liquid leakage, overheat, explosion and fire.
- It may cause blindness if the battery liquid comes into eyes. Do not knead your eyes at this moment. Please use clean water to clean and go to see your doctor immediately.
- Do not disassemble or refill the battery, otherwise it may cause liquid leakage, overheating, explosion and fire.
- Do not use or put the battery in places with heat or other places with high temperature, otherwise it may cause liquid leakage, overheating, explosion and fire.
- If the battery has temperature rising, discoloration, distortion or other abnormal phenomenon in the process of using, charging or storage, please stop using the battery and change a new one.
- It may burn your skin if the battery liquid contacts your skin or clothes. Please use clean water to clean and go to see your doctor immediately.
- If there is liquid leakage or abnormal smell from the battery, please take it away from fire to avoid from fire and explosion.
- Do not make the battery mistreated; otherwise it may cause overheating, smoking and erosion of the battery.
- Do not use or put the battery at places where it is irradiated by sunshine directly or near car, otherwise it may cause liquid leakage and overheating, and decrease its performance and shorten its service life.
- Do not charge continuously for more than 24 hours.

Please use 217V AC power supply. It may cause electricity

leakage, fire and damage the mobile phone and charger if you use other mobile phone.

Charger short circuit is prohibited, otherwise it may cause electric shock, smoking and damage the charger.

Do not use the charger if the power cord is damaged, otherwise it may cause fire and electric shock.

Do not clean the dust on the outlet in time.

- Do not touch the charger besides the charger to avoid overheating, electricity leakage and fault of the charger caused by splashed water.
- If the charger contacts water or other liquids, please cut off the power supply immediately to avoid overheating, fire, electric shock and charger fault.
- Do not disassemble or refill the charger, otherwise it may cause body hurt electric shock, fire and damage the charger.
- Do not use the charger in bathroom or places with high humidity, otherwise it may cause electric shock, fire and damage the charger.
- Do not touch the charger, power cord and outlet with wet hands, otherwise it may cause electric shock.
- Do not put the charger on the power cord or refill the power cord, otherwise it may cause electric shock and fire.
- Please pull out the plug from outlet before cleaning and maintenance.
- Please hold the charger when pulling out the plug and it may cause electric shock and fire if you pull the power cord.

### 1.3.5 Cleaning and maintenance

- The mobile phone, battery and charger are not waterproof. Do not use them in bathroom or other places with high humidity and also avoid being drenched with rain.
- Use soft cloth to clean the mobile phone, battery and charger.
- Do not use alcohol, diluents or benzene solution to clean the mobile phone.
- Out let with dirt may cause bad contact and power off, and can't charge thereby. Please clean regularly.

### 1.3.6 Common precautions

- Mobile phone:
  - Please use this mobile phone in the environment with temperature between 5°C and 40°C, humidity between 35% and 85%, and lower than 1700m.
  - Try to use this mobile phone in places away from normal telephone, TV set, radio and OA equipment to avoid affecting the performance of these devices and mobile phone.

### Battery:

- Put the battery at places with good ventilation and no direct sunshine irradiation in temperature between 5°C-40°C.

- The service life of mobile phone battery is limited. The using time of battery will be shortened gradually after frequent charging. If the charging is invalid for several times, it indicates that the service life of the battery has reached its end and you need to change a new battery of appointed model.
- Do not drop used battery into common domestic refuse. Please follow local regulations if the disposal of used battery is stipulated clearly.

#### Charger:

- Do not charge at the following places: with direct sunshine irradiation; environment temperature is lower than 5°C, or higher than 40°C; With moisture; too much dust or vibration (may cause fault); near TV set, radio or other electric apparatus (may affect video and audio quality).
- Before using

#### 2.1 Parts and functions

The icons that may be displayed in standby interface and their meanings are as follow:

Icons	Description
	Indicate the intensity of network signal.
	You can use GPRS service.
	Vibrator is activated.
	New SMS.
	New MMS.
	Alarm clock is set and activated.
	Display when earphone is inserted.
	Enable call diverting function.
	Keypad unlocked.
	Indicate battery status.
	Display missed calls.
	Enable chat function.

	Enable common stopwatch.
	New service message.
	Bluetooth earphone is activated.
	Bluetooth earphone matched.

#### 2.2 Key description

**Power key:**  
In the top of the mobile phone; press this key to lock or unlock the keypad; press and hold this key to switch on/off the mobile phone.

1. End key: End a call or reject an incoming call; press this key (center) to return to standby in other conditions.

3. Dial key:  
\* key: press and hold this key in dialing interface to switch among +, P and W.  
# key: press this key in dialing interface to input #; press and hold this key to switch between silent and general profiles.

Dial key 2: call the number stored in the SIM.

The key on the left of Dial key 1: press to access Contacts

The key on the right of Dial key 2: clear the character before the cursor

**The last row of small icons in the dialing interface have the following functions from left to right:**

First (pentagram): Call center (Log and Call settings)

Second: Contacts list

Third: Return to standby

Fourth: Shortcut menu of Contacts

**2.3 Introduction of touch screen**

1. This mobile phone supports touch screen function.

2. You can also click the icon on the touch screen to access the menu directly.

3. If you click and hold the menu icon in standby interface, all the icons will shake. It is mainly to avoid entering the menu by mistake. In this case, you can click the icons to different positions, but can't enter the menu. Click the center key to stop the shaking, and then you can enter the menus.

**2.4 Battery**

The battery in original state has about 50% electricity quantity and you can use it after unpacking. It performs best after full charge/discharge for the first three times.

To remove the battery: ① Push the back cover upside; ② Lift the

battery on the downwards and remove it.  
To insert the battery, ① insert the battery in the bottom, ② put on the mobile phone battery.

#### 2.5 Charging the battery

Connect the power supply of the charger.  
Insert the plug of the charger into the bottom of mobile phone (keep the surface with arrow upwards).  
The battery status indicator on the screen will be flashing steadily; if the mobile phone is powered off when being charged, a battery status indicator image will appear on the screen which indicates the battery is being charged. If the mobile phone is still used when battery is low, the charging indicator appears after the charging has started for a while.  
If the battery status indicator on upper right corner of the screen is flashing and won't finish, the charging is finished. If the battery status indicator image which indicates that charging is finished is displayed on the screen, this course may cost 3-4 hours. It is normal that the battery, mobile phone and charger get warm in charging process.  
Disconnect the AC outlet from mobile phone and charger when the charging is finished.  
Note:  
Use charger approved by manufacturer to charge at ventilated places with temperature below 40°C and 40°C. It may bring danger if you use unauthorized charger and you also violate the warranty clause.  
Please charge the battery in time if the mobile phone is powered off automatically or indicates "Low battery". If the charging hasn't been finished before charging, the charging time will be shortened.  
The standby and talk time provided by manufacturer are based on ideal working environment. The charging time of battery depends on network status, environment and operating mode.  
Make sure the battery is installed properly before charging and you connect the charger from mobile phone and power supply after charging.  
If you don't disconnect the charger from power supply and mobile phone, the mobile phone will be charged again after a long time (about 10-15 hours) and the energy of the battery is reduced to a certain degree, which will shorten the battery life.

#### 2.6 Connecting to the network

You must insert a valid SIM card before using your mobile phone. SIM card is the key for you to access digital GSM network.  
All information, numbers and short messages you have received and sent by SIM card phone book will be stored in the metal surface area of the SIM card. You can remove the SIM card from your mobile phone and insert it into any other GSM mobile phone (the new mobile phone will read the SIM card automatically).

#### 2.6.1 SIM card

You must insert a valid SIM card before using your mobile phone. SIM card is the key for you to access digital GSM network.  
All information, numbers and short messages you have received and sent by SIM card phone book will be stored in the metal surface area of the SIM card. You can remove the SIM card from your mobile phone and insert it into any other GSM mobile phone (the new mobile phone will read the SIM card automatically).

Do not touch the metal surface area and keep the SIM card away from electricity and magnetism to avoid losing the information saved in SIM card.  
You can't access GSM network if the SIM card is damaged.  
Warning: Please switch off the mobile phone before removing SIM card, otherwise the SIM card with external power supply is prohibited.  
2.6.2 Insert and remove the SIM card  
The SIM card is usually stored in a card and you need to take it out carefully before installing.

Turn off the mobile phone and remove battery and external power supply.  
The mobile phone supports dual-card mode. Looking at the rear side slot (Refer to mobile phone).

Please turn off the mobile phone and remove the battery before removing the SIM card.

2.6.3 Switch on/off  
Long press the power key to switch on the mobile phone; to switch off the phone, also press this power key.

If you switch on the mobile phone before inserting the SIM card, it will prompt valid automatically after it is inserted.  
The mobile phone checks whether the SIM card is valid. If the following prompts appear on the screen in sequence:  
Input Phone Number - If the password of the phone has been set.  
Searching - The mobile phone is searching for available network.

2.6.4 Unlocking SIM card  
By setting PIN1 (personal identification number) code of the SIM card, you can protect your SIM card from illegal operation. If this function is enabled, you can unlock the SIM card and make or answer a call. Users can use the code (refer to "Security settings" in Chapter 3.14.7). In this condition, the SIM card cannot be protected from illegal operation.

Long press End Key to activate the phone;  
Input PIN1 code, click the Clear key, four characters and click OK to finish. For example, if the PIN1 is 1234, you can input 1234.

If you input invalid password for three times continuously, the SIM card will be locked and you need to input the code. Contact your network operator if you don't know PUK1 code. Refer to Chapter 3.14.7 "Security settings" for details.  
Note: Your network service provider will set a standard PIN1 code (4-8 digits) for your SIM card. Please change it with your personal password as soon as possible. Refer to Chapter 3.14.7 "Security settings" for details.

2.6.5 Unlocking the phone  
Phone lock - When you insert your mobile phone from illegal operation, you need to input the phone password when the PIN1 code (when PIN1 code is enabled) is input every time you switch on the mobile phone. If this function is enabled, when you can unlock the phone and make or answer a call. Users can clear the code (refer to Chapter 3.14.7 "Security settings"). In this condition, the mobile

phone cannot be protected from illegal operations.  
■ Enter mobile phone password, press the Right soft key to clear wrong password. For example, if the mobile phone password is 1122, you can enter 1122.

If you have forgotten your mobile phone password, please contact your distributor or local authorized service center to unlock your mobile phone.

**2.6.6 Connecting to the network**  
■ When you start the mobile phone scans available network automatically. Once connected, the name of the network operator displays in the top of the standby interface. When you click the blank area, the information box of the network operator appears; click again and the box disappears.

Note: If there is prompt of "EMERGENCY" on the screen, it means that you are making an emergency call according to the signal intensity.

**2.6.7 Making a call**  
When the symbol of the network operator appears on the screen, you can make or answer a call. The information bar in upper left corner of the screen displays the intensity of network's signal. The call duration can be affected by barriers, may be improved from receiving within a small range.

**2.6.8 Making a DDD**  
Enter telephone number with Number keys. Then, press Dial key to make a call. Click "Clear" to clear the characters you enter. If you need to change the telephone number, the dialing image will be displayed on the screen. The call duration will be also a warning time if you have opened (need network support). Press End key to end the conversation.

Area code Telephone number Call key

**2.6.9 Calling extension of fixed telephones**  
Some types of fixed telephones can't be dialed through directly and you need to dial through the exchange before dialing the extension. If you insert the pause symbol P between the exchange number and the extension number when you input the phone number, the mobile phone will complete the dialing and dial extension automatically. Long press \* to enter "P" (the symbol P will be displayed on the screen).

Area code Exchange number P Extension number Call key

Example of using pause symbol:  
For example: If you have a voice mail system in the number 8880000 with mail number is 6666 and password is 8888, you can dial like this:  
8880000\*6666\*8888#  
The first part of the number is used to dial the voice mail system.  
When the call is answered, it will dial 6666 to choose mailbox.

Before dialing the password 8888, there is a 5-second delay at the second pause symbol (the first P means to wait for the connection and other following Ps mean 5-second delay).

**2.6.10 Making an IDD**  
If you need to make an international call, press and hold \* key until the prefix symbol "+", of international long distance call appears on the screen, and you can make a call in any country when you don't know the local prefix number of the country you want to call. You need to input the country code and full phone number. The country codes are according to the international tradition, and Germany is 49, UK 44, Sweden 46, etc.

You need to delete the 0 in the front of the area code as dialing international call. For example: if you want to call the service hotline from other countries, you dial +86 21 114.

+ Country code Complete telephone number Call key

**2.6.11 Calling the number in the list**  
All the numbers you have dialed and received are saved in the mobile phone. The numbers are listed on the top (refer to Chapter 3.24 "Call log"). The numbers are classified into missed calls, answered calls and dialed numbers. You can press Call key in standby interface to view Call log. When the list is full, old numbers will be deleted automatically. To view the list, operate as follow:

■ You can click the Options menu to perform operations on all the numbers in the list.  
When the numbers list appears, you can press OK to view details. Enter the option and press "Save" to save the number into Contacts.

**2.6.12 Emergency call**  
As long as the network service is available, which can be checked via viewing the signal strength bar at the bottom, left corner of the screen, you can make an emergency call. The characters of "EMERGENCY" will appear on the screen and you could only make emergency call. If you are in a service area of the network, emergency calls can also be made without a SIM card.

**2.6.13 Answering a call**  
Press the Dial key to answer, or press the key on the earpiece. If an earpiece is inserted, you can press the key to answer, and the call will be answered automatically 5 seconds after the ring or vibration.

**2.6.14 Call log**  
The log of last call and the time of all calls are saved in the mobile phone (refer to Chapter 3.24 "Call log").

**2.6.15 Call menu**  
In the standby interface, Hands-free to enter hands-free function, and press Option to enter call options.  
This menu is available only in call process, while call waiting, call diverting and multi-party conference need network support. Please contact your network

operator for details.

You can perform the following operation in call options:

- Hold the call or resume the held call.
- End single line call.
- End the current call.
- Make a new call.
- Access Contacts.
- Access Call log.
- Message center.
- Create and send a short message.
- Press Left soft key to enable/disable DTMF.
- Activate loudspeaker to enlarge call volume.

### 3. Function Menus

(※ The application of following functions is dependent.)

#### 3.1 Using function menus

Scroll to search and select.

- In all menus and submenus, you can enter or exit the menu by clicking the touch screen and following the prompts on the screen.

#### 3.2 Structure menu of function menus

The default structure of function menus is as follow when SIM card is inserted and the phone is switched on:

1. Message
  - 1-1 Short message
  - 1-2 New message
  - 1-3 Inboxes
  - 1-4 Outbox
  - 1-4 Template
  - 1-1-5 SMS settings
2. Calendar
  - 2-1 View
  - 2-2 View all
  - 2-3 Add event
  - 2-4 Delete event
  - 2-5 Go to date
  - 2-6 Week view
  - 2-7 Print
  - 2-8 Alarm
3. Album
  - 3-1 View

- 3-2 Lantern
- 3-2-1 Play
- 3-2-2 Settings
- 3-3 Auto resizing
  - 3-3-1 Auto resizing
  - 3-3-2 Cutting out main screen
  - 3-3-3 Manual cutting
  - 3-3-4 Help
- 3-4 Print
- 3-5 Browse mode
- 3-6 Wallpaper
  - 3-6-1 Wallpaper
  - 3-6-2 Screen saver
  - 3-6-3 Power on image
  - 3-6-4 Power off image
  - 3-6-5 Caller image
- 3-7 In MMS
  - 3-7-1 In MMS
  - 3-7-2 In e-mail
  - 3-7-3 In Bluetooth
- 3-8 Rename
- 3-9 Delete
  - 3-10 Delete all
  - 3-11 Storage
  - 3-12 Storage position
4. Camera
  - 4-1 Album
  - 4-2 Camera settings
  - 4-3 Lens switch
  - 4-4 Effects
  - 4-5 White balance
  - 4-6 Scene modes
  - 4-7 Special good effect
  - 4-8 Image frame
  - 4-9 Storage position
  - 4-9-1 Reset
5. Camera
  - 5-1 Play
  - 5-2 Send
  - 5-2-1 In e-mail
  - 5-2-2 In Bluetooth
  - 5-3 Rotate
  - 5-4 Delete
  - 5-5 Delete all
  - 5-6 Sort
  - 5-7 Streaming media website
  - 5-8 Network settings
  - 5-9 Storage position
  - 5-9-1 Phone

6. Memo

7. E-mail

- 7-1 Send and receive
- 7-2 Edit e-mail
- 7-3 Inbox
- 7-4 Outbox
- 7-5 Drafts
- 7-6 Clear
- 7-7 Delete marked e-mail
- 7-8 E-mail accounts
- 7-9 Template

8. New message

- 8-1 Send in SIM1
- 8-2 Send in SIM2
- 8-3 Select template
- 8-4 Insert object
- 8-5 Text format
- 8-6 Insert contact number
- 8-7 Insert contact name
- 8-8 Insert bookmark
- 8-9 Input method

9. Calculator

10. Mute

11. Mute

12. Settings

- 12-1 Mode setting
- 12-1-1 Dual card
- 12-1-2 SIM1
- 12-1-3 SIM2
- 12-2 Control
- 12-3 Acceleration sensor calibration
- 12-4 Acceleration sensor settings
- 12-5 Phone settings
- 12-5-1 Time and date
- 12-5-2 Schedule power on/off
- 12-5-3 Language
- 12-5-4 Input method
- 12-5-5 Default input method
- 12-5-6 Coding
- 12-5-7 Standby menu display
- 12-5-8 Greetings
- 12-5-9 Auto update time
- 12-5-10 Printing settings
- 12-5-11 IAPET settings
- 12-5-12 Other settings

12-6 Network settings

12-7 Security settings

- 12-7-1 SIM1 security settings
- 12-7-2 SIM2 security settings
- 12-7-3 Phone lock
- 12-7-4 Keypad lock
- 12-7-5 Changing password
- 12-7-6 Bluetooth tracing
- 12-7-7 Infrared security firewall
- 12-7-8 SMS firewall
- 12-7-9 Remote control
- 12-8 Restore factory settings
- 12-9 Sound effect

13. Call log

14. Wallpaper

15. Wireless network

- 15-1 Disable wireless LAN
- 15-2 Status of wireless network
- 15-3 Access point settings
- 15-4 Scan network

16. JAVA entertainment

16-1 Java

16-2 Java settings

17. Mail

17-1 New message

17-2 Inbox

17-3 Outbox

17-4 Drafts

17-5 Template

17-6 SMS settings

17-6-1 Sending setting

17-6-2 Receiving setting

17-6-3 Resending setting

17-6-4 Filter

17-6-5 Server settings

17-6-6 Memory state

18. Chat

19. Games

19-1 Mahjong

19-2 Jigsaw puzzle

19-3 Magic sashi

19-4 Mahjong

19-5 Mahjong

19-6 Mobile center

19-7 Game search

20. Dynamic games

21. Quick search

21-1 Call

21-2 IP call

5.9-2 Memory card

6. Memo

7. E-mail

- 7-1 Send and receive
- 7-2 Edit e-mail
- 7-3 Inbox
- 7-4 Outbox
- 7-5 Drafts
- 7-6 Clear
- 7-7 Delete marked e-mail
- 7-8 E-mail accounts
- 7-9 Template

8. New message

- 8-1 Send in SIM1
- 8-2 Send in SIM2
- 8-3 Select template
- 8-4 Insert object
- 8-5 Text format
- 8-6 Insert contact number
- 8-7 Insert contact name
- 8-8 Insert bookmark
- 8-9 Input method

9. Calculator

10. Mute

11. Mute

12. Settings

- 12-1 Mode setting
- 12-1-1 Dual card
- 12-1-2 SIM1
- 12-1-3 SIM2
- 12-2 Control
- 12-3 Acceleration sensor calibration
- 12-4 Acceleration sensor settings
- 12-5 Phone settings
- 12-5-1 Time and date
- 12-5-2 Schedule power on/off
- 12-5-3 Language
- 12-5-4 Input method
- 12-5-5 Default input method
- 12-5-6 Coding
- 12-5-7 Standby menu display
- 12-5-8 Greetings
- 12-5-9 Auto update time
- 12-5-10 Printing settings
- 12-5-11 IAPET settings
- 12-5-12 Other settings

12-6 Network settings

- 21-3 Send SMS
- 21-4 Send MMS
- 21-5 View
- 21-6 Draft
- 21-7 Date
- 21-8 Copy
- 21-9 Move
- 21-10 Send contact
- 21-11 Print
- 22. Call center
- 22-1 Call log
- 22-2 Call settings
- 23. File manager
- 23-1 Phone
- 23-2 Memory card
- 24. Profiles
- 24-1 General
- 24-2 Message
- 24-3 Outdoor
- 24-4 Indoor
- 24-5 Earphone
- 24-6 Bluetooth
- 25. World clock
- 26. Converter
- 26-1 STK service (SIM1)\*
- 26-2 STK service (SIM2)\*
- 26-3 WAP\*
- 26-4 Data accounts
- 26-5 Connection management
- 27. Currency converter
- 27-1 Weight
- 27-2 Length
- 28. Currency converter
- 29. Voice mail
- 30. FM recording
- 31. Call recording mode
- 31-2 Read message
- 31-3 Language
- 31-4 Channel settings
- 32. Video recorder
- 32-2 Video recorder settings
- 32-3 Lens switch
- 32-4 Special good effect
- 32-5 Storage position
- 32-6 Reset
- 33. Answering machine
- 33-1 Message

- 33-2 Settings
- 34. Repeater
- 35. Sound recorder
- 35-1 New recording
- 35-2 List
- 35-3 Settings
- 36. Lantern slide
- 37. E-book
- 38. Bluetooth
- 38-1 Activate Bluetooth
- 38-2 Search for hands-free device
- 38-3 Remote control
- 38-4 My Bluetooth
- 38-5 Online device
- 38-6 Settings
- 38-7 My Bluetooth
- 39. TV
- 39-1 My channel
- 39-2 My channel
- 39-3 Channel list
- 39-4 Area settings
- 39-5 Add to my channel
- 40. New contact
- 41. Mobile QQ\*
- 42. Internet\*
- 43. Patch
- 44. Radio
- 44-1 Channels list
- 44-2 Manual input
- 44-3 Auto scan
- 44-4 Settings
- 44-5 Recording
- 44-6 Appendix
- 44-7 Files list
- 45. Alarm clock

Note: The menus with "\*" appear in specific conditions only.

**3.3 Message**  
 Select "SMS" to enter the sub-menu.  
 If the network supports and you have subscribed this service, you can send or receive Chinese and English SMS and MMS through service center.

**3.3.1 New message**  
 When you receive a new message, the mobile phone will vibrate (vibration is set) and display the message content (sound prompt is set) on the screen. If you don't read the message, a prompt of new message will be displayed on home screen and the message will be saved in SIM card automatically. The number of messages (received and saved) saved in SIM card is dependent on SIM card capacity.

To read the message, enter submenu Inbox and press OK.

After reading the message, you can perform the following operations:

- The SMS service enables you to send SMS to other mobile phones that can receive SMS.
- Make sure the number of SMS center has been set before write SMS (refer to "SMS setting").
- Enter submenu Create SMS to write SMS (refer to Chapter 4.2 "Input methods"). Click Options menu in input interface to perform the following operations:
  - OK: Select this option to finish this SMS and enter next operation.
  - Templates: Insert preset template into the message.
  - Insert object: Insert picture, ring tone or video into this message.
  - SMS format: Define the text format of the SMS.
  - Insert contact number: Insert the telephone number of the entry in Contacts.
  - Insert name: Insert the name of the entry in Contacts.
  - Insert bookmark: Insert the web address of selected bookmark.
  - Input method: Change the input method when editing message.
- After writing, select Send in SIM1 (SIM1 and SIM2 depend on the slots) and you can click Send, Save and send, Save, Send to multi contacts or Send to group according to your requirements.
- Send: Send the SMS with SIM1. Select this option to enter recipient edit box, and you can click number keys and then press OK to send out Contacts.
- Send (SIM2): Same as Send in SIM1. The SMS will be sent with SIM2.
- Save and send: Send the SMS and also save it in Outbox.
- Save: Save the SMS in Outbox without sending it.
- Send to multi contacts: Send the SMS to multiple numbers.
- Send to group: Select a group and send the SMS to every member of the group.

Note: Short message centers in some cities and areas don't support long short messages of more than 70 Chinese characters (or 160 English characters).

**3.3.3 View received and saved SMS**

- Enter submenu Inbox to view received SMS; enter Outbox to view the SMS you have saved in SIM card.
- When you view the SMS list of Inbox, the receiving time and date, and the other party's number or name (if the tel number is saved in Contacts) will be displayed.
- When you view the SMS list, you can select previous or next SMS.
- When the messages list of Inbox appears, you can press OK to read the message. You can press Option to perform the following operations:

- Reply: Send SMS to the sender of this message.
- Delete: Delete this SMS.
- Forward: Forward this SMS.
- Copy to phone (SIM): Copy the SMS from SIM card (mobile phone) to mobile phone (SIM card).
- Move to phone (SIM): Move the SMS from SIM card (mobile phone) to mobile phone (SIM card).
- Delete all: Delete all SMS in inbox.
- Copy all: Copy from SIM card or mobile phone.
- Move all: Move from SIM card or mobile phone.
- Use number: Pick up the phone number of the sender and you can dial or save it in Contacts.
- Use web address: Pick up the web address in the message.
- Use USSD: Pick up numbers.
- Use e-mail: Pick the e-mail.
- Chat: Enter chat room.
- Print: You need to activate Bluetooth to match Bluetooth device.

When the messages list in Outbox appears, you can press OK to read the messages. You can press Option to perform the following operations:

- Send in SIM1 (SIM1 and SIM2 depend on the slots): Send the SMS. You can also select multi contacts or group to send this message to multiple recipients.
- Save: Save the SMS to the Outbox.
- Delete: Delete the SMS.
- Copy to phone (SIM): Copy the SMS from SIM card (mobile phone) to mobile phone (SIM card).
- Move to phone (SIM): Move the SMS from SIM card (mobile phone) to mobile phone (SIM card).
- Delete all: Delete all SMS in Outbox.
- Copy all: Copy from SIM card or mobile phone.
- Move all: Move from SIM card or mobile phone.
- Use number: Pick up the phone number of the recipient and you can dial or save it in Contacts.
- Use web address: Pick up the web address in the message.
- Use USSD: Pick up numbers.
- Use e-mail: Pick the e-mail.
- Print: You need to activate Bluetooth to match Bluetooth device.

**3.3.4 Template**

- Enter some frequently used sentences in Templates to avoid repeated input of same contents. You can edit or delete the templates.

**3.3.5 SMS setting**

- Enter submenu SMS setting to perform necessary settings before using SMS function.
- Enter submenu SMS settings.
- Mode setting: Select a suitable mode for mobile phone SMS. Enter the mode and you can set the name, SMS center

number, validity and sending format.  
**State setting:** Set whether enable message report or reply path.

**Memory state:** View the status of SIM card or mobile phone memory.

- **SMS center number setting:** Save in mobile phone or SIM card. Please contact your local network supplier to get the SMS center number. For example, one of +8613800210500. The specific operation is: Select **More setting** in SMS submenu, enter the number of SMS center and press OK to save the setting.
- **Report when the message report is enabled:** The SMS center will send report when the message receives or doesn't receive the SMS.

#### 3.4 Calendar

Enter submenu **Calendar** and press OK to display the date.

- **Press Options:** Click the Left/Right key to select date and month.
- **Blank area:** Click the blank area below to have Edit and Back menu, and you can create new schedule and return to Calendar.

**List:** List all schedules; click Options menu to perform operations like View, Add, Edit, Delete, Send (in SMS, Memory card or Bluetooth), and Save as file (in SIM card or mobile phone).

- **Week view:** Activate Week view and the calendar will be displayed in week.
- **Month view:** Activate Month view and the calendar will be displayed in month.
- **Print:** Click the "Print" symbol in the upper right corner to list Other, Group and Course. Select corresponding item to edit the calendar according to your requirements.

#### 3.5 Album

Access the Album to perform operations like View, Play, Rename, Delete, Delete all, Sort and Storage. Press Options to enter the settings.

#### 3.6 Camera

This mobile phone is integrated with camera function. Click the Camera icon at the bottom of the screen to enter Click. Click the interface to perform operations like Special good effect, White balance, Sequence setting, Scene mode, Image quality and Image size. You can also press Options to enter the settings.

- **Access Album:** Access Album pictures.
- **Camera settings:** Set corresponding parameters of taking pictures.
- **Lens switch:** Select Lens 1 or Lens 2.

**Image settings:** Set the size and quality of images.

**White balance:** Set the color of photo light.

**Scene mode:** Set the shooting mode.

**Special good effect:** Select viewing style.

**Frame:** Select a frame for picture.

**Storage:** Select the storage position of video player is memory card or mobile phone or memory card.

**Reset:** Restore the default settings.

**Note:** In viewing interface, click the icon to set corresponding image effect.

#### 3.7 Cinema

Press Options to play.

**Press Options:** Press Options to play.

**Play:** Play the selected file.

**Send:** Send the selected file (in e-mail or Bluetooth).

**Rename:** Change the name of selected file.

**Delete all:** Delete all the selected records.

**Sort:** Sort the files according to Type, Time, Size, or None).

**Streaming media website:** Inbuilt websites, history websites or new websites.

**Network settings:** Five options are available.

**Storage position:** Select to save in mobile phone or memory card.

**Note:** The default storage position of video player is memory card and the folder name is Video.

#### 3.8 Memo

You can save 50 entries of memo in this mobile phone. Select Memo in the submenu and perform operations like View, Add, Edit, Delete, Delete expired schedule, Delete all, Go to date, Send schedule and Save as file.

Select E-mail to enter the menu and the submenus are:

■ **Send and receive:** After sending and enabling e-mail account, you can select this option to send and receive e-mail.

■ **Edit:** Create new e-mail. You can add recipient, cc, bcc, subject, content and attachment. Then, you can select Send, Send and save, Save in Drafts or Exit.

■ **Inbox:** View received e-mail. You can perform operations like View, Sort, Mark to delete, Delete and Forward.

■ **Outbox:** Save the e-mail that hasn't been sent successfully. (The operation is same to Inbox).

■ **Drafts:** Save e-mail which will be sent later. You can perform operations like View, Sort, Mark to delete and Delete.

■ **Clear e-mail:** Five submenus are available: Inbox, Outbox, Sent, Drafts and All.

You can select to clear certain list or select All to clear all lists.

■ **Delete marked e-mail:** Five submenus are available: Inbox, Outbox, Sent, Drafts and All.

You can select to clear certain list, or select All to clear all marked e-mails.

**1. New account:** Press Options to enter a new account. Click On. Enter your e-mail address (e.g. A@126.com) to create an account. Click Next. Input method or Cancel. After clicking Next, you can select the communication protocol (IMAP4 or POP3) for e-mail (the protocol provided by the communication protocol (IMAP4 or POP3)).  
**2. Data account:** Press Next step and set data account (e.g. POP3). Click Next step and set receiving server (e.g. pop3.126.com).  
**3. Receiving server:** Set the pop3 address of receiving server (e.g. pop3.126.com). After setting, enter next step.  
**4. Sending server:** Enter the smtp address of sending server (e.g. smtp.126.com). Then, enter next step and set User name of e-mail server (e.g. before @). Then, enter next step and set Password.  
**5. Password:** Enter the password of the e-mail (e.g. B). Then, enter next step and set account name.  
**6. Account name:** pop3.126.com by default. Then, enter next step.  
**7. Account:** You can click the account to enter existing account and perform operations like Start, Edit, New, Delete, Account and Delete.  
**8. Access:** Access Edit and edit the account.  
**9. The second option, Display name:** the name displayed when the recipient receives the e-mail (e.g. C). Then, enter next step.  
**10. The third option, Advanced settings:** you can enter any name here).  
**Account settings:** after setting the parameters of e-mail, enter:

**Services:** Data account - GPRS, select the sending account (e.g. CHINA MOBILE GPRS).  
**Then, click:** the GPRS connection point from "onwap" to "cmnet" (note: change into the GPRS connection point from "onwap" to "cmnet" (note: Max size: The maximum size of each e-mail).  
**Sending server settings:** Sending port: 25 by default.  
**Authentication:** "On" by default.  
**Receiving server:** the receiving port is 110 by default.  
**Signature:** Enter the signature at the end of the e-mail.  
**3.10 Create message:** Refer to Section 3.3.2. Create message.

**3.11 Calculator:** The calculator provides a calculator with four basic functions: Add, Subtract, Multiply, and Divide. Click the screen to enter the numbers to calculate. Click the "=" button to calculate. Note: This calculator features limited accuracy due to the limited screen size.

**3.12 Email account:** Press Options to enter a new account. Click On. Enter your e-mail address (e.g. A@126.com) to create an account. Click Next. Input method or Cancel. After clicking Next, you can select the communication protocol (IMAP4 or POP3) for e-mail (the protocol provided by the communication protocol (IMAP4 or POP3)).  
**2. Data account:** Press Next step and set data account (e.g. POP3). Click Next step and set receiving server (e.g. pop3.126.com).  
**3. Receiving server:** Set the pop3 address of receiving server (e.g. pop3.126.com). After setting, enter next step.  
**4. Sending server:** Enter the smtp address of sending server (e.g. smtp.126.com). Then, enter next step and set User name of e-mail server (e.g. before @). Then, enter next step and set Password.  
**5. Password:** Enter the password of the e-mail (e.g. B). Then, enter next step and set account name.  
**6. Account name:** pop3.126.com by default. Then, enter next step.  
**7. Account:** You can click the account to enter existing account and perform operations like Start, Edit, New, Delete, Account and Delete.  
**8. Access:** Access Edit and edit the account.  
**9. The second option, Display name:** the name displayed when the recipient receives the e-mail (e.g. C). Then, enter next step.  
**10. The third option, Advanced settings:** you can enter any name here).  
**Account settings:** after setting the parameters of e-mail, enter:

**Services:** Data account - GPRS, select the sending account (e.g. CHINA MOBILE GPRS).  
**Then, click:** the GPRS connection point from "onwap" to "cmnet" (note: change into the GPRS connection point from "onwap" to "cmnet" (note: Max size: The maximum size of each e-mail).  
**Sending server settings:** Sending port: 25 by default.  
**Authentication:** "On" by default.  
**Receiving server:** the receiving port is 110 by default.  
**Signature:** Enter the signature at the end of the e-mail.  
**3.10 Create message:** Refer to Section 3.3.2. Create message.

**3.12 eBuddy:** This mobile phone provides wireless LAN instant message tool. Enter the menu and perform the following operations:  
**First, select language.** Several languages are available.  
**Second, select the network and log in the chat room.** You need to set an eBuddy ID, password, e-mail address, gender, age, and so on.  
**Third, select the network and log in the chat room.** You can select MSN, Yahoo!, Gmail, ICQ or Facebook as the network for chatting. Enter the user name and password and then enter the chat room.

**3.13 Map:** You can log in Google Maps through wireless LAN. Use this map to consult road names, check buses, view map and record favorites.

**3.14.1 Settings:** You can set Dual-card, SIM1, SIM2 or Flight mode.

**3.14.2 About flight mode:** The communication function of the phone is disabled in flight mode, i.e. you can't make or answer calls, or send short messages, and the phone won't receive signals from base station or try to search for base station. In this mode, the functions related to signals are disabled, but you can still use other functions, e.g. view Contacts, read documents, or watch movies in the mobile phone.

**3.14.3 Acceleration sensor calibration:** Adjust the stylus to make it more accurate through Coordinate.

**3.14.4 Acceleration sensor settings:** This menu provides the menu to use acceleration sensor. You can select to cancel personalized acceleration sensor. The function of acceleration sensor can realize sense function. In music play interface, shake left and right to switch to previous or next track; in TV interface, shake left and right to modulate the frequency; in video interface, shake left and right to select channel. You can rotate the mobile phone in different directions and watch video in different angles.

**3.14.5 Acceleration sensor calibration:** Adjust the stylus to make it more accurate through Coordinate.

In Album, you can rotate the mobile phone in different directions and view pictures in different angles.  
Rotate the phone 180° in incoming call interface to make the incoming call silent.  
In games interface, shake the mobile phone left and right to play games.

### 3.14.5 Phone settings

- **Time and date**: Set time and date.
- **Time zone**: Set city. Select a city for the time setting of the mobile phone.
- **Time/date setting**: Set current time and date.
- **Format setting**: Set the display format of time and date: 12-hour or 24-hour.
- **Time zone and time**: Select On or Off. If On is selected, the time zone and time will be set according to the time zone selected. If Off is selected, the time zone and time will not be set.
- **Schedule power on/off**: Set the time at which the mobile phone will power on/off.
- **Language**: set the displaying language of mobile phone menus.
- **Input method**: Select to activate or deactivate the input method of corresponding languages.
- **Default input method**: Select default input method.
- **Coding**: Big5 and GB2312 are available.
- **Standy menu display**:
  - **Wallpaper**: Select standby interface wallpaper.
  - **Screen saver**: Choose a screen saver picture for main standby interface and set waiting time.
  - **Power off images**: Select pictures for power on image, power off image, screen switch effect, and power off image.
  - **Screen switch effect**: Select pictures for screen switch effect menu and enter.
- **Greetings**: Display greetings in the displaying process of power on image. Select Off to disable.
- **Auto update**: Enable/disable auto update time.
- **Handwriting Setting**: Set handwriting style and color.
- **UART setting**: Select UART of SIM1 or SIM2.
- **Other settings**: Set LCD brightness and delay.

### 3.14.6 Network settings

- **Network selection**:
  - **Access point**: Press OK to access new network.
  - **Select network**: Search for and access network.
  - **Scan mode**:
    - **Auto**: Scan the network of this SIM card automatically.
    - **Manual**: Search for all available network and register manually.
- **Prior network**: Pre-store several networks you prefer.

### 3.14.7 Security Settings

- **SIM Lock**: You can set the security options under this menu to prevent the mobile phone or SIM card from unauthorized usage.
  - **Pin Code**: PIN code can prevent the SIM card from unauthorized usage.

If PIN code has been disabled, you can enable the PIN protection, and PIN code would be required when the cell powered on at the next time. If PIN code has been enabled, you can disable the PIN protection. Also, you can change the PIN code by selecting "Change PIN".

Attention: if you enter the invalid PIN code for three times continuously, SIM card will be locked, and then you need to unlock it. PIN and PUK codes may be supplied with the SIM card. If they are not, you can contact the operator. The default PIN code is 1234, and you'd better change it as soon as possible.

### Phone Lock

Phone lock can prevent your cell phone from unauthorized usage. Moreover, lock can enable the cell phone password protection. The password will be required when the phone is powered on at the next time, and you can disable the password protection again.

Attention: the default cell phone password is 1122, and you'd better change it as soon as possible.

### Keypad Lock

You can set the latency time of the keypad lock. If the phone is not automatically locked within the specified time, the keypad will be locked.

### Passwords Changing

You can change the PIN, PIN2, and cell phone lock passwords. Attention: some functions need the support of network operator.

### Anti-Theft Tracking

Notes: if your mobile phone has been lost, it will send SMS to a specified number, and the SIM card will be replaced. You can find who is using your phone through the SMS, so it is helpful for you to regain it.

Notes: the default password of anti-theft tracking interface is 000000, and you can change it.

### Anti-Theft Tracking Number

1. **Anti-Theft Tracking Number**: input the tracking number, which is the number you want to receive the SMS.  
2. **Anti-Theft Tracking Setting**: ON/OFF. You can choose ON to enable this function.

### Incoming Call Firewall

This function is the function of incoming call firewall. You can set various options such as blocking of specific numbers, or just answering the calls from numbers in the name cache. So you can answer only the calls you want.

### SMS Firewall

This phone has the function of SMS firewall. It allows you to receive the SMS only from numbers you want.

### Remote Control

This phone has the function of remote control. You can control your phone by seeing SMS from another phone to your own phone when it is away from you. Notes: The default password to enter remote control interface is 0000, and you can change it.

**1. Remote Control Settings:** options available are:

1. Remote control
2. Call diverting
3. Call phone lock
4. Disk formatting
5. SMS forwarding
6. Name card transmitting

**Attention:** 1. Remote control of a specific function is valid after you have enabled it. 2. Call diverting needs network support.

**2. Controlling Number Settings:** you can choose optional number or specified number as the controlling number.

**1. Freewill Number** (sending remote controlling SMS to your own phone from freewill number)

**2. Specified Number** (sending remote controlling SMS to your own phone from a specified number)

**3. Password Changing:** To change the factory default password of entering remote control interface

**4. Remote Control Commands Presetting:** The remote control commands are default. You just send SMS to your own phone after you have entered the corresponding proper command.

1. Remote Power-off Command  
Command: POWER OFF
2. Call Diverting Command  
Command: CALL DIVERTE
3. Call Phone Lock Command  
Command: PHONE LOCK
4. Disk Formatting Command  
Command: DATA RESUME
5. SMS Forwarding Command  
Command: SMS DIVERTE
6. SMS Forwarding Command Canceled  
Command: CANCEL SMS DIVERTE
7. Name card Formatting Command  
Command: PHONEBOOK DIVERTE

**Attention:**  
1. The options for changing the remote control commands include numbers, letters, and symbols, and the numbers of them can be 19 or less than 19.  
2. When you send SMS with will be automatically answered. This function of forwarding to your phone SMS will be in use when you enter the specified phone number.  
3. Name card Formatting Command: You will be automatically answered when you enter the needed name after the command and send the SMS to your phone.

**3.14.8. Restore Factory Settings**  
The default password for restoring factory settings is 1222.

**3.14.9. Sound Effects**  
You can adjust the sound effects by choosing the audio equalizers of sound effects, or any sound effect, or disable it.

**3.1.5. Call History**  
Please refer to the "Call Center" menu.

This menu displays all the call history, and you can see the date, calling time, calling number, calling times, and calling item of each item. At the same time, you can click the options of delete, save the number to the phonebook, call, call to the IP, send SMS, or send MMS.

Notes: call, call to the IP, send SMS, or send MMS includes the card 1 and card 2, both of which have all the call history, respectively.

**3.1.6. Wallpaper**  
In this interface, you can choose from various wallpapers. When the keypad is unlocked, you will see the wallpaper you have chosen.

**3.1.7. Wireless Network LAN**  
"Wireless Network LAN", which is a shortcut menu of wireless LAN in network service's data accounts.

**The Process of Using WiFi Function**

- Step 1: click "Network Service" from the interface of standby.
- Step 2: click "Data Account".
- Step 3: click "Wireless LAN".
- Step 4: click "Start Wireless LAN".
- Step 5: click "Search Network".
- Step 6: choose a network with powerful signal (such as BUFFALO) from networks available.
- Step 7: click "Definition Access Point" of corresponding network.
- Step 8: enter "Entry Point Setting", and choose the sixth item "WEP Key Setting".

In which  
WEP Key: change it to "128 digits" (according to practical settings); Mod: change it to "ASCII" (according to actual settings of wireless route)  
WEP Key: enter the password (if router has no password, you can neglect it)  
Click: "Complete"

- Step 9: Click "Connect".
- Step 10: Click "SIM Card I/Crete", and change the data account to "Wireless LAN".

Step 11: activate the network created.

**3.18 Java Entertainment**  
You should download games supported by the phone from the Internet.



### Game Vibrating: ON/OFF

Volume: 1 to 7, available

### 3.2.2 Dynamic Call Search

A game search interface, "Dynamic Dice", is provided. 3.2.4 Fast Search: select this item to enter "Phonebook Browsing" interface, a searching frame is provided in the window. You can enter the corresponding numbers into the frame to search for the methods you want. There are many search methods, such as numbers, names, and so on.

3.2.5 Names Search: search the number you want by entering the name, previous numbers, such as paytm, letters, numbering the name. You can search for the number, and you can send SMS and MMS to the number, and also you can read, edit, delete, copy, remove, send or print the name card.

### 3.2.4 Call Counter

3.2.4.1 Call Counter: call history of SIM 1 and SIM 2 respectively. Here we take SIM 1 as an example, as the operation of SIM 2 is the same as that of SIM 1.

- Missed Calls: press OK to view the list of missed calls.
  - Dialed Numbers: press OK to view the list of dialed numbers.
  - Answered Calls: press OK to view the list of answered calls.
- In the interface of "Missed Calls", "Dialed Numbers", and "Answered Calls", press "OK" to view the detailed information of an entry, including date, time of call, number and number of calls. In the interface of detailed information, you can press "Option" to perform the following operations: current selected call record.

Delete: delete this record.  
Save to Phone Book: save this number to SIM or phone memory.

Call: dial this number.

IP Dialing: use IP dialer and save it to phone book.

Edit call: edit this number.

Send SMS: send SMS to this number.

Send MMS: send MMS to this number.

### Delete Call History

There are four submenus in this item: "Missed Calls", "Dialed Numbers", "Answered Calls", and "Delete All" record list. Once you select "Delete All", you will delete all the record lists from the call history.

### Call Duration

Call Duration: four submenus in "Call Duration": "Last Call Duration", "Dialed Calls Duration", "Answered Calls Duration", and "Reset All".

Users can select to clear selected call record.

Dialed Calls: view the duration of last call.

Answered Calls: view the total call duration.

Reset All: clear timers and restart timing.

Call: view total call charges for you.

It can save total call charges for you.

### Last Call Charge

Enter the submenu "Last Call Charge" to view last call charge.

Total Calls Charge: submenu "Total Calls Charge" to view the total calls charge.

Reset Call Charge: you can clear call meters and restart billing.

Charge Limit: Enter the submenu "Charge Limit", you can view, modify or cancel this function. PIN2 is required for function "Modify and Cancel".

Price and Rate: Enter the submenu "Price and Rate", you can browse, modify or cancel this function. PIN2 is required for function "Modify" and "Cancel".

Attention: You need to input PIN2 for part of the operations. Please contact our network provider for passwords.

■ Send Counter: record the number of sent SMS.

Received: record the number of received SMS.

If there is a record, click "OK" to save the records.

Reset Counter: would pop up. Click "Yes" to clear and "No" to save the records.

■ GPRS Counter: record the number of bytes transmitted last time.

Last Transmission: record the number of bytes received of transmission.

Total Transmission: record the total number of bytes of transmission.

Total Received: record the total number of bytes of the received.

Reset Counter: restart to count.

Notes: SIM1 and SIM2 respectively Take SIM 1 as an example, as the operation of SIM2 is the same as that of SIM1.

### 3.2.4.2 Call Settings (SIM)

1. Call Settings (SIM)

Own Number: Default, whether use the defaults when send the number number, require the support of providers.

Send Number: the opposite can see your number while calling.

Call Waiting: enable or disable call waiting. Select "Inquiry" to check status.

Call Divert: Caller Calls: divert when it is voice call.

Divert if out of Reach: enable "Divert if out of Reach". When the opposite can not reach you, the incoming call would be diverted to the number you enable "Divert if not Answered". When there is no answer, the incoming call would be diverted to the number you enable "Divert if Busy". When you are busy, the incoming call would be diverted to the number you set.

Divert All Data Calls: divert when it is data call.

- **Cancel Divert:** cancel all divert.
- **Call Barring Service:** Barring the number you want to call.
- **Outgoing Calls:** bar the outgoing calls.
- **Barring Incoming Calls:** bar the incoming calls.
- **Enable All:** barring the outgoing calls as well as incoming calls. (Passwords are required.)
- **Cancel All:** cancel the barrings set by you. (Passwords are required.)
- **Passwords:** modify it.

Line for Outgoing Calls:

Select line 1, or line 2.

## 2. Advanced Settings

- **Blacklist:** the numbers in the blacklist would be screened.
- **Automatic Redial:** enable it, it will redial automatically after call fails.
- **Speed Dialing:** enable it, press the related key for a long time to realize speed dialing in standby. You can set 2-9 as the key for speed dialing.
- **IP Dialing:** set and enable it, you can perform the function of "IP Dialing" through your phone book.
- **Background Sound:** choose to enable or disable "Background Sound" while calling.
- **Display of Life Timer:** enable it, the calling time would be displayed, vice versa.
- **Prompt Life Timer:** set up frequency, you would be reminded by the warning tone when time is over.
- **Automatic Time Limit:** enable it and set the time. Your call will be cut off when time is up.

3.45 File Management

Store the files saved by users (phone or memory card). Enter options of

the folder:

Open: display the contents in the folder.

New folder: create a new folder in this folder.

Remove folder: delete the folder.

Note: rename the memory card and view its capacity.

## 3.26 Profile

Users can choose different profiles and define several profiles at the same time. There are six profiles in this phone: **General**, **Meeting**, **Outdoor**, **Indoor**, **Headset** and **Bluetooth**.

**General**

■ **Activate:** select "Activate" or "Personalize".

■ **Personalize:** select "Personalize" and enter. You can define the "General". The operations include "Ring Tone", "Ring Volume", "Prompting Type", "Ring Type", "Other Warning Tone" and "Answer Mode".

(It operation is the same as that of "General".)

## Outdoor

Its operation is the same as that of "General".

### Indoor

Its operation is the same as that of "General".

### Headset

Insert the earphone, then this profile will be activated automatically. The operation of personalization is the same as that of "General".

### Bluetooth

Start your Bluetooth earphone and activate Bluetooth to enter this profile. The operation of personalization is the same as that of "General".

Touch the screen to select the time of each country in the world. Select "Others", you can enable or disable the time of other countries to enable the daylight saving time.

### 3.28 Network Service

#### 3.28.1 STK Service

This function is provided by network provider, such as the following value-added telecommunication services: Mzone, VIP Zone of Globet Service.

#### 3.28.2 WAP

Your phone can support WAP service, so you have access to the service provided by the network provider. You could have all the following information through this function table, like related news, weather forecast and flight information. Network support is required for GPRS service. You must subscribe GPRS service and in the coverage of GPRS, and then you can use this service.

**Homepage:** visit homepage. Homepage is the first website you set in the connection of network.

**Bookmark:** display each bookmark, you have. Select one of them, you can browse the website directly.

**Input Website:** this item would record the entire website you browsed before.

**Saved Webpage:** this item records the web pages you saved before.

**Input Website:** select this item you can input any website, WAP or other websites.

**Send Message:** send message sent by service operator.

**Settings:** set to surf the internet.

#### 3.28.3 Data Accounts

**GSM Data:** select one account number to enter.

1. **Name of Account:** you can select "Edit" to modify this name.

2. **APN:** the number of this account.

3. **User Name:** the user name of dial-up server (not the gateway of WAP).

4. **Password:** password of dial-up server (not the gateway of WAP).

5. **Type of Line:** select the type of line, analog or digital.

6. **Speed:** speed of transmission.

## Indoor

Its operation is the same as that of "General".

### Headset

Insert the earphone, then this profile will be activated automatically. The operation of personalization is the same as that of "General".

### Bluetooth

Start your Bluetooth earphone and activate Bluetooth to enter this profile. The operation of personalization is the same as that of "General".

Touch the screen to select the time of each country in the world. Select "Others", you can enable or disable the time of other countries to enable the daylight saving time.

### 3.28 Network Service

#### 3.28.1 STK Service

This function is provided by network provider, such as the following value-added telecommunication services: Mzone, VIP Zone of Globet Service.

#### 3.28.2 WAP

Your phone can support WAP service, so you have access to the service provided by the network provider. You could have all the following information through this function table, like related news, weather forecast and flight information. Network support is required for GPRS service. You must subscribe GPRS service and in the coverage of GPRS, and then you can use this service.

**Homepage:** visit homepage. Homepage is the first website you set in the connection of network.

**Bookmark:** display each bookmark, you have. Select one of them, you can browse the website directly.

**Input Website:** this item would record the entire website you browsed before.

**Saved Webpage:** this item records the web pages you saved before.

**Input Website:** select this item you can input any website, WAP or other websites.

**Send Message:** send message sent by service operator.

**Settings:** set to surf the internet.

#### 3.28.3 Data Accounts

**GSM Data:** select one account number to enter.

1. **Name of Account:** you can select "Edit" to modify this name.

2. **APN:** the number of this account.

3. **User Name:** the user name of dial-up server (not the gateway of WAP).

4. **Password:** password of dial-up server (not the gateway of WAP).

5. **Type of Line:** select the type of line, analog or digital.

6. **Speed:** speed of transmission.

7. **Primary DNS Address:** display its primary address.
  8. **Secondary DNS Address:** display the secondary address.
- GPRS Data:** select one account number to enter.
1. **Name of Account:** you can select "Edit" to modify the account.
  2. **Connecting Point of GPRS:** input APN.
  3. **User Name/ID:** the account name of dial-up server (not the gateway of WAP).
  4. **Password:** password of dial-up server (not the gateway of WAP).
  5. **Type of Authentication:** select the type of code to activate the account.
  6. **Primary DNS Address:** display its primary address.
  7. **Secondary DNS Address:** display the secondary address.
- Wireless LAN:** select wireless LAN to realize WiFi function.
- Step 1: click "Network Service" to enter.
  - Step 2: select "Data Account".
  - Step 3: select "Wireless LAN".
  - Step 4: select "Start Wireless LAN".
  - Step 5: Search Network.
  - Step 6: Select the website you have searched with peak signal (such as BUFFALO).
  - Step 7: select the corresponding entry point of router.
  - Step 8: enter "Settings of Entry Point", select the sixth item "WEP Key Setting".
  - Step 9: **WEP Encryption:** change to "128 bits".
  - Step 10: **WEP Key:** change to "ASCII".
  - Step 11: **WEP Key:** input password (leave a blank if no password in the router).
  - Step 12: Click "Complete".
  - Step 13: select "Connection".
  - Step 14: click "OK" to exit from this menu, and then enter "WAP Settings/Profile/SIM 1/Create". Change the data accounts into newly set router settings.
  - Step 15: Activate this newly set router settings.
  - Step 16: Input address, then you can surf the internet.

### 3.2B.4 Connection Management

#### 3.29 Connection

The function of unit conversion is provided for you by your phone. It is convenient to convert, including weight unit and length.

**Weight:** conversion of weight unit includes Kilogram to Pound and Kilogram to Ounce. Input the corresponding figures to "Edit Box" and then press the left soft key to confirm, you will get the answer you need in another "Edit Box".

Box".

**Length:** conversion of length unit includes Kilometer to Mile, Meter to Yard, and Meter to Foot, Centimeter to Inch. Input the corresponding figures to "Edit Box" and then press the left soft key to confirm, you will get the answer you need in another "Edit Box".

#### 3.30 Currency Calculator

You are currency calculator in exchange rate and then input monetary value of your country. Press the soft key to confirm, you will get the answer you need in another "Edit Box".

#### 3.31 Voice Mailbox

The voice messages you received have been saved in the network. You must call the mailbox to listen to the messages.

**Call the mailbox:** call the number you set for your voice mailbox to listen to the messages.

**Edit:** you can add/edit the number of the voice mailbox, so it is easier and faster for you to use this function.

#### 3.32 FM Sound Recording

Select "Edit", enter the menu to set related param.

**Enable/Disable:** select Enable, it begins to record the sound when it is the time.

**Time:** set the period of time to record.

**Repeat:** select the frequency of regular recording. Once, Daily, Self-style, Weekly, Monthly.

**Channel Settings:** includes two menus: "Channel List" and "Manual Input".

**Channel List:** include channel list of FM, press "Select" to choose current Channel.

**Manual Input:** you can input the channel of FM you like.

**Record Settings:** set the related param of recording. You can set the following items: Recording Format, Quality of Sound, Memory Storage, Storage location.

#### 3.33 SMSCB

**Receive Mode:** select "Enable", then you enter "Receive Mode", while select "Disable" to reject the message from SMSCB.

**Read:** enter this menu to read the message you have subscribed.

**Channel Settings:** set the language of receiving SMSCB.

**Note:** the service of SMSCB and voice mailbox is provided by the provider. Please contact your provider.

#### 3.34 Video Recorder

Your phone is provided with the function of recording animation. Memory is the storage location by default. Select the menu "Camera" to enter and press the soft key in the middle to start recording.

**Note:** the brightness of recording can be adjusted by the keys on the left and right.

Select Options to Enter:

**Video Recorder Settings:** select this menu to set the related the param of camera.

required to download files by USB cable and save it to the folder named "E-book". If there is no such a folder, you must create one named "E-book".

- **Open E-book:** you can read the content in e-book.
- **System Settings:** you can change the display of the e-book (font, page cut and so on).
- **Information:** view the current detailed information in e-book.
- **Delete:** delete the current e-book.
- **Delete All Files:** delete all files in the list of e-book.
- **Type of Sorting:** sort the list of e-book. (according to name, size, date, or no sorting)
- **Outgoing System Settings:** restore previous settings to default.

**Help:** prompt help information.

**Note:** enter the list of e-book, you can use point-touch pen to click the soft keypad to set.

**3.40 Bluetooth**  
 Activate or deactivate Bluetooth function by this switch.

**Search Hands-free Device:** Mobile phone can search hands-free device around automatically through Bluetooth headset. (Generally, the default password for Bluetooth headset is 0000. See user manual for Bluetooth headset for details.)

**Remote Control:** Remote Control function can be realized.

**My Device:** You can search for Bluetooth device automatically, by searching for new devices and your device name will be shown on the screen, you can set matching following the page.

**Connecting Device:** Menu setting after connecting the Bluetooth headset.

**Setting:** Allow To Be Searched: If this function is opened, other Bluetooth devices can find this phone, otherwise, it can't be searched.

**Device Name of This Unit:** You can set this device name all by yourself.

**Authentication:** Requirement: If this function is opened, the authentication will be prompted to enter Bluetooth password when it is searched, otherwise, there is no prompt when it is searched.

**Set Voice Path:** (1)

**Only in Phone:** If you select this function, you can only use phone to call but can't use Bluetooth headset.

**(2) Diverted to Hands-free Device:** If you select this function, you can only use Bluetooth headset in call but can't use phone.

**Video Settings:** set the following related param: Quality of Video, Limit of File Size, Record Effect and Time of Record.

- **Effect:** select camera 1 or camera 2.
- **Effect Settings:** you could choose an effect for this record.
- **Storage Location:** select to store in phone or memory card.
- **Restore Default:** restore all the settings to factory settings.

**3.35 Answering** this menu stores all the message of received calls. Enter it, you can view/play this message. If there is any new message, press one short-cut key (OK in general) to view in the standby interface.

**Settings:** enable or disable the answering machine.

**Enable/Disable:** select to enable and disable the answering machine.

**Storage Location:** select phone or memory card.

**Time of Answering:** it is the time to enter message mode after the time you set is over.

**Recording Time:** set the time of recording.

**Recording Note:** you can select your favorite welcome note and also you can select it from phone or memory card.

**Repeat** select Enable/Disable to enable it.

**Repeat** You can realize the function of A/B repeat for the stereo files. Enter and select one file, select the options of A/B repeat. Meanwhile press the button of "Play" in the main interface of A/B repeat, so the file you are playing could be cut to several parts. After recording, you can enable the function of repeat by clicking "Setting" and then clicking one point of the section you set when you are recording.

**Logo Settings:** set the style of repeat.

**Repeat:** select Repeat 0 to 9.

**Plus and Minus Signas:** modify the volume.

**3.37 Repeat** record a new stretch of voice.

**Play:** play the current selected recorded files.

**New Record:** record a new stretch of voice.

**Also,** it could rename, delete, use and send the recorded files.

**3.38 Slide** The files of photos or images could be stored in the folders of the phone or T-flash card.

**Play:** play the images in the selected folder.

**Settings:** you can select play mode, speed, special effects, background effects, level play and so on.

**3.39 E-book** The storage location of e-book files is memory card. You are

**Settings:** Do settings for the FM radio.

1. **Background:** Select ON/OFF. If you enable this function, the FM radio will continue playing when the handset is closed.

2. **Mobile Phone Loudspeaker:** FM radio can sound by the loudspeaker if you start this item.

Tip: Press the number key in the FM radio interface to enter the corresponding channel.

3. **Play Mode Format:** You can select the record formats of AMR, WAV or AVB.

4. **Sound Quality:** Select high or low.

5. **Storage Location:** Select storage location of mobile phone or memory card.

**Record:** Press OK key to start the record function, you can record the content of voice messages and record the MP3 audio file.

**File List:** For saved recorded FM radio list, you can press "Option" key to do the operations of play, use as, send, detail information, rename, delete, delete all, sort mode and so on.

3.46 **Alarm Check**

This function can set 5 alarm checks. You can edit and set any one of them after selection.

3.47 **Phone Book**

You can use Contact to save some important persons' information such as name, mobile phone, home phone, company phone and so on. Select Contact from Menu to enter it.

Tip: The mobile phone can save 800 phone numbers. In the search mode, you can search, add numbers, copy all, delete, groups of accepted calls, other phone settings, call prompting photo, call prompting music, call prompting movie and so on.

■ **Fast Search:** Select this item to enter the contact browsing interface, there is a search input box below the window where you can input the corresponding information to filter the call records. Optional information includes: Number.

■ **Name Search:** Search records in the contact by entering name.

■ **Add Contact:** You can add a new phone record to the contact and select saving it to SIM card or phone. SIM card and phone memory have some difference in storage format.

■ **Copy All:** You can copy all the records between phone and SIM card or phone and SIM card.

■ **Delete:** Select this item to delete phone contacts. You can delete all the phone contacts from SIM card or from phone or delete them one by one. (Tip: When deleting the call records of SIM 1, SIM 2 and phone, you should enter password, the default password is 1122.)

■ **Accepted Call Group:** This unit provides you 5 accepted call groups. For each group, you can change name, ringing tone, call prompting picture, call prompting animation and personalized settings for group members.

■ **Other Numbers:** You can check and edit other numbers saved in the SIM card (My number/Service number/Emergency number).

■ **Contract Setting:** The setting function of contact has 5 menus: storage state, the preferred storage location, column, my business card and business card version.

**Storage State:** Select the state of phone record in SIM card and phone.

**Preferred Storage Location:** Select the preferred storage location from phone, card 1 and card 2.

**Column:** Set the content recorded in the phone contact (8 settings, as home number, company name, email and so on.)

**My Business Card:** You can edit your business card and send it by SMS, MMS or Bluetooth and also can save it to the document.

**Business Card Version:** You can choose business card of version 2.1 or version 3.0.

■ **Call Prompting music:** You can choose music for call prompting.

3.48 **Opera**

Using wireless LAN, you can search for JAVA games available for downloading in pages. (Tip: To realize this function, please pay attention to the network connection time and actual time, you can refer to "Time and Date" in "3.14.5 Phone Setting" for specific operation.)

3.49 **Music**

There are two icons on the top of music player screen: The left is function of Back to Main Menu, the right is Music List. Below the list, you can Library, Update Playlist, Play, Check Detail, Add Ring

**Non-Interpretation:**

**Play:** Play the current selected music.

**Detail Information:** Check the detail information of this music.

**Add to Ring Library:** Add the current music to the ring library of Library.

**Update Playlist:** Update the music in ring library.

**Tip:** The model supporting touch screen function can realize the following functions:

**Touch Key:** You can use the scroll bar at the bottom to turn up and turn down the music volume.

▶ and ▽ Press this icon to enable, disable and suspend the current playing.

◀ and ▶ Press these two icons to switch to the last or the next music.

**Setting:** Set the multimedia playing.

1. **Playing Setting:**

**Preferred List:** Phone memory or memory card.

**Automatically Form List:** Select start or deactivate.

**Repeat:** Select this item to repeat playing music.

**Random:** Start this item to play music randomly.

**Background Play:** If you start this item, the music won't stop when the menu exits.

2. **Panel Setting:**

**Lyrics Display:** Start this item to display lyrics when playing MP3.

3. **Audio Effect Setting:** enable or disable audio effect.

4. Bluetooth Setting: **Input**: enable or disable it.  
**Bluetooth Stereo Headset**: Start Bluetooth Stereo Headset and connect it. Then you can listen to the Bluetooth device is by set.  
**MP3 by Bluetooth headset**: name of music player is My music (phone and memory card).

4. Input Method Description  
 This unit supports the following input methods, the input methods provided for you are: English input (upper and lower case), Pinyin input (common symbol), Punctuation (common symbol).

- In the mobile phone, the function items allowing Chinese character input are:
- Input, edit, show, message
- Input, edit copy, number and name
- Search phone, ring and owner name
- Customize grid in toolbox and so on.
- Name the rec.

4.1 Input Method Description of input methods:

- **Select and Input Pinyin**: Touch screen to choose the letters, use the touch screen to click "X" (at the top right of the enter key) to clear the last input character.
- **Select and Input Character**: Touch left or right arrow to select the characters and turn over the screen to search character you character.
- **Select Associated Character**: As association input method can give a word, then press left soft key to copy, move cursor to click "X" (at the top right of the enter key) to clear character.
- **Edit Input Character**: Touch to clear character.
- **Input Symbol**: Click the left arrow icon to input symbol, you can also click the option in the screen to enter symbol of interface.

4.2. Input Method Description of input methods:

- **Input Symbol**: Click the left arrow icon to input symbol, you can also click the option in the screen to enter symbol of interface.
- **Input Symbol**: Click the left arrow icon to input symbol, you can also click the option in the screen to enter symbol of interface.

5.1 Flash Card Introduction

This unit supports T-Flash memory card to extend storage space. Specific operation is as follows:

5.1 Installation of T-Flash Card

The port for T-Flash card is at the top of battery on the phone back. You can insert T-Flash card according to the mark.

Tip: This unit supports Plug and Play, but in power-on state, in order to ease the normal use of playing information, starting the phone manually is recommended when you insert or take out the T-Flash card.

5.2 Use of T-Flash card

Generally, installation and uninstallation of T-Flash card is only allowable when necessary. T-Flash card is set as default memory in factory, you can use it directly without any setting. The first time you input the T-Flash card, you should set the default recorder as memory card, then you use the recorder, camera and so on. (The corresponding setting method is mentioned in the above function.)

Use of T-Flash card as phone memory: The first time you input the T-Flash card, you should set the default recorder as memory card, then you use the recorder, camera and so on. (The corresponding setting method is mentioned in the above function.)

Use of T-Flash card as storage space: Connected with USB line, it can copy the computer data to T-Flash card. Connected with USB line, it can copy the computer data directly. For specific use method, you can refer the use of U disk.

### 6 Troubleshooting

If the phone has abnormal situation, please mend it according to the following table.

Frequent Problem	Cause	Solution
Bad reception	When using this phone at an area with bad reception, such as near high building or in basement, the radio wave can't reach effectively. Use phone in period of time, or create a gap at the working time, the communication congestion will make you fail to call. Relate with the distance of network station. Caused by bad network link, it is regional problem. Connection is bad in some area. Standby time is shorter, the phone will consume a lot of power and cause the standby time become shorter.	Try to avoid it.  Try to avoid it.  Ask your network service provider to provide service area chart.  Hang up and redial, the trunk line may replace better connection.  Please temporarily turn off your phone in a poor reception area.  Change new battery.
Echo or noise	Standby time is shorter.	Please use phone in area of strong signal or turn off phone for a while.  Check the battery or charge it. Contact with network service provider.
Steadily time is shorter.	If it can't get the signal, the phone will consume a lot of power and cause the standby time become shorter.	
Fail to start	The power of battery runs out.	
SIM card error	SIM card is damaged.	

Problem	Cause	Solution
Unable to connect network	SIM card is not installed. There is dirt on the metal surface of SIM card. SIM card is invalid. Beyond the GSM service area. Signal is weak.	Ensure SIM card is installed. Wipe the metal contact point of SIM card with clean cloth. Contact your network service provider. Check service area with service provider. Retry in area with stronger signal.
Fail to call	Use call limited function. Use fixed dial function. Input wrong PIN number continuously for three times. The battery or charger is damaged.	Cancel setting of call limited function. Cancel setting of fixed dial function. Contact your network service provider. Check the battery power or charge it.
Fail to change battery.	Charge phone at a temperature lower than 10°C or higher than 55°C. Poor contact.	Change to proper charging environment. Check whether the plug has good contact.
Fail to add new entry in phone book.	The storage space of contact is full.	Delete part of phone records.
Fail to set some functions.	The network provider doesn't support this function or you didn't apply this function.	Contact your network service provider.