

## User Manual

### Attention:

This handbook contains important security measures and the correct use of the product information, in order to avoid accidents. Please make sure to reading the manual carefully before use the device.


- Please don't be in high temperature, moisture or very dust place
- Please don't be in high temperature, especially in summer don't put the device in the car when Windows closed.
- Avoid fall or Violent collision of the device, don't make the TFT display screen were violent tremor, this could cause TFT display screen abnormal or damage.
- Please choose the appropriate volume, Use headphones should not be too big volume, If feel tinnitus, Lower the volume or stop using it
- please charge In the following condition,
  - A、 The battery power ICONS shows have no power
  - B、 The system automatically shut off, startup after power off soon
  - C、 Operation buttons no response
  - D、 The machine that the top right corner show red icons
- When the device in the format or ongoing upload and download file, please don't suddenly disconnect, this could cause a application error.
- For those who because of damage to the product, repair, or other causes of erased the memory, the company shall not be liable for any responsibility, please follow the user manual for the standardized operation to use the device.
- Do not disassemble the product, don't use alcohol、 Thinner or benzene to scrubbing products
- Don't use the device one of the place of prohibit to use electronic equipment in regional (such as the plane)
- Please don't using the Tablet PC when you in driving or walking down the street,
- USB just only be used for data transmission

The company reserves the right to improve product, products specification and design have any change, the information is subject to changes without prior notice.

(This tablet is no waterproof function)

**【Attention】** All pictures in this manual is just for your reference. Products specification and design have any change; the information is subject to changes without prior notice.

### 1. Appearance and button:



#### 1.1 Touch panel

4.3" (Capacitive) Resistive touch panel: you can click, dragging on the icons in the touch panel

#### 1.2 POWER

Startup: Long Press and hold the power button, the system will enter the main interface

shutdown: In the main menu interface, Press the power button about 5 second to shutdown, The system can hint "power off" option,

Click "ok". you can safely shut down.

Screen Lock: short press the home button to lock or unlock the screen

**【Attention】:** 1.when low battery, the system will automatically shut down;

2.when it illegal to shutdown, restart will scan and repair the disk, the interface may be a long time at the progress bar screen

#### 1.3 ESC

Short Press ESC button will return the last interface, long Press ESC button will return the main interface

#### 1.4 Menu

the Tablet under normal operating conditions, short press M button will Back to the home screen

#### 1.5 Volume +, Volume-

the buttons on top Volume +, Volume-achieve changes in the volume.

#### 1.6 earphone jack

3.5 mm standard earphone jack

#### 1.7 Video output interface

HDMI output interface

#### 1.8 TF card

TF-CARD slot: external T-FLASH card

#### 1.9 Mini USB

Mini USB jack: you can use it to connect the computer for data transmission, charging and external connection USB flash drive

#### 1.10 Reset

When the Tablet under the condition of the crash, use the small objects to short press RESET button, Tablet will force to shut down.

**【Attention】:** Unless unable to shutdown, otherwise don't use the reset, suggest you to shut down by normal, if no will easy to damage the machine system.

### 2. First use

#### 2.1 Battery management and charge

Before first use, please set the device's battery is fully charged

Just need to connect the adaptor or USB interface, then you can charge

The first two times charging please keep about 6 hours, after that you just need 4 hours to charge.

**【Attention】:** This tablet using Built-in type polymer battery, Charge must be to choose standard adaptor (Input: AC110~240V 50/60Hz Max: 180MA.. Output: DC5.0~5.5V/1.5A), this device without supply DC charging, USB interface can charge, Choose USB interface to charger

During the charging, the battery icon will scroll

When finished charging, battery icon will become green and stop rolling

In order to prolong the service life of the machine, in the first twice use, recommend to use all the last power before further charge

**【Attention】:** 1. If you long time don't to use this Tablet, To avoid battery damage caused by excessive consumption, be sure to complete the first charge and discharge for this machine within one month, to prevent battery depletion;


2. Low-power shutdown, plug in the charger, tip the machine power is too low, charging, wait for some time, and so full of electricity to the machine need it will enter the main interface will automatically;

3. Recharge the machine need to backlight the whole dark, that is, standby charge

, to achieve the normal charging time, for the consumption of the machine and display, under normal use, charging time will take long

#### 2.2 Connect to PC

Use the supplied USB cable to connect PC and the machine, the machine prompts USB connected dialog box, select loading the USB data transfer can be realized, If you choose "no load" is a state of charge




Into the load mode, you can copy, delete the file into the device and the file on the memory card.

### 3. Equipment operation interface


#### 3.1 Main interface describe

After startup will enter the main interface




In the main interface, you can :

Management main interface software ICONS: long press the icons 3 second, after the icons will bigger, then you can drag any where in the interface.



Delete icons: long press the icons 3 second, drag the icons to the Recycle Bin icon, once it become red, Loosen your hand, after that you can delete icon

You touch the screen keep a time, appear the dialog box "Add to Home screen" as shown below:




### 3.2 status bar describe




- The status bar above of the screen  
Top left display main interface software, T-Flash card, USB connection status and so on  
Top right display the battery, battery charge icons, current time, set time, Settings Menu, ESC button.


### 3.3 Use touch panel

Device equipped with a 4.3 " touch screen. Following the main touch screen area is described, and describes some of the tips for how to use the touch screen.


No matter which interface you are on the screen, can go back to main screen through pressing the soft key  on the upper left corner of the main screen.

【Attention】 The main screen soft key  functions as the machine back key .

In different applications, by tapping the back soft key  on the upper right corner on the touch screen, you can return to its interface on the up floor.

In different applications, by tapping the menu key  on the upper right corner of touch screen, the screen will appear the operation setting interface as follows,

【Attention】 : The main screen soft key  functions as the machine menu .






In the main interface, you can touch the icon to open the APPs

In different browser (file, music, video, pictures), You shift and drag the scroll bar, so that the file list can up or down to roll.

## 4. Equipment basic set

Setting: Click setting icon , enter setting interface





#### 4.1 Sounds, Notification Display and Brightness Setting.



Sound settings: Adjust media playback volume, and change the feedback sounds.

Auto-rotate screen: When this option be selected, the screen will rollover with you holding direction, horizontal to Vertical, 4 side direction.

Animation: Open or close the windows animation.


Brightness: Adjust the Screen brightness. You can draw the button left to lower and right to higher.

Screen timeout: Automatic shut off the display to saving the power. Choose one number for how long enter saving mode.



#### 4.2 Application

Manage application




Unknown sources: Click "Unknown Sources", then click "OK"

Manage application: manager and uninstall Application

【Attention】: When you Firmware Upgrade, please close the USB connect


How to uninstall the applications?

1. enter "setting">"Application">"Manage application" And then there will be installed the program list
2. Click you the icons want to uninstall, will enter the following interface
3. Click Uninstall, then you can delete the application




#### 4.3 Privacy

Factory data reset



#### 4.4 Storage


Remove TF card, can view of the available storage space



【Attention】 : please touch option "delete SD card", so that can safety to Remove SD card

#### 4.6. Language & keyboard

Setting: (Language), text input and automatic error correction options;



Select Language: 14 kind of national languages are available

Remark: Android system can support 54 kind of language, now menu interface just support 14 kinds of language,

Android keyboard: Android keyboard setting

Sound on Key-press


Auto- calibration

Show suggestions: Display suggested words while typing


Auto-complete: Spacebar and punctuation automatically insert highlighted word

#### 4.7. Date & time setting

Set date, set time, Select time zone and select date format



#### 4.8 Touch calibration



Please one by one to click the middle point in the red round point on the touch screen to finish touch screen calibration.

#### 4.9 USB Mode Select

Choose USB work pattern: OTG/HOST/SLAVE.....

#### 4.10 About device



### 5. Apps Install and manage

#### 5.1 App installer

This Tablet can support Android APP in market by third party, most Apps can install in the network, can copy to NAND FLASH or SD card.

Click App installer icon, will appear Install, manage, Exit options.

Install: Click install, enter APK install interface

Manage: click manage, enter third party interface

Uninstall: Click the installed APK to remove.

### 6. Problem solution

#### Device can't to open

1. Check the battery power
2. Connect adaptor first, then check again
3. After charging then can't to open, please contact with the supplier

After startup the screen or the opening picture has been appear, the device appear shutdown

1. Power is not enough, please charge

#### Headset can't hear the voice

1. Please check the volume whether set to 0
2. Check the music file whether damaged. Try playing other music, if the file have damaged may lead to serious noise or hop sounds.

#### Can copy file or paly music and so on

1. Please check between computer and device is correct connection
2. check the memory storage space is already full
3. check the USB cable is good or not
4. USB connection is disconnected

### 7. basic function

#### Hardware

Size: (length\* wide\*thick) 112\*76\*12.8mm

CPU processor speed: 500MHZ

Memory: 4G-16G

RAM: 256 MB

TF card: 128M-16G

Display screen: 4.3"(Capacitive multi-touch) TFT resistive touch

Resolution: 480\*272

Battery and capacity: rechargeable Built-in type polymer battery, 1000mAh

USB: USB 2.0 OTG

G-sensor: 3D

Record: built-in microphone

Operation System: Android 2.3

Video: MKV (H.264HP). AVI. RM RMVB. FLV. MPEG-1/2

Music: MP3.WMA.APE.FLAC.AAC.AC3.WAV

Pictures: JPEG. BMP. PNG.TIF