

# Manual MP4 Watch

## Foreword

Thank you for using our digital MP4 watch player. To enable you to operate the unit as soon as skilled, we were equipped with a detailed user manual, which you can get the product introduction, usage, system settings, and safety precautions in all aspects of knowledge. In the use of your digital product, please be sure to carefully read all the information distribution in order to help you to better use the product's features.

In the preparation of this manual we are very careful and rigorous, and that the manual provided information is correct and reliable, but inevitably there will be errors and omissions, please bear with more and look forward to your correction. Information in this manual is subject to change without notice. If you use the product found in the process you can not resolve the problem, please call our hotline or visit our website for the latest product information.

## Notes:

This section is for users of the proper use of players, to ensure good performance and set the player, please carefully read and follow.

- λ Do not seriously impact the host.
- λ Do not contact with benzene, thinner and other chemicals.
- λ Do not go near a strong magnetic field, electric field.
- λ Avoid direct sunlight or heating appliances.
- λ Do not disassemble, repair, alteration.
- λ Cycling, driving cars and motorcycles, do not use the player in order to avoid danger.
- λ Do not listen to a larger volume, so as to avoid adverse effects on hearing.
- λ Packaging waste, batteries, used electronic products, classified properly.

## Basic functions

- 1, the music player: supports WMA, WAV, MP3 and other players.
- 2, sound recording support: support FM, MIC recording. Format support WAV.
- 3, Photo support: JPEG, BMP, GIF format browsing
- 4, Video playback support: AMV, AVI (need conversion tool to convert, but on the PC using the ordinary tools avi player to play) format video playback.
- 5, FM Radio support.
- 6, The time display and calendar support

## Key features

1. **M** key (MENU): Menu menu button, press the function M: pop-up menu (short press on the main interface shows the clock) Press: back to the main interface.
2. **PREV** button (PREV): Select the previous option or file.
3. **NEXT** button (NEXT): select the next option or file.
4. **PLAY** button (PLAY): Power / Play / Stop button, Enter key

## Off

Press **PLAY** button to switch to display the clock, press again to enter boot interface

Note: When the player and PC connectivity or charging, this function is invalid.

## Low battery

When the battery power appears low, the player will be prompted to the screen, and then automatically shut down into standby mode, do not restart at this time, please charge.

## System Configuration

Operating System: Windows XP & Vista/2K/ME/98 (need to install driver) / Mac OS 10

CPU: at least Pentium-133MHz

Memory: At least 32MB

Free hard disk space: at least 100MB

Video Card: 640 \* 480 above model, at least High Color (16 bit)

USB port


CD-ROM drive

And PC connectivity


In the boot state, with the supplied USB cable to connect PC with the player, PC will be prompted to select the Removable Disk window appears. Select the appropriate folder to copy files to each other.

## Music

Select music applications, the **M** key to enter the music player interface



## Music player interface



Press **M** the switch between music playback and stop by and compared with the **PREV** previous file or **NEXT** next file. You can press **FF** fast forward and **REW** rewind.


Play modes: Normal playback display **M**

## Menu Options

1. The music stops playing status, press the M, the system enters a sub menu, menu options include: volume control, card catalog, delete files, delete all, exit.



2. In the state of music is playing, press the M, the system into two sub-menus, menu options include: volume control, loop mode, EQ mode, video settings and exit.



If you press M, to exit the main menu

3. Press and to select the Browse menu. Press M to open options, or return to the upper screen, press to confirm the selection (with other applications.)

## Sub-menu One

Card catalog: Display card disk all the files. Press M to enter the card catalog to choose lower-level subdirectories. Root storage card root directory file. Record audio files stored in the default folder.

Delete files: Delete files under the current directory, press M to enter the file list, press enter delete the file interface, select the check

Consumer deleted or OK to delete, then confirm the selection.

Delete all: delete all files under the current directory. Operating Ibd.

## Sub Menu Two

Cycle Mode: Press M to confirm the selection

Cycle Mode	Logo	Description
Normal mode		Order of play all the files
Repeat		Loop current track
List of Play		Order of play the current directory files.
Directory recycling		Loop current directory files.

Full Cycle		Loop all the files.
Full Cycle		Shuffle files in the directory.
Browse Play		Browse play the file, each track Yul 10 seconds.

EQ Mode: Select the desired audio mode: natural, rock, pop, classical, soft, jazz, heavy bass

Icon corresponding to a variety of EQ modes

Nature	
Rock	
Pop	
Classical	
Soft	
Jazz	
Bass	
SRS WOW	

## Repeat setting

1. Repeat mode

①. Select the repeat mode option, the system will return to music player interface, LCD sign on the upper left corner to increase repeat that enter the repeat function. At this point A (repeat start point) is blinking. Press, confirm that the starting point selected after the current time for the repeat, B (repeat end point) starts flashing. Then, to confirm the selection end time. The AB repeat set.

②. The system will set the time interval between repeat number and repeat begin repeat.


③. Press M to exit repeat music player interface, the interface returns.

2. Repeat times: Repeat times and settings by :1-10. Recognized by M to return music player interface.


3. Repeat interval: Set the minimum time between two repeat interval of 10 seconds.

1- optional. Operation with the repeat times.

Movie




1. After entering the following interface can be seen, the interface description may refer to music player interface. Press OK to enter the video playback
2. Continuous playback breakpoint




## Menu Options

Stop mode, press M to access the menu options. Menu options include: volume control, card catalog, delete files, delete all, circulation patterns and exit. Functions and operations and apply the same music.

## Recording



## Recording Interface



Press **▶** start / pause / continue recording again. Press **M** button to save the current recording, and ready to start a new recording. Press **M**, the system will automatically save the current recording, and return the main interface.

## Menu Options

When the suspension of the process, the emergence of low signal, the system will automatically save the recording, and return to the recording interface

When the disk is full, the system will prompt "Space Man!"

Press M to access the menu options. Menu options include: card catalog, recording the type, AVR level adjustment, AVR mode

Card Catalog: View and select the current audio file stored path information. Save the selection and press M to return.

Recording type: WAV music recording, type 32K/64K/128K/256K bit rate.

AVR mode: Normal mode and AVR mode. AVR mode supports voice functions, when the external source volume is very small and for some time, go to pause recording mode, the volume threshold above to return to continue recording

AVR level adjustment: adjust the player's sensitivity to external sound source, 1-10, the greater the value, the sensitivity is smaller. The default is 5.

## Radio mode



Manual Tuning: Press **◀** and **▶** the Radio fine-tuning. Press **◀** or **▶** to automatically search for the next or a radio, for listening. Or stop and then automatically search.

Breakpoint play: FM state will be saved after exit and re-enter, continue to play out the last time when the radio broadcast.

## Menu Options

Volume Adjustment: adjust the volume.

Save Radio: Save the current station.

Radio recording: Select the radio recording, the system interface for recording to recording. After recording the same operation and recording applications.

Remove the radio: a radio program from the saved to remove the current station.

Delete all: to save the radio program has been deleted.

Auto Scan: Select this option, press **▶** OK to return to radio interface to start automatic search for stations. When the search program, the system automatically save the station, and in the interface display 01. Continue the search, press the number then click Save. Auto search stop the search after the 30 channels, such as less than 30 channels will automatically search for the second time, stop the search. Press M to stop during the search. Can be saved by switching between the radio listening.

Common band: band range: China / United States band; 87MHz-108MHz.

Japanese band: frequency range: 76MHz ~ 90MHz.

## Picture viewing



Browse **▶** button to enter the selected picture, press the M key to

exit. Press **◀/▶** front view images.

## Menu Options


Sub-menu items: the card catalog, play settings, delete files, delete all, exit. In addition to playback settings, other menu items functions and operations the same as the previous application.

## Play Set

Manual Play: the need to manually play each picture, press **◀** or **▶** to view a picture before or after one.

Auto play: Go after the adjustable time interval automatically play (2-10s), is recognized by M exit

## Text Reading



Press **▶** button to do the text reading, press M exit. Press **◀/▶** to read forward or next.

## Menu Option

Sub-menu items: the card catalog, play settings, delete files, delete all, exit.


Reading e-books, press the M button appears Bookmarks menu item: **Bookmark options**: View current e-book bookmark, choose Bookmark from the bookmark after the e-book to start playing.

**Bookmark Delete**: delete the current e-book bookmarks.

**Bookmark added**: save the current progress of the play to the bookmarks list, for each e-book files up to 16 bookmarks.

**Exit**: return reading the book

## System Settings



1. System Time: Press PLAY date when the choice to switch between minutes and seconds, press **◀** or **▶** to adjust the value, press M to save the settings.

2. Backlight time: In this time, if no button operation, the backlight is turned off. Setting range: 0 ~ 50 seconds, set the step size: 5 seconds. Interface in the following five black mode invalid: Picture display interface, video interface, USB interface, on-line equipment, the lyrics play interface. In the plug UHOST, card; switching function automatically turns the backlight.

3. Save electricity mode: setting no operating shutdown time, range: 0 to 60 seconds, step length: 10 seconds, save electricity patterns in addition to other than the USB online modes are valid.

4. Firmware Version: Display firmware version information.

5. Storage capacity: If the card, the display card's storage capacity and spare capacity.

## 6. Firmware upgrade

The player offers upgrade tools to upgrade the firmware card or repair the player's firmware.

① download the latest version of the firmware.

② the card through the reader and the PC's USB port connection, be sure to connect properly, and to ensure that no other removable disk with the connected PC.

③ run card production firmware writing tool.

First select the correct firmware, and then start at the point, the cure to the card firmware. And so complete. Then the card is inserted into a small machine, and now this catalog (firmware upgrade) to upgrade. The upgrade is complete, a small machine automatically restarts. The end of the upgrade

7. Pour screen Settings (optional)


According to open this function screen can be induced to gravity 360 degrees, such as playing pour screen when music to jilt song can be before or next one.

8. Exit: return system setting main interface.

## Calendar



Press **▶** into the calendar, short press **◀** or **▶** earthshaking here before, long press **◀** or **▶** monthly view, then, M exit. Only have a calendar display in Simplified Chinese



## Troubleshooting

Media Player does not work or LCD does not display content

- Check the battery power.

Power button does not work

The battery is depleted.

If in the course of death, or does not boot keys can RESER

RESER (RESET button inside the headphone jack)

Unable to download file

- Check the computer's USB port and USB cable between the connection.

- Format the media player.

# MP4 手表说明书

## 前言

感谢您使用本公司数码 MP4 手表播放器。

为了使您能尽快熟练的操作本机,我们随机配备了内容详实用户手册,您可以从中获取有关产品介绍,使用方法,系统设置及安全注意事项等各方面的知识。

在使用您的数码产品前,请务必仔细阅读随机配送的所有手册,以便帮助您能更好的使用该产品的各项功能。

在编写本手册时我们非常小心和严谨,并认为手册中的所有的信息是正确可靠的,然而难免会有错误和疏漏之处,请您谅解并热切欢迎您的指正。

本手册的信息资料如有变更,恕不另行通知。如果您在产品的使用过程中发现有不能解决的问题,请拨打我们的热线电话或访问本公司查询最新产品信息。

## 注意事项

内容是为了使用者正确使用播放器,确保播放器性能良好而设,请认真阅读并遵守。

切勿严重撞击主机。

切勿接触苯、稀释剂等化学物品。

不要靠近强磁场、电场。

请避开直射光线或发热器具。

切勿自行拆卸、修理、改造。

骑车、驾驶汽车及摩托车时,请勿使用播放器,以免造成危险。

切勿以较大音量收听,以免对听力造成不良影响。

废弃包装、电池、旧电子产品,请分类妥善处理。

## 本功能

1. 音乐播放:支持 WMA、WAV、MP3 等播放。
2. 录音支持:支持 FM、MIC 录音,格式支持 WAV。
3. 图片浏览支持:支持 JPEG、BMP、GIF 格式的浏览
4. 视频播放支持:支持 AMV、AVI (需要通过转换工具转换,但可以在 PC 上采用普通的 avi 播放工具进行播放)格式的视频播放。
5. FM Radio 支持。
6. 时间显示及日历支持。

## 键功能

MENU (MENU): Menu 菜单键,其功能为短按 M,弹出菜单,(在长按时短按显示时钟)长按:退回主界面。

PREV (PREV): 选择前一个选项或文件。

NEXT (NEXT): 选择下一个选项或文件。

PLAY (PLAY): 开机/播放/停止键,确认键。

## 开关机

长按 PLAY 键止/关机,显示时钟,再次短按进入开机界面

注:当播放器与 PC 连接或者充电时,此功能无效。

## 电池低电

当电池出现低电后,播放器会出现提示画面,然后自动关机进入待机状态,此时不要重新开机,请及时充电。

## 系统配置

操作系统: Windows XP/Vista/2K/ME/98(需要安装驱动)/Mac OS 10

CPU: 至少为 Pentium-133MHz

内存: 至少 32MB

硬盘空间: 至少为 100MB

视频卡: 640\*480 以上模式,至少为增强色(16 位)

USB 端口

光盘驱动器

## 与 PC 连接

在开机状态,用随机提供的 USB 线连接 PC 与本播放器,PC 会提示出现可移动磁盘选择窗口,选择相应的文件夹互相拷贝文件即可。

## 音乐

选择音乐应用,按 M 键进入音乐播放界面。



## 音乐播放界面




按 M 在音乐播放和停止间切换,按 PREV 和 NEXT 为前一个文件或下一个文件。长按 PREV 和 NEXT 可快速倒退。


播放模式: 普通播放显示标志。

## 菜单选项

1. 在音乐停止播放状态下按 M,系统进入子菜单一,菜单选项包括: 插卡目录,删除文件,删除全部,退出。



2. 在音乐正在播放状态下按 M,系统进入子菜单二,菜单选项包括: 音量调节,循环模式,EQ 模式,复读设定,退出。



若长按 M,可退出主菜单界面

3. 按 PREV 和 NEXT 选择浏览菜单,按 M 打开选项,或者返回上层界面,按 M 确认选择(其它应用同)。

## 子菜单一

插卡目录: 显示插卡盘所有文件,按 M 进入插卡目录下级子目录进行选择。ROOT 存放插卡盘根目录文件。录音文件缺省存放在 record 文件夹下。

删除文件: 删除当前目录下文件,按 M 进入文件列表,短按 M 进入删除文件界面,选择取消删除或者确定删除,再按 M 确认选择。

删除全部: 删除当前目录下的全部文件。操作同上。

## 子菜单二

循环模式: 按 M 确认选择。

循环模式	图标	说明
普通模式	[Icon]	顺序播放全部文件。
单曲循环	[Icon]	循环播放当前曲目。
目录播放	[Icon]	顺序播放当前目录文件。
目录循环	[Icon]	循环播放当前目录文件。
全部循环	[Icon]	循环播放全部文件。
随机播放	[Icon]	随机播放目录中的文件。
浏览播放	[Icon]	浏览播放文件,每首曲目预览 10 秒。

EQ 模式: 选择想要的音效模式: 自然、摇滚、流行、古典、柔和、爵士、重低音

各种 EQ 模式对应图标为:



## 复读设定

### 1. 复读模式

①. 选中复读模式选项后,系统会返回音乐播放界面,此时 LCD 左上角会增加复读标志,表示进入复读功能。此时 A (复读起始点) 在闪烁。按 M 后,确认选择当前时间为复读起始点后, B (复读结束点) 开始闪烁。再按 M,确认选择结束时间。则 AB 复读设置完成。

②. 系统会根据设定的复读次数及复读间隔时间开始复读。

③. 按 M 退出复读界面返回音乐播放界面。

2. 复读次数: 按 M 和 M 设置复读次数,1-10。按 M 确认返回音乐播放界面。


3. 复读间隔: 设置两次复读之间的最小时间间隔,1-10 秒可选。操作同复读次数。

## 电影




1. 进入后可见以下界面,界面说明可参考音乐播放界面。按 M 确认进入视频播放。

2. 支持断点续播。



## 菜单选项

停止状态下,按 M 进入菜单选项。菜单选项包括: 音量调节,插卡目录,删除文件,删除全部,循环模式和退出。功能和操作方法与音乐应用相同。



开始/暂停/重新继续录音。按 **M** 键保存当前录音，并准备开始新的。长按 **M**，系统会自动保存当前录音，并返回主界面。

### 菜单选项

暂停过程中，出现低电信号时，系统会自动保存录音，并返回录音界面。空间已满时，系统会提示“空间满！”

进入菜单选项。菜单选项包括：**插卡目录**、**录音类型**、**AVR 电平**、**AVR 模式**


**目录**：查看和选择当前录音文件的存放路径信息，选择后长按 **M** 并返回。

**类型**：WAV 音乐录音，类型为 **32K/64K/128K/256K** 比特率。


**模式**：普通模式和 **AVR 模式**。AVR 模式支持声控功能，当外界音量非常小且持续一段时间时，进入暂停录音模式，音量恢复到门限上时继续录音。

**电平调节**：调节播放器对外界声源的灵敏度，**1-10** 级，数值越大，度越小。默认为 **5**。

### 收音模式



### 收音机界面



手动搜台：按 **◀▶** 和 **▶▶** 进行电台微调。长按 **◀▶** 或 **▶▶**，可自动搜索上一个或下一个电台，进行收听。再按 **◀▶** 或 **▶▶** 停止自动搜索。断点续播：**FM** 退出后状态将被保存，重新进入时，继续播放上一次退出时播放的电台。

### 菜单选项

**音量调节**：调节音量。

**保存电台**：保存当前电台。

**电台录音**：选择**电台录音**后，系统转到录音功能界面准备录音。此后的录音操作与录音应用相同。

**删除电台**：从已保存的电台节目中删除当前电台。


**删除全部**：将已保存的电台节目全部删除。

**自动搜台**：选择此项后，按 **▶▶** 确认返回收音机功能界面开始自动搜索电台。当搜索到节目后，系统自动保存电台，并在界面上显示 **01**。继续搜索，并按编号依次保存。自动搜索 **30** 个频道后停止搜索，如不足 **30** 个频道则会自动搜索第二遍后，停止搜索。其间按 **M** 可停止搜索。按 **▶▶** 可在已保存的电台间切换收听。

**普通频段**：频段范围：中国 / 美国波段：**87MHz-108MHz**。

**日本频段**：频段范围：**76MHz - 90MHz**。

### 图片观看



按 **▶▶** 键进入浏览选择的图片，按 **M** 键退出。按 **◀▶** 前后浏览图片。

### 菜单选项

子菜单项：**插卡目录**、**播放设定**、**删除文件**、**删除全部**、**退出**。除播放设定外，其它菜单项功能和操作方法与前面的应用相同。

### 播放设定

**手动播放**：需手动播放每一张图片，按 **◀▶** 查看前一帧或后一帧图片。

**自动播放**：进入后，可调整自动播放的时间间隔 (**2-10s**)，按 **M** 确认退出。

### 文本阅读



按 **▶▶** 键进入浏览选择的电子书，再按 **M** 键退出。按 **◀▶** 前后浏览电子书。

### 菜单选项

子菜单项：**插卡目录**、**播放设定**、**删除文件**、**删除全部**、**退出**。

阅读电子书时，按 **M** 键出现书签菜单：

**书签选择**：浏览当前电子书的书签，选择书签后电子书将从书签位置开始播放。

**书签删除**：删除当前电子书的书签。

**书签增加**：将当前的播放进度保存到书签列表，每个电子书文件最多支持 **16** 个书签。

**退出**：返回阅读界面。

### 系统设置



**1. 系统时间**：按 **PLAY** 在选择年月日时分秒间切换，按 **◀▶** 或 **▶▶** 调整数值，按 **M** 保存设置。

**2. 背光时间**：在该时间内，若无按键操作，则关掉背光。设置范围：**0-50** 秒，设置步长：**5** 秒。在以下 **5** 个界面中变黑模式设置无效：图片设置界面、视频播放界面、USB 联机设备界面、歌词播放界面。在插拔 UHOST、卡；切换功能自动开启背光。

**3. 省电模式**：设置无操作关机时间，范围：**0-60** 秒，步长：**10** 秒，省电模式在除 USB 联机外的其他模式下均有效。

**4. 固件版本**：显示固件版本信息。

**5. 存储容量**：如有插卡，则显示卡的存储容量和空闲容量。

### 6. 固件升级

本播放器提供固件卡升级工具来升级或修复播放器中的固件。

① 下载最新版本的固件。

② 将卡通过读卡器与 PC 的 USB 端口连接，确定连接正常，并保证没

有其他可移动磁盘同连接在 PC 上。

③ 运行卡量产固件写入工具。先选择正确固件，然后在点开始，把固件固化到卡。等完成。再将卡插入小机，现在本目录 (**固件升级**) 进行升级。升级完成，小机自动重启。整个升级工作结束。

### 7. 倒屏设置 (可选)

打开这个功能屏幕可以根据重力感应来进行 **360** 度倒屏，如在播放音乐时可以切换到下一首或上一首。

**8. 退出**：退回系统设置主界面。

### 日历



按 **▶▶** 进入日历，按 **◀▶** 或 **▶▶** 前后翻页浏览，长按 **◀▶** 或 **▶▶** 按月浏览，再按 **▶▶**，**M** 退出。只有在简体中文才有农历显示。



### 疑难解答

**媒体播放器不工作或 LCD 不显示内容**

-检查电池电量。

**开机键不起作用**

-电池电量已耗尽。

-在使用过程中如有死，或不开机可以按 **RESER** 键进行 **RESER (RESET)** 键在耳机孔里面)

**无法下载文件**

-检查电脑的 USB 端口与 USB 电缆间的连接。

-格式化媒体播放器。