





Schematic diagram of how to install the new detachable iron poles

First: Install the poles



Put the DC cable through the thread side of the pole.


Point B in the picture is the nut side. Match the thread (A) into the nut.

Do the same steps to the other pole.


Note: 1. We apply two kinds diameter poles: $\phi 10\text{mm}$ / $\phi 12\text{mm}$. Choose the correct one according to the cars.

2. One of the two poles has grooves. Pay attention to match it to the correct side of car seat.

Second: Level the poles



Do as the direction in the picture, one hand to fix the machine (C), the other one to adjust the poles to be flat (D).




Set the poles to the middle of the square hole.

Third: Adjust the distance



To exert force in the arrow directions (E and F) at the same time. The place (G) is auxiliary. Don't use forced strength to avoid breaking poles or can not move the poles.

Fourth: Install in the car



Put the cable through the pole.





Adjust the distance of the poles to fit the car seats.

Fifth: Wrong installation



To exert force in wrong direction



Not level the two poles at the same time.

HEADREST WITH PILLOW



USER'S MANUAL

Compatible with DVD/VCD/CD/MP4/MP3/CD-RW/GPS/GAME
Enjoyable in car entertainment

Home theater Digital technology Perfect enjoyment



USER'S MANUAL

Please read the manual carefully before using and keep it well for your future reference.
Important instruction for safety:

▲ Precautions:

For your safety, do not turn on, watch or operate the unit while driving. In some countries and regions, it may be against the laws.

The product is comprised of many precision electronic components. Self-renovation or disassembling may cause malfunction to the device.

Note:

To reduce the risk of fire or electric shock, do not expose this product to rain or moisture. High voltage inside! Do not open or dismantle the unit. Do not repair yourself. Refer servicing to qualified personnel.

The product is a laser product. Make sure to read instruction manual before operating. Do not try to open the covers to avoid direct laser radiation. When the cover of the unit is opened or the interlocking system gets unlocked, the Laser light can be visible. Direct vision of Laser beam is hazardous to your eyes.

In order to prolong the life of the unit which has a large scale of integrate circuits and precision pick-up device, Frequent Turn On/Off might damage the unit. More than 5 seconds interval is required.

Note:

LCD may have a few color dots, which is common for the matrix display technology, and doesn't indicate defects or faults.

Content

I Features.....	4
II Disc for playback.....	4
III Precaution.....	6
IV Brief Instruction.....	7
➢ Accessories.....	8
➢ Remote controller operation	9
➢ Installation and connection Method.....	11
➢ Sketch map of the player.....	12
➢ Remote controller.....	13
V Basic Operation.....	15
VI Function and Setup.....	15
➢ Menu/PBC.....	15
➢ Title/Return.....	16
➢ Display.....	18
➢ Search.....	19
➢ Subtitle.....	19
➢ Audio.....	20
➢ Angle.....	20
➢ Zoom.....	20
➢ Repeat.....	20

USER'S MANUAL

Compatible with DVD/VCD/CD/MP4/MP3/CD-R/CD-RW/GPS/GAME




>Direction Buttons.....	21
>SD/USB.....	21
>Mute.....	21
>Stop.....	21
>Video Shift.....	22
>Console.....	22
VII Setup.....	29
VIII MP3.....	30
IX JPEG.....	30
X Trouble Shooting.....	33
XI Technical Specification.....	33

I、Features

- ☑ Support Game Function.
- ☑ Ease of Installation, Non hazardous design, Cigarette Lighting outfit.
- ☑ Adjusting steel tube space between 130mm to 180mm, To meet installing requirement of seat, diameter of steel tube can be replacing from 10mm to 12mm
- ☑ The display unit has built in DVD player.
- ☑ Built in wireless FM Audio Transmitter.
- ☑ Input Channels: AV Input channels and compatible to DVB-T
- ☑ AV Output channels, Stereo Infrared Transmitter. Wireless infrared headphone (optional).
- ☑ Offer earphone socket, General earphone (optional)

II Discs for playback

● Discs compatible with

Type	Icon	Content	Size
DVD		Video & Audio (dynamic image)	12cm/8cm
VCD		Video & Audio (dynamic image)	12cm/8cm
CD		Audio	12cm/8cm
MP3	MP3	Audio	12cm/8cm
MP4	MP4	Video & Audio (dynamic image)	12cm/8cm

Disc-related terms

- **Title (DVD Only)**
The main film content or accompanying feature content or music album. Each title is assigned a title reference number enabling you to locate it easily.
- **Chapter (DVD Only)**
Sections of a picture or a musical piece that are smaller than titles. A title is composed of one or several chapters. Each chapter is assigned a chapter number, enabling you to locate the chapter you want. Depending on the disc, no chapters may be recorded.
- **Track (Video CD and audio CD only)**
Sections of a picture or a musical piece on a video CD or an audio CD. Each track is assigned a track number, enabling you to locate the track you want.

Diagram of DVD disc





Diagram of VCD/CD



III Precaution

• Safety

- ✧ Please check the voltage in the car as the machine required before playing.
- ✧ Please hold the plug tightly, and avoid dragging the power cords when insert the plug in or pull out it from the jack.
- ✧ This machine has laser system which is harmful for the eyes, please do not open the crust. Any repair you need, it is necessary to ask for the specialized personnel.

• Placement

- ✧ The storage temperature ranges from -30°C to -75°C , operating temperature ranges from -10°C to 55°C .
- ✧ Please keep the pick-up clean and away the dust. If so, the cleaning disc can help deal with this problem. For detailed operation instructions for cleaning the pick-up, you can consult the user's manual of pick-up cleaning disc.
- ✧ Do not expose this unit to rain or moisture. Avoid dropping or impact to the unit.

• Vapor on convex mirror and Trouble shooting

- ✧ There's liquid on convex mirror in following cases, But it is normal phenomena. Due to sudden change in Temperature and car air-conditioner is turned ON their will be a vapor formation on convex mirror. To de-vaporize it please takeout the disc and power ON the unit about one hour.

- ✧ Please wipe the machine with soft and dry cloth dipped optional washing liquor in case of scratching the screen.

• Note

Handling discs:

Do not touch the playback side of the disc. Hold the disc by the edges so that fingerprints

will not get on the surface.
Do not stick paper or tape on the disc.

Storing discs:

After playing, store the disc in its case.
Do not expose the disc to direct sunlight or sources of heat, or leave it in a parked car exposed to direct sunlight, as there may be a considerable temperature increase inside the car.

Cleaning discs:

Fingerprints and dust on the disc can cause poor picture quality and sound distortion. Before playing, clean the disc with a clean cloth. Wipe the disc from the center out. Do not use strong solvents such as alcohol, benzine, thinner.



IV Brief Instructions

>Checking the accessories

Please check if all the accessories are here as the list below before use.


Cigarette Lighting cable	1
Power cable	1
Audio/Video input cable	1
12mm steel tube	2
Earphone	1
Remote controller	1
User's manual	1
Game handle	2(optional)

➤ **Instructions for Remote control (shown as pictures)**

- (1) Press the catch and at the time pull out the battery tray. Insert the battery, type CR2025, battery with the stamped (+) mark facing upward. Insert the battery tray into the remote control.
- (2) Direct the remote controller to infrared receiver window of the machine within 60° and 4 meters, without any barriers between them.
- (3) Commonly, the life-span of the batteries is about one year, always replace the old set of new batteries.
- (4) Please take out the battery when not using the remote controller for a long time.
- (5) Please pull out the separation film before when using the remote controller.

▲ **Warning:**

Store the battery where children cannot reach. Do not recharge, short, disassemble or heat the battery or dispose it in a fire.




➤ Installation and connection Method

Please make sure of suitability of the configuration and the size. Using the suitable accessories and tools in installation or disassembling

Installation Methods:

- Step 1 Unloading the original pillow
- Step 2 Selecting right installation steel tube matches with the original frame while installing the monitor with DVD player, then adjusting the steel tube to right position
- Step 3 Treading the power cord and the A&V cord through the steel tubes on the backside of the seat
- Step 4 Fixing the pillow and Adjusting freely by driver's requirements.




Warmhearted prompt: Adjusted steel pipe spacing, the steel pipe root and the rearpart must simultaneously the stress also dynamics and the direction must maintain consistently.

The degree of opening the bin gate don't surpass 85 degree.

>connection Method


Connecting the Cigarette Lighting cable with car power cord on the left side or the right side of the car separately.

Connecting the player power cord with the car power cord when both a player and a monitor are installed in the car. The A&V system of DVB-T is compatible to A&V input socket of the DVD player.




Note: This machine is suitable to some type of the car not all the types.

Sketch map of the player



USER'S MANUAL

Compatible with DVD/VCD/CD/MP4/MP3/CD-R/CD-RW/GPS/GAME



Note: "Ø" will show on the screen when the button function is ineffective for different disc recording format

V Basic Operation

Make sure that you have correctly connected your unit as described earlier in this book. Turn on the power, and place the disc in.

1. press power button to turn ON (Power Indicator is OFF), display is ON and player will start loading the disc.
2. Press Open button to open cover, then put the disc in the tray and close the cover.

The player will play automatically and display the disc format on the screen.



Power




Open


3. While playing DVD discs, please select one item in DVD menu or title menu. While playing VCD2.0 or CD, this player plays one by one.
4. Press Direction Buttons or the Number Buttons to select the desired item, then press Enter or Play to start.
5. Press Pause to stop temporarily, press again Pause or Play to cancel pause. while playing DVD disc, press stop for memory stop, press Play for memory play, press Stop twice to stop playing.

Note: To stop playing DVD by pressing Stop for twice.

6. While DVD disc is playing, Press Fast Forward to play circularly, screen shows as following:



Press Fast Backward to play circularly, screen shows as following:



Press Play to shift to normal playing mode.

7. Slow
While DVD disc is playing, press Slow button, picture shows circularly, the screen shows as following:



While VCD disc is playing, press slow button to play circularly, the screen shows as following:



Note: Press Play to shift to normal playing mode

8. To select previous item or chapter by pressing Previous button, to select next item or chapter, press Next button.

Note: When a title on a disc has more than one chapter or a disc has more than one track, using chapter function can move to another desired chapter/track to play. If there is no Chapter/track on the disc, the above functions will be disabled automatically.

VI Functions Explanation

Menu/PBC

- (1) Press Menu/PBC to return to the main menu or the Title menu while playing DVD disc.
- (2) While playing VCD disc, Press Menu/PBC to turn PBC on or off. (Unfunctional in DVD disc playing)
- (3) Only return to the main menu to select one song in PBC-on mode.
- (4) Pressing Number buttons to select one song in PBC-off mode.

Title

- (1) While playing DVD disc, press Title to enter into title menu directly, select the desired item by pressing the Direction buttons or Number buttons.
- (2) While playing VCD2.0, press Title to return to previous menu; however this function is disabled in PBC-off mode (Only for functional disc).

➤ Display

User can check the elapsed time or remaining time of current title and chapter by pressing Display, Press Display continuously, the screen shows as below:

(1) Playing DVD disc

Press Display for the first time, screen shows the elapsed time of current title.

Title 03/10Chapter01/04 0:06:39

Press Display for the second time, screen shows the remaining time of current title.

Title 03/10Chapter01/04 0:37:34

Press Display for the third time, screen shows the elapsed time of current chapter.

Title 03/10Chapter01/04 0:07:16

Press Display for the fourth time, screen shows the remaining time of current chapter.

Title 03/10Chapter01/04 0:03:27

Press Display for the fifth time to exit.

Playing VCD disc

In PBC ON mode

Press Display for the first time, screen shows the elapsed time.

Track01/01 01:27

Press Display for the second time, screen shows the remaining time.

Track01/01 44:13

Press Display for the third time to exit.

In PBC OFF mode

Press Display for the first time, screen shows the elapsed time of the current item.

Track01/01 00:06

Press Display for the second time, the screen shows the remaining time of the current item

Track01/01 45:04

Press Display for the third time, the screen shows the elapsed time of the entire disc.

Track01/01 00:25

Press Display for the fourth time, the screen shows the remaining time of the entire disc.

Track01/01 45:25

Press Display for the fifth time to exit.

➤ **Search**

Press Search, input a title, a chapter or a time, the player starts playing from the desired point to the end point.

Playing DVD disc:

(1) Search a title or a chapter

Press Search, screen shows as below:

Press Left or Right to select one title

For example: press Number button 3 to select title 3, select Chapter 1 by pressing Direction Buttons, the screen shows:

Title00/10 Chapter00/04

Title03/10 Chapter01/04

Compatible with DVD/VCD/CD/MP3/CD-R/CD-RW/GPS/GAME

(2) Search by time

Press Search, screen shows:

Title03/10 Time : :

Press Search, screen shows:

Title03/10 Time01:06:18

For example: Press Number button to input 0, 1, 0, 6, 1, 8, the player will play from the point at 01:06:18

Chapte01/04 Time : :

Press Search, screen shows:

(3) Playing VCD disc
Press Search to check the elapsed time for the entire disc, the item and the current item during VCD disc playing.
Press Number button to input a time, the player will play from the point you've selected.

➤ Subtitle

While playing DVD disc with multi-subtitles, choose the desired subtitle, it shows on the screen.
○ Will show on the screen when this feature is not available on the disc.

Note: This feature setting is valid only for the current disc. the subtitle language can be changed from DVD setting menu.

➤ Audio

There is multi-language feature while DVD disc is playing.

When playing discs with this function, you can select the desired voice by pressing Audio. The left audio, right audio, mixed sound and the stereo shows on the screen while playing VCD disc. You can select the desired one when playing story disc with dual languages. Note: This feature setting is valid only for the current disc which has multi-language settings.

➤ **Angle**

If the disc contains scenes recorded at different camera angles, you can change to a different camera angle during playback. Press ANGLE repeatedly during playback to select a desired angle. (Only for the functional disc)

- Will show on the screen when this function is not available on the disc.

➤ **Zoom**

In this mode, the dynamic or still picture can be zoomed in at most by 4 folds. Press Zoom for three times, the picture is zoomed in by 2x, 3x, 4x folds per order. And press Zoom again to return to the normal playing mode; The dynamic or still picture can be reduced in at most by 4 folds. The picture is reduced in by 1/2, 1/3, 1/4 folds per order. Press again to return to normal playing mode.

➤ **Repeat**

(1) While playing DVD disc, press Repeat for the first time to repeat playing one chapter, press Repeat for the second time to repeat playing one title, press Repeat for the third time to repeat playing the entire disc, and press Repeat to cancel.

(2) In PBC off mode:

While playing VCD disc, press Repeat for first time to repeat one song.
Press Repeat for the second time to repeat the entire disc.
Press Repeat for the third time to cancel.

➤ **Direction Buttons**

Press Direction Buttons to make free selection in title, content and setup menu easily.

➤ **SD/USB**

In the DVD mode, when press<SD/USB>button, the DVD mode can be switched to the SD/USB mode.

➤ **Mute**

Press Mute one or more to select mute on or mute off.

➤ **Stop**

Press STOP button to Stop playing; Press Play button again, continue to play.

➤ **MODE**

Press AV-Shift to shift from DVD-playing mode to AV-input, or AV-input to DVD-playing mode, when there is no signals, the screen will be blue.

➤ **CONSOLE**


Setting Items: volume, FM Transmitter, IR Transmitter, Brightness, Contrast, Saturation, Color, Sharpness, Rotation, Display Mode, Reset, etc.

USER'S MANUAL

When press <CONSOLE> button, the screen will display the setting items one by one.



Contrast
Brightness
Saturation
Hue
Sharpness



FM Freq (with multiple transmitting channels for selection)
IR Band



Display -H
Display -V
Language (with multiple languages for selection)
Reset

Notice:

The "Reset" item is only for brightness, contrast, saturation, color. The resetting value is the same as the standard reference.

Compatible with DVD/VCD/CD/MP4/MP3/CD-R/CD-RW/GPS/GAME

VII、Setup

• Setup

The setup page includes General Setup, Audio Setup, Video Setup, Password Setup, Preference Setup Page and Exit.

Setup page will show on the screen by pressing Setup.

Operating methods:

Press Setup to enter into Setup page,

Move up/down to select the desired item,

Move left/right to select the desired item,

Press Enter to confirm


To exit setup by pressing Setup again, or select Exit in setup menu (show as pictures):

1. Mark the current working menu — 5. Menu Bar

2. Menu topics — 6. Select the setting item you need

3. Selecting region — 7. Mark the Status when it is in



4. Status bar —



USER'S MANUAL

Compatible with DVD/VCD/CD/MP4/MP3/CD-R/CD-RW/GPS/GAME

- Menu: Show the current menu
- Menu Title
- Selection zone: Select the desired item to setup
- Menu: Showing the current menu.
- Mode: Show the current mode



- General Setup page
- (1) TV Display

Please operating by setup menu, and refer to the picture as following

Note:

If the aspect ratio is 4:3, it is able to show in 16:9.
The image will be compressed horizontally, if the DVD disc system is in 16:9.
Because low-quality or pirated discs will result in bad effect, Please play high quality disc for your pleasant enjoying.

- (2) Angle Mark
When Angel Mark is on, user can select a special angle for watching (only for discs with this function)
- (3) OSD Language
It is available for the user to select one language for both the entire setup menu and the OSD language.
- (4) Hidden Subtitle Selection
Select ON, while playing hidden subtitle disc, hidden subtitle display on screen.
Select OFF, while playing hidden subtitle disc, no hidden subtitle display on screen
- (5) Screen Saver
Screen saver is to protect the screen from aging and extending its life-span.
Screen Saver will be enabled while playing stops or the picture keeps unmoving for minutes.
- (6) HDCD
Can play the High Stream CD like this format.
- (7) Memory play setup
Disc will be played from the latest stop position in Memory-play-on mode.
- (8) Picture of switching on
Can snatch any picture when it is playing, and then take it as the picture of switching on.

• Volume setting page

According to the operating methods in the menu setting and the below picture, select the selecting itmes you need.


Volume setting: speaker setting.

SP. DIFsetting. equalizer setting. 3D proceeding. ect.

Press the ▲▼ for selecting the setting itme needed

Press the ◀▶ for selecting the setting the submenu.

Press the ENTER button for confirmation.



• Dolby setting page

According to the operating methods in the menu setting and the below picture, select the selecting itmes you need.

Dolby setting item: [Dual mono], [Dynamic], Enter into

[Dual mono].If select stereo, Left track. and it will output


the stereo signal. If select the left track, and it will output

the left track signal. If select the Right Track. and it will

output the right track signal. If select the Mixed track, and it will output the medial signals

that is mixed by the left and right track Enter into [Dynamic]. Set the items according to the scale instructions. The larger the compression rate of dynamic is, The difference will be

less between alt and bass. This item is only valid for the Dolby digital volume source.



USER'S MANUAL

Select DYNAMIC in DOLBY DIGITAL SETTING PAGE, pressing ENTER and using direction key ▲▼ to do setting. The setting is functional only for Dolby digital audio raw.

• 3D process setting




Enter in 3D process setting page, then do setting in REVERB MODE.

The REVERB MODE includes OFF, CONCERT, LIVING ROOM, HALL, BATHROOM, CAVE, ARENA, CHURCH.

• Video Setup

According to the operating methods in the menu setting and the below picture, select the selecting times you need.

Video setting item: sharpness, Brightness, Contrast, Picture of switching on. Press the ▲▼ for selecting the setting time needed. Press the ◀▶ for adjusting the range.




USER'S MANUAL

VII SETUP

According to the operating methods in the menu setting and the below picture, select the selecting itmes you need.

Notice: The main unit can enter into the original setting page only when it is in the situations of pause or stop.




(1) TV Type : Auto/PAL/NTSC is compatible.

(2) Voice

Please operate by setup menu.

Voice will be in English, French, Spanish, Chinese, Japanese, Korean, Russian and so on depending on the discs.





USER'S MANUAL

(3) Subtitle

Subtitle will be in English, French, Spanish, Chinese, Japanese, Korean, Russian, Thai and so on depending on the discs. User can either hide the subtitle or choose any subtitle language while playing DVD discs.

Note This function is valid to the discs which has multiple languages. Otherwise, only display recorded language on the disc.



(4) Selecting Language by Disc Menu

Disc has different languages such as French, Spanish, Chinese, Japanese, Korean, Russian, and so on, these languages can be played by this unit. And user can select any language from disc menu.

Note This function is valid to the discs which has multiple languages. Otherwise, only display recorded language on the disc.

(5) Age controlling

When playing the discs with lockedup function, you can choose the suitable controlling rage of age when according to the rage of discs and practical. The adult rage is the lowest one.



USER'S MANUAL

(6) Password Setup Page

The original password is 1369; please select Password to input yours. If the password is forgotten or mixed-up, please input 136900.

(7) Default

Select default to restore original factory setting.



VIII、MP3

- Basic Operation
 - MP3 can be played by List mode, Program mode and normal mode. Select one mode during stop. Press Repeat to play, repeat playing one song or play by list.
- Disc Playing
 - (1) Place the disc to the loader correctly, player begin to search the disc messages and enter into Normal Playing Mode.
 - (2) Move Direction Button or use the Number button to select the desired item in submenu, Press Play to start.
 - (3) Press Stop first, press Direction Button to select other submenu
 - Other Functions Mute, Vol control, previous/next functions can be controlled directly from unit while MP3 disc/Audio CD is playing.

IX、JPEG

This unit can play the Picture CD in JPEG format. JPEG is the most popular picture compressing format currently.

- Press Number Buttons to Select Pictures
 - (1) Place the disc in the loader correctly, and the player starts searching messages, signal shows on the screen.
 - (2) Press Number buttons to select the picture album
- Make selection by the disc menu
 - (1) Place the disc to the loader correctly; player starts searching messages, Main menu shows on the screen, select from NO.1 by Direction Button, press Play to confirm.
 - (2) Press Direction Buttons to select picture in current picture album, press Play to start
 - (3) Press Direction Buttons to select other pictures during stop.
 - (4) Return to previous menu by selecting File during stop. Then Press Play.

X、Trouble Shooting

Please consult the Trouble shooting sheet to deal with these problems when you are in trouble:

- No Sound or bad sound effect
Please check if cables are connected properly
Please check audio shift setup.
Please adjust the receiving frequency to harmonized with the transmitting frequency.

USER'S MANUAL

- No Picture

Check if cables are connected properly.

Video Input is not yet set up correctly.

The monitor is on or off.

- Poor picture

The color is not properly adjusted; please operate the remote controller to adjust it

The disc is scratched or spotted.

- The player does not work, or no disc

Insert the disc or not

Check the disc is placed up side down or not, place the disc with the playback sidedown

The disc is dirty. Clean the disc

The unit is moisture inside, take off the disc and power off unit for about one hour.

Disconnect the power cord and plug the power cord into the wall outlet securely again to reset unit.

- The remote control does not work properly

Check if remote control point to receiver or not.

The batteries in the remote control are exhausted. Replace the batteries with new ones.

- Note

Please contact with the dealer or approved service center help if the troubles can't be

solved by the methods offered.

There is an obstacle in the path of the remote control and this unit. Remove the obstacle.

XI Technical Specifications

Panel	TFT-LCD
Screen Size	7inch (16:9)
Pixel	480×RGB × 234
Temperature	Operation temperature -10°C-55°C Storage temperature -30°C-75°C
Backlight	High brightness LED backlight
Brightness	350cd/m ²
Color System	PAL/NTSC/Automatically
Discs	DVD、VCD、CD、MP4、MP3、CD-R、CD-RW、DVD-R、DVD-RW、DVCD
Input Socket	SD、USB、Game jack
S/N	≥90dB
Isolation	≥65dB
Audio Input/Output	1.6V±20%
Video Input/Output	1Vp_p±20%
Power supply	DC12V
Power consumption	≤12W
Built-in FM transmitter and IR transmitter	

Your attention please:

The design and specifications are subject to change without notice



HEADREST WITH PILLOW

Compatible with DVD/VCD/CD/MP4/MP3/CD-RW/GPS/GAME

Enjoyable in car entertainment