




Panel sketch 04 □




- 1 Power button
- 2 Mic
- 3 Controller signal receiver
- 4 Tuning/track selection
- 5 Volume up/down
- 6 Mode switch
- 7 Screen
- 8 Mute
- 9 GPS/P. N switch
- 10 Eject/angles
- 11 Reset button
- 12 USB port
- 13 SD card slot
- 14 GPS card slot
- 15 Disc entrance



Panel sketch 05 □ 7.0 inch touch button panel



- | | |
|-------------------------------------|---------------------------|
| 1 Mic | 7 Aux input |
| 2 Power on/off | 8 Eject |
| 3 Controller signal receiver | 9 Slide up/down |
| 4 Screen | 10 Volume up/down |
| 5 USB port | 11 Mute/GPS switch |
| 6 Reset | 12 Band switch |
| | 13 Mode switch |




Panel sketch 06 □ 7.0 inch removable panel




- | | |
|------------------------------|-------------------|
| 1 Aux input | 7 Decorative lamp |
| 2 Mic | 8 Eject/angles |
| 3 Controller signal receiver | 9 Power button |
| 4 Screen | 10 Loose button |
| 5 Volume up/down | 11 Reset button |
| 6 GPS/P. N switch | 12 USB port |


Panel sketch 07 ☐ 7.0 inch removable panel



- | | |
|-------------------------------------|------------------------|
| 1 Aux input | 7 Mode switch |
| 2 Mic | 8 Eject/angles |
| 3 Controller signal receiver | 9 Power button |
| 4 Screen | 10 Loose button |
| 5 Volume up/down | 11 Reset button |
| 6 GPS/P. N switch | 12 USB port |



Panel sketch 08 □ 6.2 inch touch button panel




- 1 Disc entrance
- 2 Power button
- 3 Mic
- 4 SD card slot
- 5 GPS card slot
- 6 Digital TV card slot
- 7 USB port

- 8 Aux input
- 9 Reset
- 10 Controller signal receiver


- A Mode switch
- B Band switch
- C Volume up/down
- D Mute button
- E Eject button
- F Stop/GPS
- G Previous track/Next track/Fast-forward/fast-reverse
- H Pause/Play
- I Screen

Panel sketch 09 □ 6.0 inch removable panel



- | | | |
|------------------------|-------------------------------|--|
| 1 Disc entrance | 8 Mute button | 14 SD card slot/GPS card slot/Digital TV card slot |
| 2 Loose button | 9 Aux input | 15 Reset button |
| 3 Eject button | 10 USB port | |
| 4 Power button | 11 Screen | |
| 5 Mode switch | 12 Controller signal receiver | |
| 6 Volume/Multifunction | 13 Mic | |
| 7 Band switch/GPS | | |

Panel sketch 10 □ 6.0 inch removable panel



1 Disc entrance

2 Loose button

3 Eject button

4 Mode switch

5 AM/FM

6 Band switch/GPS

7 Mute button

8 Volume/Multifunction

9 Power button

10 Aux input

11 USB port

12 Screen

13 Mic

14 Controller signal receiver


15 SD card slot/GPS card slot/Digital TV card slot

16 Reset button


Operation chart of 7.0 inch removable panel


Remove the panel:



Press  down the Loose button by force to the right position, as shown in the picture.



Press  and hold the Loose button with right hand and push the right end of the small panel to right with the left hand by force, as shown in the picture.



Remove the ejected small panel, as shown in the picture.

Install the panel:



Align A point to the metal plate at B point, as shown in the picture.



Hold the right end of the small panel by force and align it to the metal plate at the left end; then push it to left.



Press down the right end of the small panel into the slot, as shown in the picture.

Operation chart of 6.0 inch removable panel

Remove the panel:



Press **1** down the Loose button by force to the right position, as shown in the picture.




While the Loose button **1** is pressed down, hold the small panel to avoid ejection of the panel due to large elastic force, as shown in the picture.



The small panel is ejected, as shown in the picture.

Install the panel:



Insert A point into the slot at B point, as shown in the picture.




Hold the upper end of the small panel and insert it to the slot at B point, as shown in the picture.




Press down the upper end of the small panel into the slot by force, as shown in the picture.

Controller sketch




1. Power button
2. Play/Pause
3. Mute
4. Select menu button
5. Band/P. N
6. Enter button
7. Volume button
8. Radio/Select tract/Fast-forward/Fast-reverse
9. Programming play/Stereo/Single channel switch
10. Display
11. Set audio
12. Repeat play
13. Random play (LOC switch)

14. Numeral buttons
15. Channel settings
16. PBC menu
17. Subtitle
18. Go to time
19. Mode
20. Stop/Return
21. Angle
22. Slow play
23. Setting menu
24. Subtitle
25. Zoom

Note: the button  is used for turning under radio mode, and is used for selecting track (short press) or for fast-forward/fast-reverse (long press) under DVD mode.


Main menu

Under the main menu of the product, touch the icons to enter corresponding status and play disc or conduct operations. Press the  button in the top left of the menu to enter night mode, which provides a function that: when the headlights of the car are turned on, the screen of the product will become darker, so that the driver will not be dazzled by the light of the screen. Under the main menu, the system will return to play interface automatically if there is no operation for about 10 seconds. In English interface, there are two kinds of wallpaper that you can select.




Radio interface




 **Return button:** return to main menu

 **Volume button**


 **Preview/Auto search for channel**


Short press the button to search for channel up/down manually, and long press it to search for channel up/down automatically


Note: 6 channels can be saved in each band, and 30 channels can be preset in all. After the channels are preset automatically, all formerly preset channels will be canceled.


 **Band switch:** touch the position where band is displayed on the screen to switch band in the order of:


FM1→FM2→FM3→AM1→AM2


 **Auto select and save channel button**



 **Switch menu interface:** enter radio menu interface


 **Save channel button:** short press one of M1-M6 buttons to call the channel saved in the button; long press one of M1-M6 buttons to save the current channel in the button.

 **Stereo/single channel switch button:** in FM band, press this button to switch between stereo and single channel. When the signal is weak, switch to single channel to reduce interference.

 **Remote control button:** achieve remote control

 **Night mode:** click any position on the screen to return to normal mode.

 **Multi-frequency auto switch:** if in RDS channel, the AF icon light remains on; if not in RDS channel, the AF icon light twinkles. Long press  button to search for RDS channels only.

 **Auto frequency tracking:** click the TA button on the screen to enable the RDS auto tracking function. When the product receives RDS signal, it will switch to RDS channel automatically; click the TA button again to disable auto tracking function.


 **Click the PTY button repeatedly to select from 31 different programs of RDS channel.**


Note: Enter System settings and select RDS to enable the RDS function.


Frequency spectrum



 **Volume up/down**

 **Equal loudness**

 **Sound field mode:** press this button and EQ OFF will display on the screen, then press this button repeatedly to select from 4 sound effects including FLAT / CLASS / ROCK / POP to achieve better sound quality.


 **Return to radio menu.**



Note: The product applies default settings when leaving factory. You can change the settings according to your needs.



Bluetooth





1. Matching: enter Bluetooth menu and search for new device in the Bluetooth interface of your mobile phone. Select Connect when the product is listed on your phone and input password (0000 by default).

2. Dialing: after matching, click the numeral buttons 1 to 9 directly to input the phone number you want to dial, and then click  button to dial.


3. Clearing: when inputting phone number, if one number is wrong, click  button to clear the previous digit, if you want to clear all, click  button.

4. Answer/hang-up: when there is an incoming call, click the  button to answer, or press the  button to refuse. (Note: the system will switch to Bluetooth automatically when there is an incoming call, and the playing music or program will stop.)

5. Call history: click  button to enter Call History menu, which has the same functions with the call history of your mobile phone. In this menu you can view answered calls, missed calls and dialed calls, and can dial the viewed number directly. See figure A1 for reference.



A1

6. Play music via Bluetooth: click  button to enter Music menu to play/pause the music in your mobile phone and select next and previous track.

7. Return to main menu: click button to return to main menu.

Disc/USB/SD card play menu



- Select previous track/fast-reverse button: under player mode, short press this button to select previous track, or long press the button repeatedly to select X2, X4, X8 or X20 fast-reverse. When in fast-reverse, click Play button to return to normal speed.
- Select next track/fast-forward button: under player mode, short press this button to select next track, or long press the button repeatedly to select X2, X4, X8 or X20 fast-forward. When in fast-forward, click Play button to return to normal speed.
- Pause/play button: when playing DVD disc, press this button to pause playing, and press it again to resume.
- Stop button: when playing DVD disc, press this button to stop playing, and press the Play button to play again.
- Return to main menu
- Volume up/down
- Scroll button: click this button to see more buttons of different operations.


*Click the button for the first time, the following interface will appear:



- System menu settings
- Menu play button: when playing DVD disc, press this button to display track list (number), and play the selected number (require support of the disc)

- Previous page
- Next page

• Image setting, see the following figure:



• Audio setting, see the following figure:



- Repeat play: click this button to select Repeat chapter, Repeat title, Repeat all, or Repeat off.
- Random play: click this button to enable/disable random play. When enabled, the tracks will be played randomly.
- Switch subtitle: when playing DVD disc, if the disc contains different subtitles click this button to switch between those subtitles; if the disc contains only one subtitle, this button is invalid.

• Screenshot: under DVD mode, if you see an image that you like very much, you can capture it and make it the power-on image. To do this, you can: click button, then "Capturing image" will display on top left of the screen; wait for 5 seconds until it displays "OK". The system will save the captured image automatically, and when after you restart the player, the power-on image will be the captured one.

• Sound channel switch: when playing VCD disc, click this button to switch between left and right channel; when playing DVD disc, if such disc contains more than one sound track and language, click this button to switch between different tracks and languages; if such disc contains only one sound track, this button is invalid.

• Display title

* Click the button for the second time, the following interface will appear:



- Up/down button: click this button to select up/down in the menu. When an option is selected, click Ok button to conduct the selected operation.
- Left/right button: click this button to select left/right in the menu. When an option is selected, click Ok button to conduct the selected operation.
- Enter
- Return to page one menu

Note: In DVD/USB/SD mode, click center left of the screen to go to previous track, click center right of the screen to go to next track, and click four corners of the screen to slip up/down.

TV interface

