



# USER MANUAL



Wide Angle



Super Long Time  
Recording



Fashion Design



Hidden Camera

## 时尚安防闹钟说明书

## 前言


本用户手册将详细说明如何使用本产品,同时提供给您详细的信息,包括使用、操作。使用前请仔细阅读本手册并完全理解。请妥善保存本手册,我们希望本产品能满足您的需求并长期服务于您!

## 产品保证

本产品经 FCC & CE 等权威机构认证符合推荐指标,顾客使用具有安全保证。

## 电子闹钟操作说明

### 一、产品结构



### 二、功能介绍:

- ◇ 时间显示功能,显示当前时间、年、月、日。
- ◇ 闹铃和贪睡功能,可设置闹铃和贪睡时间间隔(1-60分钟)。
- ◇ 语音报时功能,语音播报当前时间。
- ◇ 温度功能,侦测当前环境温度。
- ◇ 自然声音欣赏功能,可设置欣赏时间(10-60分钟)

### 三、功能设置:

#### 1、 当前时间设置:

◇ 在时间显示模式按“SET”键进入年份设置, 屏幕显示“2010”并闪烁, 通过“UP”. DOWN 键的配合进行设置

◇ 再按“SET”键依次设置月→日→小时→分钟, 设置时相应位置的数字会闪烁.



时间模式

设置年份

设置月份



设置日期

设置小时

设置分钟

◇ 按“MODE”键退出时间设置, 显示设置好的时间。

#### 2、 闹铃时间设置

◇ 在当前时间模式按“MODE”进入闹铃设置模式, 显示“--:--:--”

◇ 按“SET”键第一次设置闹铃小时, 按第二次设置闹铃分钟, 按第三次设置贪睡时间间隔(1-60 分钟),


按第四次设置闹铃声音, 通过“UP” “DOWN” 进行选择



闹铃模式.

设置闹钟小时

设置闹钟分钟



设置贪睡时间间隔

设置闹钟音乐

◇ 按“MODE”键退出闹铃设置, 显示当前时间模式。

◇ 在闹铃模式按“UP”键可打开或关闭闹铃, 贪睡功能开启时“☺”符号会闪烁



闹铃关闭

闹铃开启

贪睡功能开启


◇ 按“MODE”键返回时间模式。

3、 在当前时间模式: 按“UP”键可进行 12/24 小时转换; 按“DOWN”键可进行温度: 摄氏(°C)/华氏(°F)度的转换






12 小时制



24 小时制




摄氏温度



华氏温度

#### 4、 报时、自然声欣赏功能：

- ◇ 在当前时间模式，按“TALK”键，播报当前时间。
- ◇ 在任意模式，按“TIME”键可进行自然声欣赏时间的设置（10-60 分钟）。



设置自然声欣赏时间

- ◇ 在任意模式，长按“TALK”键三秒进入自然声欣赏模式，按设置好的时间倒计时，时间到“00:00”自然声停止。




自然声欣赏模式



自然声停止

- ◇ 在自然声欣赏模式，按一下“TALK”键暂停，再按一下，欣赏下一种自然声音。按“MODE”键退出自然声欣赏模式。










注：在面板的显示窗口、数码管前面两个 LED 灯对应的位置印上“PM”和“☀”符号。如下图：




## 录影安防闹钟产品简介


本产品是一款外置TF卡存储器的高清30帧(1280x960)遥控摄像监控钟,集摄像、录音、移动侦测、网络聊天、电子闹钟、存储于一身的多功能高科技新产品。本产品配备高容量电池,可供24小时以上连续录像、60小时以上连续录音,长达14天的移动侦测监控。500万像素高清晰录像,录音、多国语言电子报时,最高支持32GB TF卡,可供长时间工作,遥控操作更方便。隐蔽性强,是居家防盗、监控取证的最佳工具。

### 一、操作说明

- 1、打开右边旋盖,插入TF卡,开启“ON”开机
- 2、用遥控器对准本机接收头轻按开机,蓝灯亮,进入待机状态
- 3、按进入录像,蓝灯闪三下后自灭进入工作状态,停止按,蓝灯亮
- 4、按进入录音,蓝灯闪二下后自灭进入工作状态,停止按,蓝灯亮
- 5、按进入拍照 蓝灯慢闪一次
- 6、移动侦测 按进入自动感应摄像功能,停止按,蓝灯亮
- 7、按关机,蓝灯灭

- 8、在机器处于ON状态下,先插入USB线然后开遥控。此时机器进入U盘模式。
- 9、网络摄像功能使用:在使用前请先安装光盘中的驱动软件;机器在ON状态下并用遥控先打开,插入USB线连接电脑。此时进入PC CAM模式
- 10、充电:在总开关拨到OFF一端时,插入USB充电器,此时红灯亮,充满后红灯灭。使用电脑USB也同样可以充电。
- 11、复位:当产品因非法操作或其它未明原因停止响应时,把拨动开关打到OFF状态。然后再打到ON就可以对本产品进行复位。
- 12、当电池低电量时,蓝灯会不停闪动,此时应马上充电。当无电时,文件会自动存储。
- 13、程序丢失时,应先安装光盘中的驱动软件,点击STK02NU程序升级工具,然后点击“update”在①DRAM Timing后选0x35在②DRAM Size后选“8M”按OK进行烧录几分钟完毕按确定。

### 二、文件存储及播放

完成录像等操作后,将开关拨到ON,插上USB数据线,用遥控打开,将里面所存的档复制或剪切到计算机里播放,同时也可将TF卡取出,使用读卡器来读取卡中的文件数据。推荐使用Media player/KM player等播放

### 三、规格参数

像素	500万CMOS
分辨率	1280*960
视频格式	AVI
帧数	30fps
视角	140度
移动侦测摄像距离	直线6米
最小照度	1LUX
电池容量	4800MA
持续录像时间	24小时以上
摇控器距离	18m
录音范围	40m <sup>2</sup>
功耗	150MA/3.7V
储藏温度	-20-80摄氏度
操作温度	-10-60摄氏度
操作湿度	15-85%RH
记忆卡类型	TF卡
记忆卡容量最大支持	32GB
播放软件	Media player/KMplayer
等USB界面	USB1.1/2.0
操作系统	2000/XP/Visat32
存储消耗	1GB/40分钟
充电时间	8小时左右

### 四、注意事项

使用场合：请严格遵守国家相关法令，不得将此产品用于其它非法用途，否则后果自负。软件升级：为了使产品具有更好性能，厂家将不断完善产品软件，本产品具有方便客户自己升级软件的特点，请向当地经销商索取最新版本软件的信息以及升级方法。

工作温度：请在自然温度下使用，请勿在人体不能适应的温度下工作。

工作湿度：请在人类适宜生活的环境湿度下使用，请勿将产品置于潮湿的工作环境，产品不具备防水功能。

拍摄照度：请在有充足的光源环境下使用，请勿将摄像头直接对着太阳等超强光源，以免光学器件受到损伤。

保洁要求：请勿在粉尘密度过大的环境下使用，以免镜头头以及其它部件沾染粉尘，影响摄像效果。镜头可以用擦镜纸或眼镜布轻轻擦拭，保持洁净。其他事项：该产品属于精密电子产品，请勿使其受到强烈冲击、震动；请勿在强磁场、强电场下使用。

## Mlutifunction Clock DVR User Manual

## Profile


This manual introduce how to operate this product and the details information about this product. Before you start to operate it, please be sure that you read this manual and understand it completely and correctly. Wish it can bring to reasonable and favotable.

## Warranty

This product is with CE, FCC and RohS.



## 1、Structure



## 2、Introduction

- ◇ Date and Time Display
- ◇ Alarm Function and Snooze Function, the interval(1-60minutes)
- ◇ Voice Broadcast the present time.
- ◇ Temperature Display
- ◇ Natural Sound Broadcast ( Interval 10-60minutes)

## 3、Time:

- ◇ In the status of time display, press and click the button, SET to reset Year. There is "2010" flashing on LCD, press the button, UP or DOWN to

choose the Year.

- ◇ Press the button, SET to reset Month-Day-Hour-Minute one by one



Time Mode      Year Reset      Month Reset



Date Reset      Hour Reset      Minute Reset

- ◇ When the resetting finishes, press and release the button, " MODE" to get out.

## 4、Alarm Reset

- ◇ In the status of Time, press and release the button, MODE to Alarm Reset Mode
- ◇ Press and release the button, SET one time to reset the Hour

Press and release the button, SET two times to reset the minute

Press and release the button, SET three times to

Reset the Snooze Mode(Time Interval, 1-60minutes)

Press and release the button, SET four times to reset Alarm Ring, press the button, UP or the button, DOWN to choose.



Alarm Mode Hour Reset Minute Reset



Snooze Mode Time Interval Alarm Ring

- ◇ Press and release the button, "MODE" to get out, the present time display on LCD.
- ◇ In the status of Alarm, press and release the button, UP to turn on or turn off Alarm. When the Snooze Function on, the "🔔" will flash.



Alarm Off Alarm On Snooze On

- ◇ Press and release the button, "MODE" to get back to the time reset mode.

- ◇ In the time mode, press the button, "UP" to choose the time mode(12 or 24), press the button, DOWN to choose °C or °F



12Mode 24Mode



Celsius Fahrenheit

## 5、Timekeeping, Natural Sound

- ◇ In the time mode, press and release the button, TALK to talk the present time.
- ◇ In any mode status, press and release the button, TIME to reset the Natural Sound(10-60minutes)



Natural Sound Time Reset


- ◇ In any mode, press the button, TALK for three seconds to Natural Sound Listening Mode, the interval time will countdown.



### Natural Sound Mode Natural Sound Stop

- ◇ In the mode of Natural Sound Mode, press and release the button, TALK to pause, press and release again to choose the next Natural Sound. Press and release the button, MODE to get out.

Notice: On the Display, there are two signs, one is PM and the other is "🕒". Please pay attention to the following picture:



## DV Function Introduction

This product is a multifunctional clock provides the DV functions including video, audio, motion detection, webcamera, movable disc. It supports TF Card and remote control function. The max. memory can be up to 32GB, the high capacity battery provide the enough power for long time recording. Just because of this many functions and features, it can be used as home security monitor.

### 1、Operation


#### (1) Turn On






Open the right side lid of camera, insert the TF card, push the button to ON.

#### (2) Press the button, on remote control until the blue indicator is burning. It enters into the Standby Status.

#### (3) Press the button, to enter into the Video Status.

The Blue Indicator is off after it flashes three times.

Press the button,  again to stop video. The Blue Indicator is burning.

- (4) Press the button,  to record audio, the blue indicator will be off after it flashes three times. Press the button again to stop the recording. The blue indicator is burning.
- (5) Press the button,  to shoot a image, the blue indicator will flash one time.
- (6) Press the button, to start this function, press and release the button again to stop it. The blue indicator will be burning.
- (7) Press the button,  to turn off the camera, the blue indicator will be off.
- (8) Push the button to ON, connect the camera and PC, then, press and release the button,  on remote control.
- (9) Webcamera  
Install the software in CD  
Push the button to ON  
Press the button,  to turn on the camera  
Connect Camera and PC with original cable

#### (10) Charge

Push the button to off

Connect the camera and power source

The red indicator is burning

During charging, the red indicator is burning

When it is full, the red indicator is off

Notice, PC also can provide the power to it.

#### (11) Reset

Because of the wrong operation or any other unknown reasons, there is no any feedback from the camera, please push the button to OFF and push it to ON again.

#### (12) Low Power

When it is low power, the blue indicator will flash quickly.

#### (13) Update

- ◇ When the programe lost, please install the drive proramme in CD
- ◇ Click the STK02NU
- ◇ Press update
- ◇ Choose 0x35 behind of ①DRAM Timing
- ◇ Choose 8M behind of ②DRAM Size
- ◇ Press and release the button, OK



(14) File Storage and replay

Push the button to ON

Connect the camera and PC with USB Cable

Press and release the button, 

The blue indicator is burning

Copy the file to PC

Replay the file in software, Media player/KM player

## 2、Specifications

Pixels	5. 0 Mega CMOS
Video Resolution	1280*960
Video Form	AVI
FPS	30fps
View Angle	140°
Motion Detection Distance	Direct 6 meters
Low Illumination	1LUX
Battery Capacity	4800MA
Recording Time	More than 24 hours
Remote Control Distance	18m
Recording Audio Area	40m²
Power Consumption	150MA/3. 7V
Store Temperature	-20~80℃

Operation Temperature	-10~60℃
Operation Humidity	15~85%RH
Memory	TF Card
Max.	32GB
Software	Media player/KMplayer
Data Transfer Interface	USB1. 1/2. 0
Operation System	2000/XP/Visat32
Memory Consumption	1GB/40min
Charge Time	About 8 hours

### Notice

Place of using: It can not be used in the illegal place, before use it, please pay attention to the law.

Software Update: The factory will improve the software in order to improve the service and using feels of this products. Please try to contact your seller to get the newest software.

Working Temperature: Please use it in the suitable temperature which the man can bear.

Working Humidity: Please do not use it in humidity place.

LUX: Please use it in the place with enough light, please

do not make the lens straight to strong light source.  
Clearance:Please do not use it in the dirty  
place,please clear it with soft cloth and clear it  
smoothly.Please do not use it in strong magnetic  
field or strong electric field.