

- page is the WAP site you have set in the setting. If you have not yet set, use the site set in advance by the manufacturer.
- ✓ **Bookmark:** display exist bookmarks, select that can directly link to the web linked to the bookmark.
  - ✓ **Web history:** under this submenu, list all the recent visit web record.
  - ✓ **Input website:** select the saved web pages to internet.
  - ✓ **Service inbox:** under this submenu, input the URL site of the WAP service.
  - ✓ **Setting:** setting of browse relative content of the service inbox.
  - ✓ **edit setting:** the phone default GPRS.
  - ✓ **browse option:** set the parameter of browsing web, include waiting time and showing picture.
  - ✓ **service information setting:** open or close service information.
  - ✓ **clear up cache:** select this menu to clear up cache.
  - ✓ **clear up personnel data:** select this menu to clear up personnel data.
  - ✓ **credit credence:** to check credit credence.

#### 5.10.3 Accounting data

##### GSM data:

- ✓ Select an account to enter:
- ✓ **Name:** edit and set the name of the account data file.
- ✓ **Number:** the dialing connection number of the current account data.
- ✓ **User account:** the dial service (not WAP gateway) account name.
- ✓ **Code:** the dial service (not WAP gateway) code.
- ✓ **Style of line:** choose the style of line, simulation or digital.
- ✓ **Speed:** choose right transfers speed.
- ✓ **Website:** IP address

#### 5.11 JAVA

##### Install JAVA

Java provides you many kinds of games and network application program, select a message reference. Select carry, it will start Java program. If select the network for entering network.

##### JAVA Setup

Can set Java sound effect, Java background light, Java vibration, select SIM card, Java SIM card 1 setting group, Java SIM card 2 setting group, storage setting.

##### JAVA default safety

Can set the third part, distrust range and range option.

#### 5.12 Opera mini

##### Start Wi-Fi

Can set system time to current date, then direct link to

#### Opera mini

Note: 1. When the cursor point to website input bar and pop out drop box, select the last option "insert symbol", and you can enter the website input interface to do keyboard input.

1. When the cursor point to website input bar, press delete key to delete all letters in the website bar, then click "insert symbol" in drop box to do keyboard input.

#### 5.13 Message

Can open Wi-Fi, enter MSN to carry - successful login, also can login by GPRS.

#### 5.14 FM Sender setting

1. Open/Close
  2. Open and sound of phone close: phone doesn't play sound while sending.
  3. Close: close FM Sender.
- Set sending frequency  
The default frequency is 100.0  
Set the other side FM channel as 100.0, and the phone play sound, the other side can play too.

#### 5.15 GPS

See GPS user manual.

#### 5.16 Profiles

**Startup:** Choose Startup and enter the general environment.  
**Individual Setup:** Choose Personal Setup and enter the general mode to customize.

##### Function as below:

**Ring settings:** change the calls, alarm clock, open-close the phone, information and key sound.

**Volume:** here set the rings and the volume of keys.  
**Ring methods:** select the ring, shaking, vibration and ring and ring after vibration several options.

**Ring tones types:** select one tone, continuous ring and gradual increase.  
**Reminder tones:** open or close the alarm sound, errors, network linking sound and call linking these several sounds.

**Response mode:** any key can be set to receive this response mode.

**Messaging:** outdoor, indoor, operate it like the general profile.

**Header:** When insert headset, it auto open the mode. Personal operate it like the general profile.

**Bluetooth:** When insert headset, it auto open the mode. Personal operate it like the general profile.

#### 5.17 Shortcut

Can quickly enter function.

#### 5.18 File Management

Insert memo card, in the menu, you can create new folder to manage your data, store different files, such as music, picture etc. enter file management interface, separately list the total capacity and capacity of memory available, enter option