

Automatic Re-dial: after automatically redialing, each failed call will be automatically redialed.

Quick dial

Starts: open or close quick dial function.

Quick dial list: can auto add the number from phonebook.
IP Dial: set and choose IP phone numbers. Add an IP number and start it, choose one number in the phone book, choose "IP dialing", and then add the set IP number automatically in front of the number when dialing.

More

Call Time Display, Call Time Reminder, Auto limit time, switch line.

5.5 Setup

This menu include every personal settings.

Mode setting

Double cards open, only SIM card 1 open, only SIM card 2 open, flight mode.

Phone Setting

Time and date setup: set date and time

Time Zone setup: set time zone of a city.

Time /Date Setup: set the current time and date.

Timing on-off: set time and open or close the handset within the set time.

Language: set the display language of handset menu.

Preset input method: choose a default input method.

Color lamp setting: set color lamp open / close.

Preset coding: provide two code for choose.

Standby menu display:

Wallpaper: choose standby interface wallpaper.

Screen protection: choose a screen protecting picture for the main screen in standby interface and set the wait time.

Animation for opening: choose the animation picture for opening.

Animation for closing: choose the animation picture for closing.

Display Time and Date: open or close the current display time in standby interface.

Greetings: In standby interface Open or Close greetings. Greetings Content can be edited.

Designate function key: designate the quick enter menu via press direction keys in the standby interface.

Auto update time: open or close auto update time.

UART setting: choose the SIM card 1 or 2 serial port.

Other Setup: set the brightness and the delay time of LCD background light.

Note: some function needs network supplier support.

Network Setup

Network Selection:

Auto select: auto search the network of the SIM card.

Manual: search all available networks, manual login.

Preferential Network: Pre-save several networks you like.

Safety Setup

Safety setup of the SIM card 1:

1. The SIM card 1 Lock: you can set the safety option in this menu, prevent your handset or SIM card from being illegally used.

2. PIN Code, PIN Code can be used to prevent your SIM card from being illegally used.

If the current PIN code has been closed, choose Open and start PIN code protection, and your PIN code will be required before your handset starts next; if the current PIN code has been opened, choose Close and close PIN code protection, and choose Change PIN code and set new PIN code; please input the old PIN code, new PIN code and repeat the new PIN code in accordance with the reminder.

* Note: if PIN code is input continuously incorrectly to three times, the SIM card will be locked, when you need PUJK code to unlock SIM card. PIN code and PUJK code can be offered to you with SIM card, if not, please contact your network supplier. The default PIN code is generally 1234, and please change it to your own set password as soon as possible.

3. Fixed Dial-up:

When the function operates, the phone numbers in Fixed Dial-up table or of beginning with some certain digits can only be dialed. (Requires SIM card support)

Mode: open or close Fixed Dial-up function (input PIN2 code)

Fixed Dialing List: input the phone number of Fixed Dial-up.

* Note: to open and close Fixed Dial-up function, it is necessary to input your PIN2 code. Please contact your network supplier to obtain PIN2 code. Open Fixed Dial-up and then enter the calling card which displays the numbers of Fixed Dial-up.

Restrict dialing: restrict dialing out.

Change Password: Change Password, including modifying PIN1 and PIN2 and phone password.

Safety setup of the SIM card 2: this setup operation consult the safety of the SIM card 1.

Phone Lock:

In order to prevent illegal usage, you can set password in your mobile phone. Once this function is chose, each time you power on your phone, you must input phone password, and you can unlock the phone only by this way, and then send or answer the call. Users can remove phone password, in this case, the phone can not prevent illegal usage.

Input the mobile phone password, use the right soft key to clean error input, and press confirm to finish it.

* The default password of mobile phone is set to be 1122, input 1122.

quick as possible. Suppose that you forgot your phone password, you must contact with your retailer or local authorized maintenance center to unlock your password.

Change password:

Can change the phone password.

* Note: part of functions is supported by your network supplier.

Restore Factory

Set the functions of your phone to default settings: 1122

Sound effects

Sound special effects: open the balance, can set the sound effects style.