

Enter dialled call menu, press confirm to view dialled call list.
 In call record list interface, you can press confirm to view the detail of record, include number, times.
 In detail message interface, you can press confirm to view the detail of record, call record, operation as below:
Delete: delete the record.
Dial: dial the number into SIM card or handset.
Edit: edit the phone number.
Send SMS: send a SMS to current number.
Send MMS: send a MMS to current number.

Received Calls

Enter received call menu, press confirm to view received call list.
 In call record list interface, you can press confirm to view the detail of record, include date, dialled time, number, times.
 In detail message interface, you can press confirm to view the detail of record, call record, operation as below:
Delete: delete the record.
Save: save the number into SIM card or handset.
Dial: dial the number into SIM card or handset.
Edit: edit the phone number.
Send SMS: send a SMS to current number.
Send MMS: send a MMS to current number.

Delete records

Enter delete record submenu, you can delete a call record or clear all records.

Call Time

In call time interface, there are four submenu:
Previous call time: view the time value of the last call.
Total Dialled Calls: view the total time value of the call out.
Total Received Calls: view the total time value of the call in.

All Time Return-to-Zero

Clear up the data in timing stat and restart time.

Call Cost

Call Cost can store the accumulated charge of call for you.
Previous Call Cost: View the last call cost.
All Call Cost: View all the accumulated call cost count the cost.
Cost Limit: Enter the sub-menu Cost Limit, which can be browsed, modified or cancelled. Where, it is essential to enter PIN2 code if you want to modify or cancel.

Price and rate: Enter the sub-menu price and rate, which can be browsed, modified or cancelled. Where, it is essential to enter PIN2 code if you want to modify or cancel.

Note: You need enter PIN2 code for operating some functions, and please contact your network supplier to receive the password.

Note: needs network support.

SMS Counter

Enter dialled call menu, press confirm to view dialled call list.
 In call record list interface, you can press confirm to view the detail of record, include number, times.
 In detail message interface, you can press confirm to view the detail of record, call record, operation as below:
Delete: delete the record.
Dial: dial the number into SIM card or handset.
Edit: edit the phone number.
Send SMS: send a SMS to current number.
Send MMS: send a MMS to current number.

Sent: record the sent SMS number.
Received: record the received SMS number.
 You can select the left soft key "reset" to empty the two items respectively.

GPSS Counter

Last Sent: record the last sent size.
All transmit: record all transmit size.
All received: record all received size.
Clear counter: recount.

5.4.2 Call Setup

They are SIM card 1 call setup and SIM card 2 setup in the menu. The two operation are the same, as below:

The phone number: the system default value is used for whether to send the number. Press up/down navigation key to select system default, hide number or send number.

Call Waiting: open or close Call Waiting. Choose Inquiry and view the current status of Call Waiting.

Call Forwarding:
 • **Unconditional transfer:** open the unconditional transfer and any dialing call will be transferred to your set number under no circumstances, call to your set number.

• **Contact not transfer:** after not contact transfer is opened, under the circumstances where the other side will not contact you, transfer the dialing call to your set number.

• **Transfer without answer:** after transfer without answer is opened, under the circumstances where your handset has no answer, transfer the dialing call to your set number.

• **Transfer when busy:** after transfer when busy is opened, when your handset is busy, transfer the dialing call to your set number.

• **Cancel forwarding:** cancel all Call Forwarding.

Call Restriction: restrict the dialing calls.
 • **Stop Call out:** restrict dial all calls, except emergency calls.
 • **International call:** restrict international calls.
 • **National call:** restrict national calls.

International call: restrict international calls.
 • **National call:** restrict national calls.

Stop Calling: restrict all the incoming calls.
 • **Cancel Restriction:** cancel the set restriction (input the PIN2 code).
 • **Change Password:** change the Password.

Line Handoff: choose Line 1 or Line 2.
Close Group: close Group function.