

tv box

User Manual

SAFETY WARNING

PLACEMENT

- Do not place the unit on an unstable cart, stand, tripod, bracket, table, or shelf.
- Do not expose the unit to direct sun-light and other sources of heat.
- Do not handle liquids near or on the unit.
- Never spill liquid of any kind into the unit.
- Do not put the unit near appliances that create magnetic fields.
- Do not put heavy objects on top of the unit

POWER SUPPLY

- Make sure use a 5V/1.5A min output AC adapter instead.

- Please unplug power supply and aerial plug when the weather is thunder-storm or lightning.
- Please unplug power supply, when there is nobody at home or didn't use over a long period of time
- Please keep power cord from physical or mechanical damage.
- Please use exclusive power cord, don't modify or lengthen it.
- Please check an ensure AC source is connected with the ground.

TEMPERATURE

- Do not place the unit near or over a radiator or a heater register.
- If your unit is suddenly moved from a cold to a warm place, unplug the power cord for at least two hours until moisture removed

HUMIDITY

- Do not expose machine in rain, damp or place near water.
- Ensure the indoor is dry and cool.

VENTILATION

- Keep the ventilation openings clear.
- Ensure that the unit has enough space for ventilation around.

FEATURES

tv box is based on Android OS. You can use it:


- Surf the Internet via Wi-Fi
- Communicate with your friends via SNS applications
- Enjoy movies, music and photos

PRODUCT & ACCESSORIES

tv box , HDMI extention Wire

USB Power Supply Wire, Adapter, User Manual

INTERFACE



Number	Features
1	camera
2	IR
3	Microphone
4	Led for power
5	Power button
6	Recovery button (press and hold it, plug in USB line, then boot into upgrading mode).
7	Micro USB for connect pc
8	standard HDMI port
9	Standard USB support USB mouse & keyboard
10	standard ethernet port
11	DC port for power supply
12	Earphone & audio port
13	TF card slot
14	Out wifi antenna port


QUICK INSTALL GUIDE

- Normal Condition

Insert tv box into TV's HDMI input interface.

Connect Micro USB port to adapter via USB power supply wire for power supply.

MAIN LAUNCHER



By using the App Manager, you can view and launch application, such as Weather, Calendar, News



Browser contains bookmarks and search bar. It allows you enjoy

your time on surfing Internet. You can search for information and watch online TV ect.




Settings contains most of the customizing and configuration options, such as language, aspect ratio and network settings.



The Video tabs contain: Video / Music / Picture

SETTINGS



Wi-Fi settings

Check to turn on Wi-Fi so you can connect to Wi-Fi networks
Check to receive an alert when an open Wi-Fi network becomes available

Opens a dialog where you can add a Wi-Fi network by entering its SSID and security type

Bluetooth settings


Turn on Bluetooth and locate available device

Pairing to the available device

Ethernet


Connect to a Ethernet cable.

The following icon shows in status bar indicates it works fine now.



Static IP Setup:

Entering SETTINGS--Ethernet--Static IP Settings, enter in the correct IP, gateway and netmask, and that corresponds with your network setup. Then enter your preferred and alternate DNS server addresses. Here is a simple



APPLICATIONS

Install from USB Flash Drive / TF card

1. Open the "File manager"
2. Choose your USB flash drive or any other mass storage's folder
3. Find your application, and press it
4. Press the install button
5. You can find the application in tab

Download & install from Browser

1. Open the Browser.
2. Press search key and input your website address.
3. Download the APK file which you like if there is a link for download (If you have problems with downloading, please try to put your TF card in the card slot).
4. You will find the file in your SD card folder.

Install from ApkInstaller

1. Open the ApkInstaller.
2. Find the icon of the application, and enter it.
3. Press the install button.
4. You can find the application in tab "Apps" after installation.

Remove Applications

1. Enter SETTINGS
2. Enter Apps
3. Find the application you want to remove in tab "All"
4. Enter the icon and press "Disable"
5. Press "OK" to confirm uninstall