

# User's Manual

## Gesture control Bluetooth Speaker

### Content

Specifications  
Charging for Bluetooth Speaker  
Bluetooth Speaker Turned on  
Indicator Light  
Pair Bluetooth Speaker with mobile phone (or Tablet PC ,computer with Bluetooth) ,  
How To Use Bluetooth Speaker  
Remarks  
Frequent Questions  
Maintains

### Specifications

Bluetooth Speaker Version: V3.0  
Frequency: 2.4GHZ  
Rated Power: 3W  
Signal-To-Noise: <82db  
Voltage for Working : 3.7V  
Voltage for Charging: 5V DC  
Time to Charging: about 3-4 hrs  
Range: About 10m  
Music Playing time : about 4hrs (as the volume of voice)  
Time to Call :about 6 hrs

### Bluetooth Speaker Charging

Rechargeable Battery is built-in in Bluetooth Speaker.

1. That Bluetooth speaker is in a 100% charge state is suggested before initial using.
2. Insert the plug of charge to the charging hole of Bluetooth speaker, and then have the charge combined to power AC or PC.
3. The indicator light will be on in a charging state, and the indicator light will be off after finishing.

\*Only the charge with 5V DC or USB for computer can be used\*

### Bluetooth Speaker Turned on

1. Make sure the battery with 100% charge state.
2. Pair the Bluetooth speaker with mobile phone or PC which Bluetooth is on.

### Indicator Light

State of BluetoothSpeaker	State of Indicator Light
The Standby	Blue Flash
Charge	Red on
Full charge	Red off
TF Card Model	Blue with slow flash (just for Bluetooth Speaker with TF Card)

### Pair Bluetooth Speaker with Mobile Phone

1. Be sure the Bluetooth Speaker is on.
2. Turn on the Bluetooth of mobile phone and search the devices with Bluetooth ,then the match name with "Myvision" is chosen . Click the word "pair" and "Pair successfully" will be announced.

### How To Use the Bluetooth Speaker

1. "M" Button : Press the button for 3 seconds as this function of hand gesture recognition is implied "off". It will be next song if from left to right;in contrast,it will be the last song .That from down to up stands for "Pause",of course, that from up to down is "Play" .

2. "M" Button: Transform models ( Bluetooth Model/TF Card Model/Line-in Model) is just to be pressed for a short time. "Bluetooth Model "is implied. Insert a piece of TF card ,it will be automatically transferred to the TF card mode; the Line-in Mode will be on when line is combined.

- A. Volume Button: Touch "V-" is for "Volume Down", "V+" is for "Volume Up".( Transforming Between Chinese and English for this two button same time 3 second pressing )
- B. Call on/off: the button is for "Pause"or"Play" when it is pressed for a short time.When call is coming, it is also for "Call"or "Hang up". Long press is for On/Off.
- C. Resetting Button : The range is 15mm from outside of Line base to resetting key inside round hole of Line-in of plug base.

### Remarks with using Bluetooth Speaker

1. The furthest range is 15cm when the function of hand gesture recognition is effective.
2. The best range is 50cm if you have a call with Bluetooth Speaker.

### Frequent Questions

#### Is there some noise?

As it is open area that where Bluetooth protocol is effective. **It is 10m that there are no obstacles** . Besides, Human body is also the largest obstacle for Bluetooth speaker. we suggest the Bluetooth speaker is placed an open area to get a better efficiency..

#### Is there no voice ?

1. Please make sure the Bluetooth speaker is on and in full charge state .
2. Please be sure the Bluetooth speaker and mobile phone paired successfully.
3. Please be sure the Bluetooth speaker and mobile phone paired successfully ,if not, Please take the Bluetooth menu of mobile as a reference or turn the power on once more. [Please read (To Pair Bluetooth Speaker and Mobile Phone) ]

### Bluetooth speaker can't be paired successfully with mobile phone ?

1. Please make sure the Bluetooth speaker is on and in full charge state .
2. Please be sure the Bluetooth speaker and mobile phone paired successfully.
3. Please make sure Bluetooth of mobile phone is on .More details ,Please read the Instructions for mobile phone .
4. Please keep it is inside 10m between Bluetooth speaker and mobile phone.No obstacle as the wall or any electronics.

### Please try to operate as below if the above methods can't resolve the problem:

1. Get the Bluetooth speaker recharged.
2. Turn the mobile phone off and take out the battery ,then install it once more.
3. Turn Bluetooth of mobile phone and delete the all match names.
4. Pair the Bluetooth speaker with mobile phone again .

### Remarks

1. Don't put the Bluetooth speaker on the supplementary restraint system in car . It maybe result in heavy hurt if the supplementary restraint system pop-up.
2. Caution on the children playing Bluetooth speaker ,as the little part maybe make the children choke if the children eat it carelessly.
3. Please attention when you get into a specialized place as hospital or blasting site or potential blasting. Maybe you will be requested turn the electronics and wireless device off.
4. Please make sure Bluetooth speaker off before taking a flight.
5. Please make an appropriate volume to protect your ears.
6. Please don't try to amend any places of Bluetooth speaker by yourself.
7. Please keep the Bluetooth speaker in a dry condition.
8. Please don't clear up the Bluetooth speaker when it is in charging. Survive the charge from Bluetooth speaker and clear them up.
9. Please don't force to open the built-in battery of the Bluetooth Speaker.

### Maintains

1. Turn the Bluetooth speaker off when it is put into bag. If not ,maybe the mobile phone will call someone in fault.
2. Don't make the Bluetooth speaker touch something wet as liquid,moisture,rain etc.since the Speaker non water-proof.
3. Don't clear the Bluetooth speaker with something corrosive.
4. Don't expose the Bluetooth speaker to high or low temperature conditions.
5. Don't make the Bluetooth speaker in sunshine for a long time.
6. Don't make the Bluetooth speaker close to fire as stove.
7. Don't abandon the Bluetooth speaker into fire as it will result in a blast.
8. Don't make the Bluetooth speaker touch something sharp as the damage.
9. Don't make the Bluetooth speaker stab anything, maybe it will hurt the internal parts.
10. Don't try to open the Bluetooth speaker because there is no amended parts include.
11. Keep the Bluetooth speaker in a dry condition if it isn't used for a long time .please take it to charge every month to prolong the battery.
12. Don't charge for Bluetooth speaker in a high or low temperature.
13. Don't abandon the Bluetooth speaker as household rubbish. It should be abandoned according to rules.

### Built-in Battery

1. Don't try to replace the battery of Bluetooth speaker,because the battery is built-in and not be replaced.
2. Please charge the battery according to the instructions attached.