# Power Case For SAMSUNG GALAXY S6 edge

## **User Manual**



\*Please read this manual carefully before use


#### Specifications

| Item          | Spec                              |   |  |
|---------------|-----------------------------------|---|--|
| Input         | DC5V-0.8A                         | Т |  |
| Output        | DC5V-0.8A                         |   |  |
| Charging time | 4.5/8hours                        |   |  |
| Operation     | 0℃-45℃                            |   |  |
| Cell type     | Cell type Polymer Lithium Battery |   |  |

#### Product Details:

- Designed for SAMSUNG, Make your phone special style.
- ► Cell Capacity: Original Polymer Lithium battery, Power your phone standby extend.
- Creative Design, Enjoy your phone without removing the power case.
- High class material to protect your phone, Charging and protecting 2in1.
- ► Integrated circuit design, effectively avoid shorting circuit or overcharge even under extreme conditions of wrong operating.
- With smart switching and precise power display, to extend the life of the built-in battery

#### Instructions



①4 LED indicators ②Micro USB input port ③Slide stander ②On/OFF key④Output⑥ With USB port

#### How to use



Put your phone tightly on the power case
 Slide your phone tightly to the bottom

#### Accessories

1. Power Case X1 2 User manual X1

### Operating Guide

- ▶ Charging the power case
- Connect the Micro USB cable with the power case, Then plug the USB to power adapter to charging, LED indicators are flashing
- ▶Charging the phone
  - Put the mobile phone into the power case, press the switch key on bottom-left to charge the phone. When charging, the LED indicators are flashing, press again the switch key to stop charging.
- ▶ Charging both the power pack and phone 1.When charging the power case, put your phone into the case, press the switch key on the bottom-left, the phone will be charged firstly, Press the switch again to stop the phone charging priority.

#### I FDIndicators

| Capacity         | Charging the power case |           |          |          |  |
|------------------|-------------------------|-----------|----------|----------|--|
|                  | LED1                    | LED2      | LED3     | LED4     |  |
| < 25%            | Flashing                | OFF       | OFF      | OFF      |  |
| 25%-50%          | ON                      | Flashing  | OFF      | OFF      |  |
| 50%-75%          | ON                      | ON        | Flashing | OFF      |  |
| 75%-100%         | ON                      | ON        | ON       | Flashing |  |
|                  | Chargin                 | g the SAN | SUNG     |          |  |
| Capacity         | LED1                    | LED2      | LED3     | LED4     |  |
| < 25%            | Flashing                | OFF       | OFF      | OFF      |  |
| 25%-50%          | ON                      | Flashing  | OFF      | OFF      |  |
| 50% -75%         | ON                      | ON        | Flashing | OFF      |  |
| 75% -100%        | ON                      | ON        | ON       | Flashing |  |
|                  | Not Cha                 | rging     |          |          |  |
| Capacity         | LED1                    | LED2      | LED3     | LED4     |  |
| < 25%            | ON                      | OFF       | OFF      | OFF      |  |
| 25% -50%         | ON                      | ON        | OFF      | OFF      |  |
| 50%-75%          | ON                      | ON        | ON       | OFF      |  |
| 75% -100%        | ON                      | ON        | ON       | ON       |  |
|                  | Chargin                 | g both    |          |          |  |
| Capacity         | LED1                    | LED2      | LED3     | LED4     |  |
| SAMSUNG priority | ON                      | OFF       | OFF      | OFF      |  |

#### A [Caution]







- Do not drop or bump, do not put it into the fire, hot temperature and water.
- ■Please use the proper charger or adapter for it, if have any deformities or corrosion, please stop using!

Warning: improper use may cause product damage and may harm vourself! keep it away from the child!