Power Case

For Samsung Galaxy Note 5/S6 edge+

User Manual



*Please read this manual carefully before use


Specifications

Item	Spec		
Input	DC5V-0.8A		
Output	DC5V-1.5A Max		
Charging time	6.5hours		
Operation	0°C−45°C		
Cell type	Polymer Lithium Battery		

Product Details:

- Designed for SAMSUNG, Make your phone special style.
- ▶ Cell Capacity: Original Polymer Lithium battery. Power your phone standby extend.
- ▶ Creative Design, Enjoy your phone without removing the power case.
- ▶ High class material to protect your phone, Charging and protecting 2in1.
- Integrated circuit design, effectively avoid shorting circuit or overcharge even under extreme conditions of wrong operating
- With smart switching and precise power display, to extend the life of the built-in battery

Instructions



@4 LED indicators @Micro USB input port ®Slide stander

@On/OFF key @ Output

How to use



@Put your phone tightly on the power case @Slide your phone tightly to the bottom

Accessories

1.Power Case	X
2. User manual	>

Operating Guide

- ▶ Charging the power case Connect the Micro USB cable with the power case, Then plug the USB to power adapter to charging, LED indicators are flashing
- ▶Charging the phone Put the mobile phone into the power case, press the switch key on bottom-left to charge the phone, When charging, the LED indicators are flashing, press again the switch key to stop charging.
- ▶ Charging both the power pack and phone 1.When charging the power case, put your phone into the case, press the switch key on the bottom-left, the phone will be charged firstly. Press the switch again to stop the phone charging priority.

LEDIndicators

Capacity


Capacity	LED1	LED2	LED3	LED4
< 25%	Flashing	OFF	OFF	OFF
25%-50%	ON	Flashing	OFF	OFF
50% -75%	ON	ON	Flashing	OFF
75%-100%	ON	ON	ON	Flashing
		g the SAN		
Capacity	LED1	LED2	LED3	LED4
< 25%	Flashing	OFF	OFF	OFF
25%-50%	ON	Flashing	OFF	OFF
50% -75%	ON	ON	Flashing	OFF
75% -100%	ON	ON	ON	Flashing
	Not Cha	rging		
Capacity	LED1	LED2	LED3	LED4
< 25%	ON	OFF	OFF	OFF
25% -50%	ON	ON	OFF	OFF
50%-75%	ON	ON	ON	OFF
75%-100%	ON	ON	ON	ON
	Chargin	g both		
Capacity	LED1	LED2	LED3	LED4
SAMSUNG priority	ON	OFF	OFF	OFF

Charging the power case

⚠ [Caution]







■ Please use the proper charger or adapter for it, if have any deformities or corrosion, please stop using!

Warning: improper use may cause product damage and may harm yourself! keep it away from the child!