



1. Smart view at a glance




2. Smart view at a glance /Accessories




3. Turn on /off, turn in sleep mode

1. Turn On
Press power button for 2seconds.
2. Turn Off
Press power button for 2seconds
Select "power off" on pop-up menu.
3. Sleep mode
Short press power button




4. Screen focus /brightness

1. Focusing
Turn the focus wheel in one direction
2. Adjust brightness
Setting-Display-Brightness




5. Charging battery

- Connect DC Charger to DC charger jack
- LED light on, while it's charging
- LED light off, once it's fully charged



6. Optical track pad

- Optical track pad supports 3mode
1. Default mode - Mouse
 2. Press 0.5sec - Drag mode
Short click to change mode to Mouse mode
 3. Press 1.5sec - Navigation key mode
Press 1.5sec to change mode to Mouse mode




7. How to connect

Use the included USB cable to connect Smart view to your computer. Connecting Smart view to your computer lets you transfer movie, music, and other content.

You can use Smart view with the Bluetooth/Wi-Fi devices, such as a Bluetooth speaker, headset and keyboard. Before you can use a Bluetooth device with Smart view, you must first pair it with Smart view.

1. Make the device discoverable.
2. Go to Settings / Bluetooth and turn Bluetooth on.
3. Select the device and, if prompted, enter the passkey or PIN.




8. How to use eShare app - Wi-Fi direct




Run eshare application



Press Direct ICON For searching Connectable device




Connect Wi-Fi direct




Select a device wants to connect



Once device is connected, Wi-Fi direct icon on upper-right changed to Blue



Choose renderer device and media server





Select a file

9. Remote controller



Press Remote controller icon




Press icon to change to mouse mode

10. How to update software


1 Download SW update file on website




2 Run Update application



3 Select Local update



4 Run SW update file



5 Press update button, waiting until updating has completed

6 After SW update, device will be rebooted automatically