



- 1, 负离子发射口
- 2, 风嘴
- 3, 出风口
- 4, 入风口
- 5, 冷风按钮
- 6, 电源开关

- 1, Ion outlet
- 2, Nozzle
- 3, Air outlet
- 4, Air inlet
- 5, Cool switch
- 6, Power Switch

- 7, 可折叠手柄
- 8, 挂环
- 9, 电源线
- 10, 整发风嘴

- 7, Foldable handle
- 8, Hanger
- 9, Cord
- 10, Nozzle for styling

Before use

This hair dryer can be operated directly from a 220V ~ 50Hz power source. It has a new turbo function so you can dry your wet hair quickly. Use soft function can drying short hair or styling your hair. To prevent overdrying while styling hair, the unique healthy setting reduces heat output to 57°C.

The ioniser inside emits negatively charged ions that surround your hair. Negative ions reduce the build-up of static electricity and help to keep your hair in good condition, making it shiny, smooth and frizz-free. The handle of this dryer can be folded for storage.

How to use

PH8802:

1. Make sure the power switch is in the "0" position. Plug the unit in and turn on the power switch.
2. Drying your hair after washing. Set the power switch to "3" or "2" without attaching the nozzle. If you want to use the cool, please press the cool switch "☆".
3. Hair setting. Set the power switch to "1" and attach the nozzle. If you want to use the cool, please press the cool switch "☆".
4. Turn the power switch to "0" and unplug the unit.

PH8803:

1. Make sure the power switch is in the "0" position. Plug the unit in and turn on the power switch.
2. Drying your hair after washing. Set the power switch to "2" without attaching the nozzle. If you want to choose the cool airflow, please press the cool switch or set the power switch to "☆". If you want to choose the warm airflow, please set the power switch to "☆".
3. Hair setting. Set the power switch to "1" and attach the nozzle. If you want to choose the cool airflow, please press the cool switch or set the power switch to "☆". If you want to choose the warm airflow, please set the power switch to "☆".
4. Turn the power switch to "0" and unplug the unit.

Cautions

1. Always ensure the voltage to be used corresponds to the voltage stated on the unit.
2. Always switch the appliance off before putting it down, even if it is only for a moment.
3. Do not unplug by pulling on the cord. Always grasp the plug and unplug it from the outlet.
4. Do not use the dryer near gas or other inflammable materials (such as benzene, paint thinner, sprays, etc.).
5. As the handle of the hair dryer incorporates electrical components, the hair dryer must be fixed so that the handle, when fully extended, is out of reach of a person using a bath or shower.
6. The hair dryer is not recommended to use in bathroom, unplug the appliance after use since the proximity of water presents a risk even when the hair dryer is switched off. As an additional safety measure, we recommend the installation of a residual current difference device in the electrical circuit supplying the bathroom, acting at not more than 30 mA. Ask your installer for advice.
7. Do not use the dryer with wet hands or in the bath or shower. Do not use this hair dryer near water contained in bath-tubs, basins or other vessels. Do not leave or store the dryer near a tub, sink or other place where it will be exposed to water and other liquids or high humidity.
8. Do not clean with abrasive or corrosive products.
9. The dryer is equipped with a heat-sensitive safety device. In the event of overheating (for example if the rear grill is blocked), the dryer will stop automatically. Unplug the appliance and let it cool down for a few minutes. Before you switch the appliance on again, check the grills to make sure they are not blocked by fluff, hair, etc.
10. Do not direct the airflow towards the eyes or other sensitive areas.
11. Close supervision is necessary when the dryer is used by or near children and invalids.
12. If the cord is damaged, discontinue use of the dryer immediately and return the dryer to your nearest authorized POVOS service dealer for repair or replacement.

Guarantee and service

1. We grant 2 years guarantee on the product commencing on the date of the purchase.
 2. Within the guarantee period we will correct, free of charge, any defects in materials or workmanship, either by repairing or replacing the complete appliance as we may choose.
 3. To obtain service within the guarantee period, hand in or send the complete appliance with your sales receipt to an authorized POVOS Customer Service Centre.
- This guarantee does not cover:
- (1) Damage due to improper use.
 - (2) The guarantee becomes void if repairs are undertaken by unauthorized persons and if original POVOS parts are not used.

Technical specifications

Model No: PH8802/PH8803

Power source: PH8802 220V ~ 50Hz 1600W
PH8803 220V ~ 50Hz 2000W

This product is intended for household use only.

The unit is applied to the Chinese standard GB4343.1, GB4706.1, GB4706.15, GB17625.1.

使用前

本电吹风可直接用于220V ~ 50Hz 电源。有快速干发功能，独特的健康护发功能将风速控制在57°C，防止头发过干而受损，柔和暖风，适合吹干短发或定型。本电吹风附赠集风嘴，便于准确定型。整发风嘴适用于卷发和其他各类富有弹性的发型干发和定型。本电吹风特有负离子恒温护发系统，让您能够以恒定的护发温度吹干头发，同时负离子可减少静电，使您的秀发顺滑、有光泽且不毛糙。本电吹风的手柄可以折叠，便于收藏。

使用方法

PH8802:

1. 首先将电源开关设置在0的位置，然后将电源插头插入插座，打开电源开关。
2. 洗发后，如想尽可能快的吹干头发时，将电源开关设置在2档。如想要用冷风来吹干头发，按下冷风按钮。
3. 整发时，先装上风嘴，再将电源开关设置在1档。如果您是想要为卷发或富有弹性的发型定型，先装上整发风嘴，再将电源开关设置在2档或者1档。如想用冷风功能，请按下冷风按钮。