Z00Z-J series manual



A. Features

☐18 digits display with smart function
☐ Bluetooth 4.0 BLE compliance,APP support Samsuny Andriod system
☐Watch time synchronize with phone time automatically
☐Phone call ,instant messaging,Phone SMS,email ,Phone memo alert
☐Reject call answer
☐Anti-lost alert
☐Emergency call for help
☐Remote phone camera
☐12 digits time display hour, minute, second, date, week;
☐ 12/24 Hour format selectable;
☐ Worldtime
☐ Stopwatch
☐ Alarm
☐EL backlight

B . Product Function Modes



☐ In any Mode, press A key to illuminate EL for 3 seconds,

☐ Press B key shortly to select operational Mode(Alarm Mode will return to Time Mode automatically if no any key active within 1 minute)

☐In Time Mode, press B key for longer than 2 seconds to turn on/ off Bluetooth , when start up ,bluetooth icon will flash ,it will display on the screen when bluetooth connecting successfully ,it will flashing all the time when Bluetooth connecting failed .

☐ In Time Mode,press B key for longer than 2 seconds to select phone reminder sound in sequence(single vibration ON) (single tone ON)(tone and vibration ON)(tone and vibriation OFF)

☐ When bluetooth connecting success, press B and D key together to active searching function , when phone is searched , it will alarm for 10 seconds.

Z00Z-J series manual

☐**Emergency call fuction:** In any Mode, press A and C key together to active Emergency call function, your phone will dail the number which has been set automatically

☐**Anti-lost alert:** when your phone is far away from you in a distance, the watch will alarming by BB BB,or vibration for 5 seconds.

☐**Remote Phone Camera:** when your camera open,press B and D key together to capture photo automatically

☐ **Reject Call Answer :**When your phone is ringing, press any key to reject answering, the phone stop ringing .

☐1. Phone Call ,Instant Messaging,Phone SMS,Email and Phone Memo Alert Mode

☐When watch connect phone successfully , the watch ring by B-B tone or virbration sound if your phone have phone call, instant messaging, SMS,email and memo alert .



Phone Call Reminder **Instant Message** **Email Reminder** **User-defined Memo Reminder**

☐When there is a phone call , the phone symbol will blink fast . it will blink slow when phone call missed, when you viewed missed call from phone, icon on watch will stop blinking .

☐Icons will not stop blinking when user do not view phone or only view watch icon unless you press any key of the watch to stop .

☐The blinking symbol including(Instant message,Weichat,QQ,Sina Wei blog,Tencent Wei blog,facebook, Twiffer,Whatsapp) To realize reminder functions, the user need to turn ON relative items in the settings of phone

Remark: The email reminder function of current APP version can only comply with the system of Gmail

2. World Time Mode

☐ When watch received world city time zone name,it will update the time zone code and relative world time automatically

☐ Press D or C key to check world city time zone

☐ Press and hold C key for 3 seconds to turn ON/OFF DST time ,the icon "DST" will dispaly on the up right screen as below :



DST OFF DST ON

Z00Z-J series manual

☐ (DST).Under local time time zone , when turn ON/OFF DST time , the normal time will synchronously turn ON/OFF DST time automatically.
Remark: the DST time of each time zone can turn ON/OFF independently.

World Time City Code reference table:

City code	City Name	GMT Differential	Other major cities in same time zone
GMT	GMT	0	
WLON	London	0	Dublin, Lisbon Casablanca, Dakar, Abidjan
PAR	Paris	+1	Milan Rome,Madrid,Amsterdam,Algiers.Hamburg, Frankfurt,Vienna,Stockhoim,Berlin.
CAI	Cairo	+2	Athens Helsinki,Istanbul,Beirut Damascus Cape town
JED	Jeddah	+3	Kuwait Riyad,Aden Addis Ababa Nairobi Moscow
THR	Tehran	+3. 5	Shiraz
DXB	Dubai	+4	Abu Dhabi Muscat
KBL	Kabul	+4. 5	
KHI	Karachi	+5	Male
DEL	Delhi	+5. 5	Mumbai Kolkata
DAC	Dhaka	+6	Colombo
RGN	Yangon	+6. 5	
BKK	Bangkok	+7	Jakarta,Phnom Penh,Hanoi Vientiane
HKG	Hongkong	+8	Singapore Kuala Lumpur Beijing Taipei Manlla Perth Ulanbaata
SEL	Seoul	+9	Seoul Pyongyang
TYO	Tokyo	+9	Tokyo
ADL	Adelaide	+9. 5	
SYD	Sydney	+10	Melboume Guam Rabaul,
NOU	Noumea	+11	Pt Vila
WLG	Wellington	+12	
PPG	Pago	-11	
HNL	Honolulu	-10	Papeete
ANC	Anchorage	-9	Nome
LAX	Los Angeles	-8	San Francisco,Las Vegas,Vancouver,Seattle/Tacoma,Dawson City
DEN	Denver	-7	Paso,Edmonton
CHI	Chicago	-6	Houston,Dallas/Ft,worth,New Orleans,Mexico City,Winnipeg
NYC	New York	-5	Montreal,Detroit,Miami,Boston,Panam Havana,Lima,Bogota
CCS	Caracas	-4	La Paz,Santiago,Pt Of Spain
RIO	Rio De Janeiro	-3	Sao Paulo, Buenos Aires,Brasilia,Montevideo

REC	Recife	-2	
AZO	Acores Island	-1	

3. Time and Date Setting

□In the normal Time Mode, Press A key for longer than 3 seconds to access Time and Date Setting along with "Time Zone" flashing , Press B key to change mode in sequence as following



□ Press D key shortly to adjust "plus" time zone,Press D key longer to adjust quickly
□ Press C key shortly to adjust "minus" time zone, Press C key longer to adjust quickly
□ Press D or C key to turn ON/OFF DST time, the icon "DST" will display on the screen
□ Press D or C key to select 12/24H format
□ Press D key shortly to increase adjusting digit, Press D key longer to increase adjusting digit quickly
□ Press C key shortly to decrease adjusting digit , Press C key longer to decrease adjusting digit quickly
□ Press D or C key to reset second, second digits will run to 00
□ Press A key to confirm and exit setting , then switch back to normal Time Mode
□ During Time or Date setting , if no any key active in 1 minute, it will switch back to Time Mode automatically
□ When Normal time selected 12 or 24H format , the world time will synchronously adjust to 12 or 24H format

4. Stopwatch Mode

□ Max Stopwatch counting range: 23H 59M 59.99S , it will stop and re-counting from "0" when counting to the max value 23:59:59.99

Stopwatch Setting

□ Stopwatch Mode, Press D key to start/Stop running , When it stop running, press C key to reset to 00, please refer below :



Stopwatch Running Stop Reset to "00"

Stopwatch for LAP counting

□ When stopwatch running ,press C key to enter into LAP counting, Press D key to stop, Press C key to check total value, press C key again to reset stopwatch value to "0", refer as below:



□ In LAP mode , Press C key to exit, press D key to stop running, Press C key again to reset to "0",refer as below::



□ When stopwatch running, press B key to switch back to other Mode , it will run in the background
□ When stopwatch is running or running in the background, the icon "ST" will flash when switch to any other mode

5. Alarm Mode

□ In Alarm Mode, press C key to turn ON/OFF alarm
□



Alarm Setting ：

□In Alarm Mode, press A key longer than 3 seconds along with" Hour " flash to access Alarm Setting ,Press B key to select items in sequence as below :



□ Press D key shortly to increase adjusting digit, Press D key longer to increase adjusting digit quickly
□ Press C key shortly to decrease adjusting digit , Press C key longer to decrease adjusting digit quickly
□ Press A key to confirm and exit setting , then switch back to Alarm Mode
□ During setting , if no any key active in 1 minute, it will switch back to Time Mode automatically
□ When time is up to set alarm time , it will ring for 30 seconds with BB-BB, press any key to stop alarming

Notes： When enter into APP interface, you can also set watch alarm time , you can select Saturday and Sunday to No Alarming,or turn ON/OFF alarming, No matter you set watch alarm manually or use phone APP setting watch alarm ,your watch will choice the last setting time for alarming

6. Phone APP Setup

APP User Guide

1, Download: Android platform download please scan:

IOS platform download please scan:

Notes: All below illustrations are for reference only, interface will has difference for different mobile phone or if your phone system upgraded



After finished installment, the user have to go back to application interface "Settings- My Device – Secondary Function" to turn on "BJ watch" as below :



Click "My Device--Secondary Function" to turn On "Interactive control" as below (1) :

□ Slide your phone from top of the interface to pop up picture (2) as below , turn on "synchronization"



Phone Data Connecting

□ Turn on the bluetooth of your smart watch , then click up " BJ watch " in application page of your phone ,then access "BJ watch" page as below :



Click "BJ watch" Click BJ Find BJ

□Click "BJ" to serach the device , when the smart watch found in your phone , click Baojie to access settings as below :


All the symbols in this interface can turn on/off,dark when turn off



When all symbols turn on,click setting


设置
电话
电子邮件
即时聊天工具
闹钟
事件
SOS
清除连接
防丢报警
Access setting interface

Notices:

1) Bluetooth compliance fuction of this production is one to one, when your watch is connecting with your phone , please don't use any more mobile phones or more watches for Bluetooth connection in the distance of 15M .
2) If your watch connected with a wrong mobile, or your phone connected with a wrong watch, please access "Setting- Remove All Current Connection" as below, then stay away from the current location and re-search again .


设置
电话
电子邮件
即时聊天工具
闹钟
事件
SOS
清除连接
防丢报警


清除当前所有连接
取消
确定


Re-search

APP Home Page Operation

□The "BJ Watch " APP interface have phone call , message email,alarm , camera, time synchronize with phone, clic " " to access search , when it connect successful with your smart watch , the watch will ringing or vibration one time .

□Click the symbol " ☎ " to turn on or off phone call reminder function

□Click the symbol" ✉ " to turn on or off mail reminder function

□Click the symbol " 💬 " to turn on or off message reminder function

□Click the symbol " 📅 " to turn on or off user-defined notes reminder function

□Click the symbol " 🕘 " to access synchronous time setting function（this fuction can't use if device did not connect）

□Click the symbol " 📷 " to active remote phone camera function

□Click " Settings " to access setting items

Phone Call Reminder Filter Settings

□ All Call in phone numbers including : All Numbers in contacts or parts of Numbers of your contacts which selected by user


设置
电话
电子邮件
即时聊天工具
闹钟
事件
SOS
清除连接
防丢报警
Phone Call Filter Selection


来电设置
选择提醒号码
所有来电号码
通讯录号码
指定来电号码
Select all Phone Numbers


来电设置
通讯录
取消
确定
Select Set Phone Numbers

Mail Reminder Filter Setting

□You can select Email or Gmail or two of them for reminder function（ this version only support Gmail system）


设置
电话
即时聊天工具
闹钟
事件
SOS
清除连接
防丢报警
Mail Filter Selection


选择邮件通知
选择邮件通知
电子邮件
Gmail

ℓI der Fil

on /off
, QQ me
s of them or one of them to turn
i blog, tencent wei blog, Facebook、
Twitter、WhatsApp。


设置
电话
电子邮件
即时聊天工具
闹钟
事件
SOS
清除连接
防丢报警
Message Filter Selection


即时通讯设置
选择即时聊天工具
短信
QQ
微信
Skype
新浪微博
腾讯微博
Facebook
Turn on/off instant chat tool


即时通讯设置
选择即时聊天工具
短信
QQ
微信
Skype
新浪微博
腾讯微博
Facebook
Select reminder catalogue

Z00Z-J series manual

□ Select message filter: all messages or parts of messages of the contacts which selected by user


即时通讯设置
选择即时聊天工具
短信
QQ
微信
Skype
新浪微博
腾讯微博
Facebook

Message Filter Selection


信息设置
所有短信
通讯录短信
指定短信号码

Select All Messages


通讯录
+8613590447649
+8613699777692
13544105191
+85222310052
+8615658136046
取消
确定

Select Set Messages

_Remarks:

To select the reminder function of Facebook 、Twitter、WhatsApp 、skype, you need to set the reminder message to Status Bar(Normally it is on the upside of your phone, symbol will flash if you have a message coming). For example , you can refer below settings of Facebook message


更多
应用程序设置
帐户设置
代码生成器
编辑收藏夹
快捷隐私设置
条款&政策
报告问题
帮助中心


Settings
通知设置
通知
振动
手机 LED
通知铃声
留言
消息
评论
朋友请求


Settings
朋友请求确认
照片标签
活动邀请
周边好友
应用程序请求
群：
浮动聊天头像
其他设置
同步通讯录

Alarm (watch Alarm)Settings

Z00Z-J series manual

□ In setting interface , click Alarm to acess Alarm Setting , this set alarm can synchronize with the watch alarm


闹钟
08 : 23
闹钟重复
日 一 二 三 四 五 六
取消
确定

Adjust Alarm Time


闹钟
08 : 23
选择星期
确定
日 一 二 三 四 五 六

Select Week


闹钟
08 : 23
闹钟重复
日 一 二 三 四 五 六
取消
确定

Set Alarming Week

User-defined Memo Alarming settings

In the setting interface, click Memo Alarm to input your memo content and alarming time

□ When alarming time is up, the Memo Alarm symbol in your smart watch will flash and vibartion or ringing .




事件
标题
提醒时间
内容
取消
确定


事件
2014-5-29 星期四
2014
05
29
设定
取消

Reminder Date Setting

Z00Z-J series manual


事件
标题 qq
提醒时间
we
内容
取消
确定

Confirm Selection


事件
标题 qq
提醒时间
we
内容

Inpurt Memo Content


事件
09:44
09
44
设定
取消

Reminder Time Setting

SOS Number Setting（Emergency Call）

□ After set the SOS number, Press A ,C key on watch to send Emergency order, phone will dial the number automatically


设置
电话
电子邮件
即时聊天工具
闹钟
事件
SOS
清除连接
防丢报警


设置
SOS
13501234567
确定
取消

Input Phone Number

ℓ Anti-lost Alert Settings

□ After Anti-lost Alert function turn on ,When your mobile phone leave away from you , the smart watch will have vibration or alarming along with Alerting sound from mobile phone .



Anti-lost Alert ON

ℓ Time Synchronization Settings

□ Click Synchronous local time ,World time, DST time, your watch time will update and synchronize with your phone time automatically



Local Time Synchronization

DST Time ON

ℓ Phone Camera Function

□ Click camera symbol to access photograph function, Press B and D key to turn on remote camera function



View picture

Notice:

1) **If Phone and watch didn't connect for work within 30 minutes , the watch will turn off Bluetooth automatically , you have to connect and start up all data again for next time use .**

2) This watch support Bluetooth 4.0 BLE compliance, For APP support , please refer below table

Samsuny phone item No.	Android system		
	4.2.2	4.3	4.4
Samsung Galaxy S4	v	v	
Samsung Note2		v	
Samsung Note3		v	
LG Nexus 5			v

3) **Remark:** Please use original licensed mobile phone, copycat mobile phone can't support this watch for all functions .

C. Specifications

□ Movement Dimension (include oustanding) : Φ36.2mm

□ Thickness (include buzzer) : 9.8±0.15mm

□ Work Temperature : -10℃~+60℃

□ Work Voltage : 3.0V

□ Time Accuracy : s/m30 second

□ Battery Code : CR2450(610mAh)

□ Static Max Crrent （Bluetooth OFF） : ≤20uA

□ Static Aerage Current（Bluetooth OFF） : ≤18uA

□ Working Max Current (with Bluetooth connection) : ≤0.5mA

□ Working Average Current (with Bluetooth connection) : ≤40uA

□ Alarm Average Current : ≤2.0mA

□ EL Backlight Average Current : ≤10mA

□ Vabration Average Current : ≤30mA

□ Battery Life: (Calculate according to :1 day 1 time alarm for 30S,,1 day 4 times EL backlight for 12S, phone call , message,wei chat,memo reminder for 3 times vabriation or alarming

: ≥ 18 Months(Janpan battery)

	Prepared	Checked	Approved
Name	冯碧颜	赵星亮	
Date	14/07/01	14/07/01	14/07/01