
Briefing



WARNING: In order to avoid failure in reading Micro SD Card due to compatibility in Android OS, formatting the 64G Micro SD Card through Windows OS is prohibited.

Insert the micro SIM cards

Setting Up Your Phone

① To eject the micro SIM card tray, insert the micro SIM eject pin or a small bent paperclip into the small hole of the tray.



- ② Pull the micro SIM card tray out and place the micro SIM card into the tray.
- ③ Insert the micro SIM cards tray into its slot.

Charge the Phone

① Connect the USB cable to your phone.



② Plug in the power adapter to an electrical outlet to start charging.

Important:

Please use the power adapter and USB cable that packaged in the box for optimum battery performance.

Make sure you charge the battery fully for over 5 hours for the first time.

Let the battery drain completely for the first time, thereafter, repeat the charging step until the battery icon stop blinking.

Welcome Screen

For the first time you turn on your device, you will be welcomed by the Welcome Screen.

①Tap OK to create more screens

(1)Tap OK to create more scree for apps and folders.

② Follow the onscreen instructions to complete your phone setup.



Get Started

① Press and hold the power button on the left side of the panel to turn the phone on or off.



2) To lock, briefly press the power button.

③ To unlock, press the power button briefly, then pull the onscreen lock down to unlock.

Meaning of Icons


You'll see a series of icons of your smartphone as follows in the left side of the table, and the meaning of the icons are listed in the right.

Personalization

Customize Your Phone

Customize your phone with wallpapers, widgets, ringtones, and more.

- ① Tap → Settings → Personalize to access customization options.
- (2) Choose what you want to change, such as sound preferences, display or language.
- ③ Select from the options, and then tap Apply.



i.e. select sound preferences

① Tap ☐ → Settings → Audio profiles → General → tap 🙀 Select from the options, and then tap Apply.

Manage Home Screens

Customize home screen by touching and holding an empty area to set wallpapers or adding icons.

- ① To add a new icon on Home screen, press and hold the icon and then drag it to a new location on the panel.
- ② To remove an icon from your home screen, press and hold the icon for a short while, then drag it to the Delete icon appears at the top of the panel.
- (3) The preset icons on the tray are as following.



Touch Screen & Navigation

Navigate Your Phone

Use your fingertip to lightly tap the screen and select options, and use quick flick of your finger to scroll up/down and left/right. Slide your finger horizontally to the left or right and you'll discover additional space for adding icons, widgets, and more.



(1) Home Key: Touch the key to take you back to the main Home Screen. In idle screen, touch and hold the key to view recently accessed features.



Contacts & Phone Calls

Add a new contact

The Contacts app preset on the tray at the bottom of the panel, tap it into Set Up My Profile, then click at the right bottom to access Phone Contact page and click Done to save.



Contacts App

Make a Phone Call

- ① Open the Phone app.
- ② Enter a phone number or tap a contact from your contact list.
- (3) Tap call.
- 4 To hang up, tap End Call.



Text Messaging

Send a Text Message

- ① Open the Messages app.
- ② Tap to compose a new message.
- 3 Enter a number or tap to browse your contacts.
- ① Tap the add text field to enter your message.
 ⑤ Tap to send.



Tap to attach a file # Type text message > Tap to send



Attach a Picture or Video

- ① While composing a text message, tap +
- (2) Select Picture, video or other files you want to attach, even make a new one right now.
- (3) Tap > to send.




Internet

Browse the Web

Once you successfully connect Wifi or select 3G, WCDMA you just need to tap on the browser icon on the apps screen or the shortcut icon on home screen to launch this application.

- ① Tap open the Internet app.
- ② Slide two fingers apart to zoom in or together to zoom out.
- ③ To visit another website, tap the address bar, enter the web address, tap go start surfing on the internet.



Camera

Take a picture

① Open the Camera app. .

② To zoom in and out, slide your finger on the zoom bar. ③ Tap 🐧 to take the picture.

Record a video (1) Open the Camera app.

② Tap 🗖 to start record video.

(3) Slide your finger on the zoom bar to zoom in and out while recording.

(4) Tap (1) on the left top of panel to stop recording.

Send a Picture or Video

① Open the Gallery app.

2 Browse an album, and then tap a picture or video.

③ Tap
on the right top of the panel to share via Bluetooth, send by email, send as a message, or upload to a social network



Music & Google Play Store

Listen to Music

① Tap →Settings → Music

2) Tap to browse a category, such as Artists, Albums, Songs or Playlists.

3) While browsing your music collection, tap a song to play it.

4) Tap the onscreen icons to control music playback, repeat songs, and more.

Find & Install an App

Google Play Store is the place to go to find a variety of apps for your phone.

① Open the Play Store app.

(2) Browse by featured apps or by category, or search for the app you want.

(3) Tap the app to select it.

(4) To download or purchase, tap Install (for free apps) or the price button.

(5) If you agree to the conditions, tap Accept & download or Accept & buy.



Wi-Fi & Bluetooth

Connect to a Wi-Fi Network

(1) Tap Settings

(2) Under Wireless & networks, turn on Wi-Fi using the On/Off option.

(3) Tap Wi-Fi, and then choose a Wi-Fi network to connect to (secured networks require password).

Pair with another Bluetooth Device

(1) Tap → Settings

(2) Under Wireless & networks, turn on Bluetooth using the On/Off option.

(3) Tap Bluetooth, and then tap Scan for devices.

(4) Tap an available device to pair.



Other Cool Features

Maps

You can view satellite images or street map with detailed route instructions just as you are walking in the street. The map app can be used to locate yourself, view real-time traffic conditions or public transit.

Security Settings

You can lock your phone for security purpose by selecting



Screen Gesture

Your smartphone allows quick access to several functions in Standby Mode with a certain gesture functions selected open in your device, such as drawing C to quick access Camera, and slide like an M for playing Music, etc.



Intelligent Dialing

With Proximity Sensor, your smartphone is smart enough to know what you want to do without tapping on it.





Swing to answer Nearing the ear Flip over to mute to call and answer