


# WIFI REMOTE MANUAL



## wireless controls

The built-in Wi-Fi allows your HERO3 camera to connect to the Wi-Fi Remote and smartphone/tablet via the GoPro App.




To turn Wi-Fi ON/OFF via the Wi-Fi button:


Press  to turn Wi-Fi ON/OFF. When turning Wi-Fi ON the Wi-Fi mode will be set to the most recently used mode.

### USING HERO3 WITH THE WI-FI REMOTE NOT PAIRING


Pair your HERO3 with the Wi-Fi Remote to control your camera remotely. The


Wi-Fi Remote can control up to 50 cameras at a time at distances of up to 600'/180m in optimal conditions.


1. Power ON the HERO3 and turn Wi-Fi ON.
2. Press  to cycle through to the Settings menu.
3. Press  to enter .

3. Use  to cycle through to locate .

4. Press  to enter Wireless Controls.

5. You will see .

6. Press  again to enter the sub-menu.

7. Use  to select Wi-Fi RC.

8. Press  to select it.

9. Use  to select CURRENT or NEW.

10. Press  to select desired option.







## WIRELESS CONTROLS


wireless controls (continued)

On your Wi-Fi Remote:

1. Turn ON the GoPro Wi-Fi Remote.

2. While holding , press and release .

3. Once you see , you can release .

4. A check  will appear once the Wi-Fi Remote and camera have successfully paired.

The Wi-Fi Remote's LCD screen will now mirror the HERO3 LCD screen.