



QUICK START GUIDE



Quick Power On


1 Remove screws

Turn screws on back panel anti-clockwise.






2 Open the battery cover

Remove battery cover.



3 Insert the SIM card

After removing cover carefully insert SIM as per diagram.




4 Insert the Micro-SD card

Insert the SD card into the slot as per diagram.



5 Insert the battery

Insert the battery, replace cover, insert and carefully tighten screws clockwise.



6 Charge 12 hours

Recommended 12 hours charge before initial use.

Keypad Description



Note:

We recommend the consumer uses original charger provided in the box.