

Special key

Left Navigation Key: The Shortcuts for the default Profiles.

Right Navigation Key: The Shortcuts for the default Messaging.

Up Navigation Key: The Shortcuts for the default Video player.

Down Navigation Key: The Shortcuts for the default Alarm.

Long press on # key: Switch profiles between Silent and other modes.

Note: "Press" in this manual, means to press and release the key; "Long Press/Press and hold" means to press and hold the key for at least 2 seconds.

Contacts

The mobile phone can store up to 500 telephone numbers.

Call Logs

Call history

Missed Calls / Dialed Calls/ Received Calls/ All calls.

Call settings

- **SIM Call settings**

Call waiting/ Call divert/ Call barring and Line switching.

You can browse a list of above.

- **Advanced settings**

Through this function, you can set Blacklist, Auto redial, Call time display, Call time reminder, Reject by SMS, Answer mode and Auto Call Recorder.

Settings

Profiles

The mobile phone provides multiple user profiles General, Silent, Meeting ,Outdoor ,Bluetooth and Power saving.

You can customize settings on profile and then activate corresponding profiles.

Phone Settings

- Time and date: Set the home city , Set time/date , Set format, on/off the function of Update with time zone .
- Language: Set the displaying language of mobile phone menus..
- Pref. Input method: Select one of the input methods as the prior. So while you write SMS, it will automatically display the selected input method by default.
- Display Settings: User can access this item to set wallpaper, Auto keypad lock and Show date and time.
- Dedicated key: Customize the shortcut functions of the Up, Left, and Right direction keys. In the standby

interface, you can press a direction key to directly enter the function menu corresponding to that direction key.

- Auto update time: You can use the automatic update function of time.
- Flight mode: You can use a flight mode.
- Misc.settings: You can set the LCD backlight brightness and display time.

Dual SIM settings

Choose one of them: Dual SIM open, Only SIM1 open , Only SIM2 open or Flight mode .

Network settings

You can search the network again. Select your favorite network and choose to register the network automatically or manually. You can also choose GPRS transfer pref. (Data prefer or Call prefer)

Security Settings

This function provides you with related settings about safety use.

- **SIM security**

PIN lock: The PIN (Personal identification number, 4 to 8 digits) code prevents your SIM card from being used by unauthorized people.

Change PIN: In general, the PIN is supplied with SIM card by the network operator. If PIN check is enabled, you need to input the PIN each time when you power on your mobile phone. The SIM card will be locked if you input wrong PIN code for three times.

- **Phone security:** Set the phone lock, the password is 1122 by default.
- **Mobile Tracker:** Open this function, when new SIM card insert your phone, after a period of time, it will automatically send the message to the setting number.
- **Privacy Protection:** Your phone gives you a good privacy lock here. The password is 1122 by default. You can manage the Phonebook, Messaging, Call history, Image viewer, Video player, File manager, keypad lock, Audio player.

Connectivity

- **Data accounts:** According to the GPRS parameters of corresponding operators.

Restore settings

Use functions to restore factory settings. The initial password is 0000.

Gallery

The phone supports the memory card, it also provides built-in flash. You can use the file manager to conveniently manage various directories and files on memory card.

Messaging

You can send and receive text message and Multimedia message. If the short message memory is full, a blinking message icon appears on the top of the screen. While entering the Messaging interface, you will see the following menu options: Write message, Inbox, Drafts, Outbox, Sent Messages, SIMS templates, SMS settings, SMS Export and SMS Import.

Multimedia

Camera

Use this function to take photos.

Image viewer

You can view the pictures or images through this function.

Video recorder

You can record videos through this function.

Video player

Use this function to play video files.

Music

Use this function to play audio files. In audio player interface, you can press */# key to tune volume, press Up key to change the repeat mode, press Down key to change the Shuffle mode, press Left/Right navigation key to switch to the last/next song.

Sound recorder

Use this function to record audio files. The phone supports amr format.

FM radio

You can use the application as a traditional FM radio with automatic tuning and saved channels. */# key to tune volume. While listening to radio, you can dial or receive a call normally. During call conversation, the radio will turn mute automatically. If some applications are using GPRS or CSD to send or receive data, they may interfere with the radio.

When the FM radio is activated, the mobile phone will display the number and name (if having been saved) and frequency of the radio channel.

Option menu:

- Channel list: You can edit and save 30 channels.
- Manual input: You can edit the specified radio frequency band. The frequency of the radio is between 87.5mHz and 108.0mHz.

- Auto Search: You can have automatic search and save the searched channels into the list.
- Settings: You can set the Background play, Audio quality, Loudspeaker.
- Record: You can record new files.
- File list: The record files.

Organizer

Calculator

This calculator provides limited precision and is only applicable to simple arithmetic calculation.

Torch

Switch on/off the torch here.

In addition, when in the idle screen, long press OK key to turn on/off the torch.

Calendar

Once you enter this menu, there is a monthly-view calendar for you. It also support Indian calendar.

Alarm

Five alarm clocks are set but deactivated by default. For each alarm clock, the time can be set with ringing alert.

World clock

Users can search for a city's current time.

Currency converter

You can make the exchange rate.

Bluetooth

You can transfer files via bluetooth when connected with other devices and listen to music, watch videos, call via bluetooth earphone.

Games

Enter it to play the games stored in the phone, it provides default F1 race and Game settings.

Internet

Internet service: It includes the following submenus, Homepage

SIM toolkit: It offers kinds of entertainments and applications by different operators.