

Tronsmart
TRANS-FORM YOUR LIFE


Draco AW80

Octa-Core Android™ Media Player

Quick Setup Guide


Overview

Before you set up your Tronsmart® Draco AW80, get familiar with the inputs on the Android™ TV BOX and the buttons on the remote control.





Number	Features
1	LAN Port
2	OTG Port
3	HDMI Port
4	AV Port
5	Optical Audio Port
6	DC 12V/2A Power
7	USB Port
8	USB Port
9	SD Card slot
10	SATA Port

Remote Control:










*Requires Two AAA Alkaline batteries

PS: Alkaline batteries are the forbidden objects in general air shipment, so Tronsmart® will not supply the battery. Please purchase AAA Alkaline battery in your local market.

-  **Power** To wake up or put the Draco AW80 into sleep mode
-  **Mouse** Display/Hide the mouse cursor



-  **Chose** To confirm a particular action, and as an “enter” key
-  **Home** Return to the home screen (Choose the launcher required)
-  **Play/Pause** Play/Pause when watch videos
-  **Back** Return to the previous screen running or cancelling an activity
-  **Volume-** Adjust the system volume down
-  **Menu** Call out the options menu for your current screen or running application
-  **Volume+** Adjust the system volume up

When use the Tronsmart® IR remote control, please make sure there are no obstructions between the Tronsmart® IR-Remote and the Draco AW80.

Other Control Methods

You may control the Draco AW80 with the following input devices:

1. Wired mouse
2. 2.4Ghz USB wireless mouse and keyboard set;
3. 2.4Ghz USB air-mouse / gyro-mouse (Tronsmart® branded mouse sold separately).

Chapter 1: Connecting Your Tronsmart® Draco AW80

What you needed

To start using Draco AW80, you need the following items:

- High-definition TV or PC monitor-That can display 720p,1080p or 4k video with at least one HDMI input
- HDMI Cable- To connect the Draco AW80 to your TV (HDMI cable included).

Network

A wired network cable or an 802.11 a,b,g,n or ac Wi-Fi wireless network (wireless video streaming requires 802.11g,n or ac).

Your wireless network name and password.

If you want to use 5.8G network, or 1000M Ethernet, make sure your wireless router support that;

A broadband Internet connection (DSL, cable or LAN)

Your wireless network name and password (if you use one)

Software and accounts

To play content (video, photos, music) from a smart phone or PC on the Tronsmart® Draco AW80 you will need:

- A UPnP/DLNA software pre-loaded on your smart phone or PC
- A Google account to sign-in to Google Play Store to download the corresponding applications (e.g. iMediaShare, eHomeMediacenter) necessary for streaming the content from a smart phone or PC.
- Other accounts may be required for full access to some internet contents.

Setp 1: Connecting your Draco AW80 to your TV:

Tronsmart® Draco AW80 connects to your TV through an HDMI port that delivers both audio and video. Before you set up Draco AW80, look at the ports on the back of your TV to make sure you have the right cables.

PS: You also can connect to your TV via the AV cable, but we strongly suggest you to use the HDMI cable to get the high quality videos.

Step 2: Connect your Draco AW80 to a power source

Important: Before you connect Tronsmart® Draco AW80 to a power outlet, carefully read these installation instructions:

Like most home entertainment products, your Tronsmart® Draco AW80 requests electricity to run.

- 1 Connect the AC adapter to the back of your Draco AW80.
- 2 Insert the power plug into a power outlet and Draco AW80 will power on directly

Important: Please make sure to use the 12V/2A power adapter which included in the package.

Don't place anything on top of Tronsmart® Draco AW80. Objects placed on top may interfere with the wireless signal. Don't place Tronsmart® Draco AW80 on top of other electronic equipment in a media cabinet.

Step 3: Turn on your TV and select the input

If you see just a black screen the first time when you use Tronsmart® Draco AW80, make sure the input setting you've selected on your TV matches the input you connected the cables to on your TV or home theater receiver.

Chapter 2: Quick Setup your Tronsmart® Draco AW80

Wi-Fi setup (basic)

To connect to your wireless network follow these steps:

Launcher Home Screen > Settings > Wi-Fi > Check the option
“To see available networks turn Wi-Fi on”

Wi-Fi will turn on and automatically scan the wireless network available, then select the wireless network that you wish to connect to and confirm, key-in password of the Wi-Fi network when the virtual keyboard prompts, finally hit the “Connect” button.

Language Setup

You may choose the desired system language by following these steps:

Launcher Home Screen > Settings > Language & Input >
Language

The default language is English, you may choose your desired language and confirm.

Time Zone Setup

You should adjust the time zone according to your current location by the following steps:

Launcher Home Screen > Settings > Date & Time > Select
Time Zone

Choose your time zone and confirm.

Ethernet Setup

You should connect your wired network cable to the Ethernet port on Tronsmart® Draco AW80, follow these steps:

Launcher Home Screen > Setting > Wi-Fi > Turn off the Wi-Fi
and then choose Ethernet, Turn on.

HDMI™ Output Setup

You can adjust the HDMI output resolution by following these steps:

Launcher Home Screen > Settings > Display > HDMI Mode