

## SPECIFICATION







The Kenxinda Power Bank is a fully rubberized and waterproof high power battery for outdoor use. Suitable for all products that can be charged with a micro USB cable or USB cable according to our specifications.

## OPPERATING INSTRUCTIONS

- 1. For the first use, please charge the product min.8-9 hours
- 2. During the charging process,the diodes will flash. When the Power Bank is fully charged, all four diodes will light up.
- 3. Press power button to check capacity, there are four LED lights to indicate the capacity

light	1 ON	2 ON	3 ON	4 ON
Capacity	<25%	25%-50%	50%-75%	75%-100%

4. Torch:Click one time torch button for 20% brightness and twice for 100% brightness

## WARNING

- . Do not disassemble and destroy the product
- · Do not expose fire and high temperature
- · Please close to closure flap to push into water
- · Please use the original power adapter to charge this product







POWER BANK(size:106X76X30mm weight:360g)USB cable with micro USB



