

**zopo**

**ZP320**


**Smart phone Quick Guide**

**More information**

You can search our mobile phone models and feature  
In our website, and can select more accessory for your  
phones.

The phone model in different countries may be different.

# Parts description and preparation



Open the notch on the lid,  
Then pull lightly along the lid cracks.


Notice: In accordance with the instructions,  
you should be prompted to insert,remove the  
batteries to avoid unnecessary damage to the  
body or battery.

Plug the battery  
Keep battery metal contacts and fuselage battery  
contactor alignment, then gently press down to  
push the battery into the phone smoothly.

# Gesture Operation


## Gesture Sensing

You find **Gesture sensing** under Settings interface and open it, after learning gestures action, you can select the corresponding application, then you can use gestures to control your application to perform the corresponding functions.




## Smart Wake

You find **S Smart Wake** under Settings interface and open it, after selecting and opening the corresponding function, you can use gestures to perform the corresponding function under screen-off status.



# Basic Function

## Power On



1. Keep press the power button (power icon), until screen turn on.
2. Please wait for seconds for power on.

## Unlock and Lock screen

### Unlock




Press (power icon) button quickly, and drag the ring to unlock.

### Lock Screen

Press the power key (power icon) in any interface, then the mobile phone will enter standby model.

## Keys



- Menu Key : Enter for fast setting
- Home Key : Enter to desktop
- Back Key : turn back to last menu

# Shortcuts

## Desktop

Unlock the desktop, you can click the icon to open the corresponding application Change wallpaper, open the file.Also can slide the desktop to get more applications.



### Enter Desktop

Desktop enter key (house icon)

### Browse Desktop

Slide the screen

## Desktop Gadgets

Desktop gadgets is a shortcut to enter the APP. You can use it directly at desktop, eg: desktop weather gadgets can let you know the weather information anytime.

## Applications Menu

You can enter the application menu from home key after unlock the screen, press (app icon)

### Start Applications

At application menu, touch the APP you want.

## Notification Bar

At top of home /main menu, it displays the mobile phone signal. Battery power , new message and other notice.

### Checking the notice

One finger pull down from the top of notification bar.

### Quick menu

Use 2 finger to pull down from the top of notification bar. You can turn on/off fast for WLAN,Bluetooth,GPS and etc function.

# More Basic Function

## Dial


Press (phone icon), through to search contacts or enter the phone number then press (dial icon) to dial out.If want to delete the number, please press (delete icon).

### Call ends

Press (end call icon) key during the calling.

### Incoming call

When have call coming, slide the ring to (answer icon) to receive.



## Message

### Sent message

- 1.Press (message icon) enter the message menu
- 2.Press (compose icon) to create new message
- 3.Press (contacts icon) to add one or more contacts.
- 4.Press (+ icon) to sending text or inserting pictures, face,video.etc
- 5.Press (send icon) to sending when finish edit.

## Phones Setting

- 1.Find (gear icon) in application menu. Touch it enter the setting menu.
- 2.Touch (three horizontal lines) menu key under the home menu, then press (gear icon) to enter the system settings.
- 3.Enter quick menu,touch (gear icon) enter system setting.