1 Release the battery cover

Unlock and take off the back cover, then open the seal cover.

4 Replace battery cover

Install the battery correctly then press the seal cover tightly. Finally fix the back cover and lock.

2 Insert the SIM card

Insert SIM into the phone as shown (contacts face down).

3 Insert Micro-SD card

Insert SD card into the phone as shown.

5 Charge for 6 hours

Please charge for 6 hours before initial use.

Keypad Description

Receiver

Distance/
Light sensor

Front
camera

Power key

Home

Menu

Microphone

Back

Main
camera

Sub microphone

Torch

Loudspeaker