

LED Touch watch Instruction Manual



time:12:00



Date:1th JAN



Secon: 35

Function & Specifications

Key Features

How to see the time and date

How to adjust

the time and

date

There are 28 bright LED display: hours, minutes, month, day With one key control the touch function Battery: CR2016 6V

A---Touch function, Function to set key, Adjustment.

In static mode, the bottom close to the wrist, hand-to-A key does not move for two seconds to wake LED light display hours, minutes, release the hand, then touch the A key again to display the date

1) Normal display mode, the bottom close to the wrist, hand-to-A key does not move for 2 seconds when the hour flash, then to touch the A key, you can adjust the hours.

2) After the hours is adjusted, touch the A key does not move for two seconds, minutes flash, then release the hand, touch the A key, you can adjust the

3)After the minutes is adjusted, touch the A key does not move for 2 seconds to enter the date adjustment status, now the months flash, then to touch the A key, you can adjust the months.

4) After the months is adjusted, touch the A key does not move for two seconds, date flash, then release the hand, touch the A key, you can adjust the date.

5) After the date is adjusted , touching the A key does not move, then complete adjustment and return to normal display, after 3 seconds turn off the lights.