

Welcome to use the third generation network video Call NVC802W which can follow this guide that let you fast and easier to do the quick installation.

I. Device Connection

1. Insert the 3C number card into the slot.



2. Connected to the wifi antenna



3. Power on the device

II. Wifi Settings

After the device is properly connected, press the "ok" button to enter the device menu interface.



Select Network—wifi— enter wifi setting interface



Choose your own wireless router, and input password, then select OK.



Back to the login screen, then appear Icon , indicate successful connection Wifi.

III. Android and IOS access setting (Android and IOS) Please download software "Phonescam" from Google play,

Android software download address:

https://play.google.com/store/apps/details?id=com.phonescam&hl=zh-CN




Please download software "Phonescam" from App store, IOS software download address: https://itunes.apple.com/cn/app/phonescam/id717831430?mt=8



After installing the software, select the software and download phonescam into the software interface, for the first time need to register, as shown below:



You can choose registered mail or phone, after successful registration, the software automatically login.



Follow the above steps to complete a simple set NVC802W, you can learn more about NVC802W, pls login to our website, and to download details user manual.

IV. More Function

1. Access Password Settings. Enter General Settings—Access Password as below image shows:



Default password is empty or you can set up your password as "123456" or other No. without "0" at the beginning.

2. Add Contact

Open PhonesCam, choose contact menu, find the add button, and choose add



device

Add Device: Add the device NVC802W's 3C NO.

Add Contact: Add the automatic account assigned by mobile phone software system when first registration.

Add the 3C Number of NVC802W into the device list as below image shows:



The first line: 3C number:

The second line: Device name which can be arbitrarily named;

The third line: Access password of NVC802

Click "Save" after above three lines and enter the contact interface again.

3. Wireless Alarm Settings



Image 3.1

Cling to the complete set of wireless alarm tightly together, and enter the contact interface to click the contact you added and then the settings dialog appear as below image 3.2 shows:



Image 3.2

Set the selection of Settings - Protection Zones.

There are 9 zones settings in the protection zone setting interface like image 3.3.





Image 3.3

Image 3.4

You can choose your wanted zone like "Hall":



Image 3.5

Click one of number from 1-8, there is a dialog interface appearing:



Click ok and then separate the wireless alarm system like image 3.7 show. Alarm will flash red light, and the software will have learning success tip.



Image 3.7

Come back to the settings interface after done successfully and choose alarm settings.



Image 3.8


Let the mobile phone software account bind into the alarm Settings on alarm interface as image 3.8 shown. So it will send alarm message to your mobile phone when the alarm occurs.

4. Remote Controller



Image 3.9

SOS:	Emergency	Call



Open the protection after the wireless alarm settings to complete the entire alarm Settings.

Or you can open the protection by enter the device PhonesCam settings interface.

According to the above steps, the device NVC802W simple Settings finished. If you want know more about NVC802W, you can login this website and

http://share.weiyun.com/193379f70ccbcc0f5ed0017688bcb412



download the manual