To Customers

Dear Customers:

Thank you for choosing inWatch Z.

To helpyou use inWatch Z better, please read this user guide and After Sale Service Manual carefully before you start using your inWatch ZWe think itoffers a brand new experience in both fashion and intelligent technology.

We hope that inWatch Zoffersyou everything you want in a smart watch.

And we hope inWatch Zwillbe your fashionable and convenient companionevery single day.

Best regards

inWatch Technology

A Look At Your inWatch Z

Hardware and Design of inWatch Z

When you open the package, please check to make sure that the box includes:

- 1, inWatch Z
- 2. inWatch Z USB charger
- 3. Smart watch adapted USB cable

Power key/ Screen lock key

Press this key to turn on/off the watch and lock the screen.

Please input the password if needed.

Continue to press the power key for 15 seconds to reset the watch, which has the same effect as removing and reinserting the battery.

Introduction

Please read below before you start yourunique journey with your very own in Watch Z:

Please turn your inWatch Z off when you are near chemical plants, gas stations or other explosives.

Please don't use inWatch Z during flight.

Pleased on't use near heart pacemakers, hearing aids and other medical electrical equipment; your inWatch Z will interfere these devices.

Please don't disassemble, repair or modify inWatch Z. Please contact our postsale service center if there is any problem.

Please keep your inWatch Z away from magnetic materials, such as disks, credit cards and so forth, in order to avoid degaussing.

Please do not expose your inWatch Ztoextreme temperatures. Prolonged direct sunlight or humid environments should also be avoided. (Please see Environmental Requirements)

Please do not use liquid or a damp rag with detergent to clean your inWatch
One.

When recording audio, photographs or video with inWatch Z, please do not engage in illegal or unethical behaviors as it mayviolate local laws and regulations.

(Remarks) This manual is to be used with the English language mode of operation.

(Warning) We hold no liabilities for any direct, incidental or consequential damages resulting from improper use.

The actual device may not always match the content and material herein; please refer to the actual device.

Hardware and Design of inWatch Z

inWatch Z supports a micro SIM card. Itcan save a lot data for communication. You can save your personal information, including PIN code, contact list, messages and other data from extra system services.

Before using inWatch Z, pleaseopen the SIM card slot and insert the SIM card into the tray. Warning: Pleasedon' t twist or scratch the SIM card, and keepit away from static electricity, dust and water.

Please turn off inWatch Z before you install the SIM card. Put the SIM card into the watch as illustrated below.

Warning: Pleasekeep the SIM card and tray away from the children.

Using the inWatch Z Bone Conduction Speaker

The rectangular rubber pieceon the wrist band is a bone conduction speaker. Press it againstany flat object (i.e box, desk etc.), and the sound emittedwill be amplified, allowing for operation as a speakerphone.

Bane conduction

How to Wear inWatch Z

When putting on your inWatch Z, please align the dasp, push from behind slightly then press down.

How to Adjust the Wristband

After adjusting the size of the wristband, the position of the daspwillbe different. You need to adjust the steel pinto find the most comfortable wristband

How to Use the Included USB Charger

inWatch Z uses external conductive contacts to charge. Open the included charging dip and align it to the contactsunder the wristband, dose the clip and connect the included USB cable for charging.

inWatch Z features a built-in 580 MAH battery, the performance of which could be influenced by many factors such as network configuration, signal strength, temperature, user settings, and mobile phone accessories used besides voice, data or other application modes.

In order to achieve the best battery performance, please observethe following quidelines:

It takes a longer time to charge anew battery or one that has been unused for a prolonged period of time.

When charging, keep the battery at or near ambient temperature.

As with all rechargeablebatteries, after long-term use it will take a longer period of time to charge due to gradual capacity loss. Please note that this is a normal phenomenon.

If battery is unused for some time, or when battery power is low, a certain interval of time is needed before the normal charging display screen appears. Please wait patiently.

If the watch is off whilecharging, the screen will display an image similar to the one below.

1. The Main Page

When first turning on inWatch Z or pushing the "HOME" button, the main page will display the time, telephone icon, camera icon and date. Touch the date and time toswitch to weather.

When a user is on the main page, they can scroll by swiping down or left, as shown below.

In general, the screen will display the following content when you swipedown on the main page: time, date and inWatch Z's basic settings, including airplane mode, battery level indicator, WLAN, GPS, data comection, volume etc.

2. App Center

The App Center includes the followingbasic apps: Calendar, Calculator, Clock, E-mail, Camera, Photo album, Music, Video Player, Voice Recorder, To-Do List, Document Manager, Settings, Telephone, Contacts, Messages, Browser, Compatible, Ledongli (exercise app), Voice Assistant.

Tapthe "Application" icon to enter Application Center.

3. Dialing

inWatch Z can keep a history of incoming, outgoing and missed calls.

Touch the "Phone" iconto enter dialing mode:

- 1. Input a phone number, then press the "Call" button.
- 2. Press "Call Record" at the bottom-left corner to access the list of recent calls.
- Press "Contacts" in the lower-right corner to accessyour list of contact names and phone numbers.

Note:To make international calls, press "0" for a few seconds to get the symbol "+", then input the country code(no need to add "00") and phone number.

4. Telephone

Tapthe "Phone" icon to access the dialing page.

When onan incoming or outgoing call, the screen will display the calling page, which will show the call status and the call so contact information.

Tapthe upper-left icon to open or cancel "hands free" .

Tap theupper-middleicon to nd the call.

Tap theupper-right icon to mute or unmute the microphone.

Tap thelower-left icon to open the keyboard.

Tap thelower-middle icon to pause the call.

Tap thelower-right icon to add more contacts to the call.

5. Input

inWatch Z uses the Sudoku input keyboard and handwriting input method. inWatch Z also has the YunZhiSheng voice input system built-in. You can change the input methodon the "Language and input" Settings screen.

6. Calculator

inWatch Z features a simple built-in calculator.

Tapthe "Calculator" icon in the App Center to access the calculator.

Because of the inWatch Z' s limited screen space, the calculator's input keyboard is divided into two sections. You can swipe left and right to switch

11. Album

Tapthe "Messages" icon in the App Center to access the messagingapp.

Tapthe message that you want to read to display its full content.

Tap theicon in the upper-left corner to edit the messages list.

You can type number in "To" field, or select a contact from address book.

You can composenew messages in the "Type" field. Touch "send" button to deliver the message after finishing editing.

inWatch Z supports the sending of MMS content. Touch the "+" at the lower-lef corner of the screen to add anattachment.

inWatch Z can store pictures taken with the built-in camera to the photo album.

Tapthe "Album" icon in the App Center to accessthe album, where your photos will be arranged and displayed.

You can also create individual albumsto manage your photos more efficiently.

Touch the cover of the album to open the albuminWatch Z will displaythe album's photos in a grid. Touch each picture to view in full-screen mode.To check the next or previous picture, dragto the left or right.

8. Contacts

Tapthe "Contacts" icon in the App Center to access the contacts page.

Contacts are arranged in alphabetical order, and only names are displayed on the first page of the phonebook.

You can typethe name of the contact you want to access in the input box at thetop of the screen to search.

There are several locations to save contacts' information, including: inWatch memory, micro SIM card and to a smart phone set up forsynchronization with your inWatch.

Contacts' information include: name, company name, three phone numbers(mobilenumber, homenumber, worknumber), e-mail, fax number, chat icon,etc.

After dialing anumber on the calling screen, you can touch the lower-right corner to access the "Contacts" page. Then tapping the "create a new contact" button on the bottom, you can add the number to the phonebook.

12. Music Player

inWatch Z sbuilt-in a music playersupports the use of aBluetooth headset. Supported formats include: MP3, WMA, WAV, 3GP, MP4 and WMV.

Touch the "Music" icon in the App Center to enter the music player.

The Player page shows the information for the song that is currently playing. You can pause or continue playback by tappingthe middle of the screen.

Tapthe upper-left corner to access the playlist.

You can play a song by tappingits title on the playlist page.

Tapthe upper-right corner to toggleshufflemade on or off.

Tapmiddle-left to replay the currently playing song. Tap it twice togoto the previous song.

Tapmiddle-right to skip to the next song.

By sliding your finger across the playbackprogressbar you can adjust the playback volume.

9. Calendar

Tapthe "Calendar" icon in the App Center to access the electronic calendar.

inWatch Z's built-in calendar can displaythe solar calendar, Chinese lunar date and solar term. You can choose to display by month, week, or day.

To create an event, select the date and time you need. Enter the event information such as event name, location, time etc.

13. Video

inWatch Z features a built-in video player. The playback formats supported include: AVI, RM, RMVB and ASF.

Tapthe "Video" icon in the App Center to enter the video folder. Video preview screens are displayed in a grid. You can tapany preview to play the video.

After accessing the playbackscreen, the current video's name will be displayed at the top of the screen, you can tapthe button next to the name to share the video.

By tapping the middle of the screen, you can pause or resumevide oplayback.

The bar at the bottom of the video displaysplayback progress.

Tapthe lower-right corner to enter full-screen mode.

10. E-mail

To setup your email account when you use it for the first time select the email setup assistant Input your password to complete account configuration. You can then write and receive emails.

14. Clock

inWatch Z's built-in clockfeatures alarms, a timer, and a stopwatch.

15. Audio Recorder

Tap theplay key to start to recording, the upper middle of the screen is the timer, after you finish recording, touch the icon. *?* to save or cancel.

16. ToDo

ToDo allows you to setup reminders to help you stay on schedule.

17. Document management

You can viewall the documents in your inWatch Z's Android filesystem, and can change the way it is sorted order. You can also set up a new folder and edit its contents.

18. Voice Assistant

You can open the main menuand call someone usingvoice commands (i.e tapthe microphone icon and say: open camera, or open message, or call "Gary", etc.)

19. inclub

1) Download inClub

You candownload inclub from the inWatch's official website, or search it from the AppMarket.

2) inClub function

inClub is an application to connect your inWatch Zto inWatch's cloud services. Input your inClub ID to login iCloud provides private cloud storage, quick setting the smart watch, remind you the incoming call and message from the cell phone inClub is still under development and more features will be added in future updates.

3) inClub operation instruction

- a. Download and launch the inclub app on your smartphone. Make sure that Bluetooth is enabled on both your smartphone and in Watch Z, and that they are within connection range of each other. Pair them from within their Club app.
- b. Use your Baidu ID to register and login(Your BaiduID will serve asyour inWatch ID)
- c Tapthe upper-right corner to find "account management" and set up your account information. This includes youravatar, nickname, WeChat QRcode, etc.
- d. Touch the upper-right corner to find "watch setup". You can quickly set up incoming call reminders, message reminders, and set the device's time here.
- e. Touch the upper-right corner to find "Check forupdates" to check if any software updates are available for the inWatch Z.

20. Compatibility settings

If a third-party app does not display corrently, try activating this option. The inWatch $\mathbb Z$ s operating system will attempt to adjust applications to better fit the device's display.