


ACE-001


Quick Start Guide

ACETECH

Equipment parts drawing



Equipment parts drawing



Operating instructions

1.Horn switch

- a.Press The Horn Switch button, can ring
- b.Pressing The Horn Switch button 30 Seconds,
The dashboard mileage reset

2.The headlight button

- a.Press The head light Button, Headlight and back light work

3.Power switch lock

- a.Put key in power switch lock, clockwise electric power supply,
Turn off the power supply and vice

4.Folding switch lock

- a.Folded up folding pull switch lock

Operating instructions

5.Instrument panel



Running speed

Headlight


The total mileage of driving

DST trip distance

Dump energy

Operating instructions

6. Foot Plate




ACETECH

6

Operating instructions

7. Support




ACETECH

7

Operating instructions

8.Folding




ACETECH

8

Operating instructions

9.Unfold



ACETECH

9

Technical parameters

1. Motor parameters

- a. 48V 350W.
- b. Max Speed 35KM/H

2. Charger parameters

- a. INPUT 100-240V 50/60Hz 2.2A (MAX.)
- b. OUT PUT 54.6V --- 2A

3. Battery parameters

- a. 48V 11AH high-energy lithium polymer battery
- b. Charge time: 3-5Hours

4. Maximum load

- a. Maximum load: 150KGS

5. Maximum Distance

- a. Maximum Distance Range: 35KMs

Technical parameters

6. Size:

- a. Unfold size 1156mm*1035mm*578mm
- b. Fold size 1160mm*632mm*308mm

7. Net Weight

- a. Net Weight: 30KGs

Attention

- 1. Do not exercise for a long time or stay in the rain
- 2. Shall not be soaking in the water
- 3. Need to stay away from fire and high temperature object
- 4. Not overload
- 5. Shall not be in the hot sun exposure