

LED PROJECTOR USER MANUAL




Remarks

- ♦Thanks you for your interest in this projector, please read this manual book carefully before using the projector.
- ♦To ensure stable power supply, please use national standard power cable and power cord with grounding.
- ♦Please use the power supply and power cable indicated on the projector or the manual.
- To protect your eyes, please do not look into the lens while the machine is working;
- ♦While working, the projector should be kept away from cloth, sofa or any other material that could have stock the ventilation holes. And no flammable and explosion materials should be put around the projector.
- ♦To prevent electric shock, the projector and power adaptor should be kept away from water as they have no water-proof function; no such apparatus as vase or cup should be put around the projector
- ♦The projector should be put in the place with good ventilation, dry and clean condition, and avoid vibration, heat and radiation.
- ♦Please turn off the projector and cut off the power supply, if it will not been used for long time.
- ♦If any trouble is found for the projector, please cut off the power supply first. Customer please does not dismantle the projector without authorization, or the company bears no obligation for free maintenance service.
- ♦The projector might be different from description in the user manual because of the software update, please subject to the projector, use manual is for reference only.

5. Product details



6. Button function



Enter: confirm the choosing item;

Left: move left, up and volume down; Right: move right, down and volume up;

Input: Choose the signal input source; exit the current menu or back;

Power button: power on and off.


Product Feature 1

- ♦The professiona appearance design for ventilation has largely improved the stability and life time for the projector;
- The LED lamp can works for over 20 thousand hours, and can provide beautiful colors;
- ♦ Manual focus adjusting, get picture from 20 to 60 inches;
- ♦ Professional trouble shooting and protection measures;
 ♦ The projector is small and light, easy to carry with;
- ♦ Easy changing in 16:9 and 4:3 aspect ratio;
- Low power consumption, echo-oriented; Multi-function interface: AV, VGA, SD, USB;
- Vehicle power supply supported, easy to use;

Fittings

User manual	1 pc
Power adaptor	1 pc
3 in 1 AV cable	1 pc
Remote control	1 pc

7. Remote Button function



8. Function operation

8.1. Power on and off

Stand-by status: After the projector is power through adaptor, it goes into stand-by status, and the red indicate light flashes; Power on: Press the power button once, the indicator light stops flash, the projector start works.

Power off: Press the power button once, the projector is off, and the indicate light starts flash.

8.2. Focusing

Take the table of projection size and distance table for reference Put the projector at a certain place within the distance scale, and then rotate the lens to make the picture clear.

3. Specifications

Model		Im age sy ste m	LCD
Native Resolution	320*240	Supported resolution	1920*1080
Lamp	LED	Input Voltage	12V .
Lanuguage	English etc	Brightness	48 Lux
Contrast	300:1	Lens	F=125
Im age size	20—80Inches	Projetion distance	1.25-4.0m
Color	16770K	Projection mode	Front projection
Power waste	24W	Speaker	1.0W *2
Weight	0.38K G	Size	.127*126*56.6m m
Operation mode	Manual remote control	Working Temp	-10-36℃
Output	Head phone	Input	AV/VGA/USB/SD/HDMI

4. Multi-media support files

File	Format	Sub-fix	Decoding
A udio files	WMA	.wma	
	M P3.	.mp3	
	M 4A	.m4a	
Image files	JPEG.	.jp g	
	BMP.	.bmp	
	PNG	.png	
Video files	M PEG1.	.dat\.mpg\.mpeg	
	MPEG2.	.mpg	
	M PEG4	.avi\.mp4	DIVX,XVID
	RM 、 RM VB	.rm\.rmvb	RV8\9\10
	H264	.mkv\.mov	M PEG1,2,4
	MOV	.avi\.mp4	11111111111
	MJPEG	.avi	The har an
	FLV	.flv	H264
	VC1	.wmv/.asf	vcl
	DivX、	.DIVX\.AVI	M PEG, DIVX

Remarks:

If you want to play any files that is not included in the above table, you might encounter troubles, and please transform the format first so as to make it play smoothly and normally.

Remarks:

While using the projector, please connect the power adaptor with the projector first, and then connect the power adaptor with the power.


8.3 Menu Operation

8.3.1 Input source selection



Press "source" button on the remote control or "input" on the projector to get the source menu, then press "OK" button on the remote control to confirm the input source you need.

8.3.2 Picture menu operation



Press "OSD Menu" to enter into the main menu and press " ◀/▶" to each sub-menu.

8.3.3 Multi-media menu operation



Insert the USB or SD first, and then choose Media from source menu. Then choose the icon for different files and press OK to confirm.

By this menu, you need to play video, photo and music correspondently with the icon showing.

Remarks: You can only insert the USB or SD on at a time, or the projector can not recognize any of them.