

Model: L3
USER GUIDE

IN THE PACKAGE





4

User guide








Ground insert






If any item is missing, or if any part of your product fails to operate properly, please contact your dealer immediately.

PRODUCT DIAGRAM





LOADING BATTERY



Spin the battery cover according to the "OPEN" arrow direction.



Remove the cover.



Load three C batteries.



Spin the the battery cover according to the "LOCK" direction until the cover locks.

Note: If the batteries are loaded correctly, the LED light will flash 3 times

Please take out the batteries if you do not plan to use this product for a long time.

<u>INSTALLATION</u>

1. Indoor use:

Place the light on the flat places such as the table and book shelf, or use the hook to hang it in places such as the cabinet.



2. Outdoor use:

Insert the pole(s) to the light, and thrust the ground insert into the ground for outdoor places such as the lawn. There are 2 poles provided in the package. You can combine the 2 poles as a longer pole to keep the light at a higher height.

LIGHT MODE SELECTION



This product offers 3 modes:

- Off
- Motion detection

mode vou desire.

• Always on Press the button to choose the


Note: The light will not be turned on automatically in a bright environment (> 9 lux). In a low-light environment, the light is turned on automatically when a movement is detected, and will be turned off a short time after no movement is detected. There is a red LED indicator fickering when the product is set on the motion detection mode.

SENSOR RANGE



The optimal height to install this product:

1.6-6.6 feet (0.5-2 meters)



Radius: 26 feet (8.0 meters)

<u>SPECIFICATIONS</u>

Light -	LED
Power	0.5 W
Luminous power	43 lm
Color	White
Waterproof	Supported
Power supply	3 x C alkaline batteries (not included)
Motion sensor detection range	~26 feet
Motion sensor detection angle	~110 degrees
Mode	Off / Motion detection / Always on
Motion and light detection mechanism	The light will not be turned on automatically in a bright environment (> 9 lux). In a low-light environment, the light is turned on automatically when a movement is detected, and will be turned off a short time after no movement is detected.
Estimated battery life	Always on mode: ~110 hours Motion detection mode: ~8.5 months (based on the assumption that the light is automatically turned on about 10 times per day)

Note: The design and specifications of this product could be amended at any time without prior notifications. There might be some differences between the product and the description in this manual.

3