

## User Guide



## Keys functions description



Functions Description	
1. Menu key	9. USB jack
2. Home key	10. SOS key
3. Back key	11. Camera/Torch key
4. Proximity Sensor	12. Rear cover screw
5. Front camera	13. Speaker
6. Earphone jack	14. Rear camera
7. Volume up/down key	15. Flashlight
8. Power key	16. Hand strap insert









## With my iMAN i3 I want to...










Make a call	Phone(or in the standby mode) Select  to enter dial screen) Input the number Press  icon to dial
End a call	Press  icon
Add a new contact	Phonebook Press  to add new contact Edit When finished editing, select <b>Done</b> to save
Send a msg	Messaging Press  to write message Edit recipient or select contacts from phonebook Edit content Once done typing, press  to send
Browser	Browser Input URL Select <b>Go</b> to open web page
Music	Music touch & hold a listing (artist, albums, songs, or playlists) Select a song to play
FM radio	Plug in your earphone

	FM radio
Take a picture	Camera (Press  to switch to camcorder) Press  to take pictures
Turn on Bluetooth	Settings Select Bluetooth to turn on/off
Wi-Fi	Settings Select Wi-Fi to turn on/off Press Wi-Fi Select one access point(AP) Connect(Input the password if the AP is locked)
Camera/torch key	When screen is locked, long press the key for 3 seconds to light the torch on/off When screen is unlocked, long press the key to enter Camera, short press to capture pictures
SOS key	When the phone is on, pressing SOS key and Volume up key at the same time will activate SOS dial

Accessories in package	
Phone	1 piece
Battery	1 piece
Travel charger	1 piece
Headset	1 piece

## Safety Instructions

	Do not make or receive handheld calls while driving, and never text while driving.		Do not use at gas stations.
	Keep your phone at least 15 mm away from your ear or body while making calls.		Your phone may produce a bright or flashing light.
	Small parts may cause choking.		Please do not dispose of used batteries in the trash. The proper disposal of your waste battery will help to protect the environment and human health.
	Your phone can produce a loud sound.		Avoid contact with magnetic fields.

	Keep away from pacemakers and other electronic medical devices.		Avoid extreme temperatures.
	Switch off in hospitals and other medical facilities when requested.		Avoid contact with liquids. Keep your phone dry.
	Switch off in aircraft and airports when requested.		Do not disassemble your phone.
	Switch off when near explosive materials or liquids.		Please use only authentic accessories with this phone, and do not use the battery with any other type of phone.
	Do not rely on your phone for emergency communications.		