USER MANUAL




S1

Contents		
1 GET STARTED	.1	
1.1 CHARGE BATTERY		
1.2 Install&take out SIM Card		
1.3 SWITCH PHONE ON AND OFF		
2 INPUT METHOD		
3 MAKE & ANSWER CALL		
3.1 Make calls		
3.2 Answer calls		
3.3 ADJUST VOLUME		
3.4 H-free		
3.6 CALL OPTIONS.		
4 CONTACTS		
5 CALL CENTER		
5.1 CALL LOG		
5.2CALL SETTINGS		
6 MESSAGING		
6.1 Enter message		
6.2 INBOX	4	
6.3 Drafts		
6.4 Outbox		
6.5 SENT MESSAGES		
5.6 MESSAGE SETTINGS	4	
7 MULTI-MEDIA		
7.1 MUSIC PLAYER	4	
7.2 Record.	2	
7.3 FM Broadcasting	4	
7.4 FILLE MANAGEMENT		
B TOLL BOX.		
8.1 Calandar		
8.2 ALARM CLOCK		
8.3 CALCULATOR		
5.3 CALCULATUK		

9 SETTINGS	5
	5
9.2 Shortcut	6
9.3 Phone settings	6
9.4 Network settings	
	6
	6
9.7 RESTORE FACTORY SETTINGS	6
10BLUETOOTH	7
10.1BLUETOOTH	
10.2 RIJIETOOTH DIALER	8

VOUR PHONE

FRONT/ROTTOM VIEW




Kevs Instruction:


- 1: earpiece/loudspeaker
- 2: display screen
- 3: function key
- 4: SIM Card
- 5: dial key
- 6: microphone
- 7: back key
- 8: end key

Tips: to start up, turn on power switch and press on/off key.

Sketch map







1 Cet started

1.1 Charge battery

In Charge battery
 Insert one end of charger to jack of phone and another end to outlet.
 Note: this phone can be charged with USB cable of computer.
 ♦ Battery indicator presents dynamic display during charging process

until fully charged.

1.2 Install & take out SIM card

The phone supports one SIM card (minSIM card). Please ensure the phone is power off and not being charged when conducting following operation.

A Make golden contact of SIM card upward, gap of card close to SIM card slot and insert SIM card to slot.

♦ Take out SIM card and flip with fingernail, it will popun.

⇒ Take out sint card and flip with ingernal, it will perform and off
 ⇒ To switch on or off, press end key for a long time.
 ⇒ If there is SIM lock, input PIN code to switch on.

2 Input method

The phone supports multiple language inputs. To switch input method, press "#" on edit page and press corresponding keys on keyboard to finish input.

3 Make & Answer Call

3.1 Make call

To make call, input phone number in standby interface and press

To delete input phone number, press right function key.

To end call, press end key.

3.2 Answer call

To answer call, press dial key; to reject call, press end key.

To end call, press end key.

3.3 Adjust volume

To adjust volume during calling process, press navigation key.

3.4 H-free

To open or close hands-free during calling process, press right function key.

3.5 Call waiting

Start call waiting function during multi party call. If network supports call waiting and you start this function, then the network will inform you about a new incoming call while you are talking. You can answer or reject new incoming call.

Open or close call waiting in "call waiting" function.

3.6 Call options

To enter call options during calling process, press left function key.
Call options are Hold or End call, Contacts, Call log, Messaging,
Record, Mute and Volume, etc.

4 Contacts

This function allows to view and manage phone numbers in phone as well as SIM card.

4.1 Contacts list

♦ Select contacts list in main menu to enter.

Contacts list displays default phone record, press "option" to enter menu, select "contacts settings->primary storage location" to reset phone record to be displayed.

♦ Conduct following operations in list page:

- To add phone number in SIM card or phone, select "add to contacts":

-To look up records, press navigation key;

- To view phone numbers, press number key (based on input method):

- To call current phone number, press dial key;

- To enter option menu, press left function key, execute corresponding function through menu;

4.2 Option menu

You can execute following operations in option menu of contacts:

♦ View: view detailed information of current contacts;
 ♦ Send message: send message to assigned contacts;

♦ Call: call selected contacts:

♦ Edit: edit materials of current contacts:

♦ Delete: delete current contacts:

♦ Copy: copy current contacts;

♦ Contacts settings: you can conduct following operation:

1. Primary storage location: select primary storage location; 2. Speed dialing: assign a phone number to one of the speed-dialing

key and press corresponding keys for shortcut calling;

3. Other numbers: set fixed dialing;

4. Storage status: check storage status of phone and SIM card;

5 Call center

5.1 Call log This function records related call log and you can view current call log here.

5.1.1 Missed call:

This function records number and name of recent missed call.

Press left function key to enter option menu, you can view, call, send message, save to contacts, edit before call and delete, etc.

5.1.2 Dialed call:

This function records number and name of recent dialed call. The operation refers to that of missed call.

5.1.3 Received call:

This function records number and name of recent received call. The operation refers to that of missed call.

5.1.4 Delete call log:

This function deletes existing call log.

5.2 Call settings 5.2.1 Call waiting:

Open or close, inquire current status. Note: need support of network operator, please consult local network operator for further information.

5.2.2 Call forwarding:

Unconditional forward, forward on busy, forward on no answer, transfer on no arrival, cancel forward; note: call forwarding function needs network support, please consult local network operator for further information.

5.2.3 Call barring:

All calls, incoming calls, incoming calls if abroad, international calls, international roaming calls, cancel all restrictions and modify password of call restriction. Note: some network operators limit use of the function, please consult local network operator for further information. Network operator will offer original network password when you apply for this service.

5.2.4 Line selection: Select line 1 or line 2

5.2.5 Advanced settings:

♦ Automatic redial: open or close automatic redial; once open, the phone will redial number if fail to make call.

♦ Holding time prompt: after opening and setting, prompt will be given when reaching set time.

Answer mode: set any key to answer or earphone mode for automatic answer.

6 Messaging

6.1 Enter message Text messages:

♦ Enter messaging interface, input message content, enter option menu by pressing left function key and switch input method by pressing # key.

Select "option" to enter menu, select options of "send to, input method, set Cstar, advanced option and save to draft", etc.

♦ In edit page, select "send to" or OK key to enter number input page:

- Input number: directly input number

- Add from contacts: select recipients from contacts and send to multiple persons:

♦ Input number of recipients and press OK to send message.

6.2 Inbox

Inbox stores and manage received messages.

Enter inbox, press navigation key to select message and OK to read content.

Press left function key to enter option menu, view, reply and call addresser, transmit, delete, delete all and save to contacts, etc.

6.3 Drafts

You can view and manage messages saved to drafts here, please refer to the operation of inbox.

6.4 Outbox

Outbox stores and manages messages being sent and failing to send, please refer to the operation of inbox.

6.5 Sent message

Sentbox stores and manages sent and stored messages, please refer to the operation of inbox.

6.6 Message settings SIM card settings:

Mode settings: set number and name of message center 7 Multi-media

7.1 Music player

Enter music player page and press below keys for related operations:

- ♦ OK key: play/stop.
- ♦ Top and bottom navigation key or *, # key: adjust volume.
- ♦ Left and right navigation key: switch last and next song.
- ❖ Left function key: enter option menu, select play/stop and list. Enter play/ist, press top and bottom navigation key to select song, press left function key to enter option like playing, detailed information, updating playlist and settings, etc.
- ♦ Update playlist: update songs in playlist. Notice: store songs in My Music files of T card and then playlist will update automatically.

7.2 Record

Enter record function, select new record as per option and enter record status. Press left function key to pause record, press right function to stop and save record.

Press left function key to enter option, execute operations such as new record, play, add, rename, delete, list, set and send, etc.

7.3 FM broadcasting

This phone owns FM broadcasting function to listen broadcast and it needs to insert earphone for use.

Enter radio interface, press left and right for intelligent search of previous and next channel, press up key to forward frequency and down key to back up frequency, press OK to play/stop broadcast, press left soft key, following options appear:

Play/stop: play or stop broadcast.

Channel list: edit channel name and frequency.

Manual input: manual input of frequency.

Automatic search: search radio stations automatically and store searched channels in channel list.

Set: set relevant parameters of radio.

7.4 File management

File management function manages files in T card. Enter file management and present current storage device list

\$Format T card in list interface and all data in storage device will be deleted after formatting.

♦Press OK to enter selected folder.

♦ Press left function key to enter option and execute below operations:
 ♦ Open: open current file.

◆Send: send selected file through "Bluetooth".

◆ New folder: establish a new folder in current storage device.

Rename: rename files.

◆ Delete: delete selected files and this function is not available for system folder.

◆Copy: copy file to specified folder. ◆Move: move file to specified folder.

◆Details: view related information of file.

8 Tool box

8.1 Calendar

♦ In main interface of calendar, press left and right function key to switch date.

8.2 Alarm clock

This function allows to set 3 groups of alarm clock. When reaching set time, prompt will be given as per prompt type set by phone.

❖ Enter alarm clock function, select one and press left function key to

enter edit interface.

♦ Press up and down key to select option to be set, edit OK and press

right function key to save settings.

8.3 Calculator

This phone offers calculator function and can execute simple addition, subtraction, multiplication and division operation.

♦ Press number key to input number. Input +, -, × with navigation key.

Press right function key to delete data.

Press OK to calculate result.

9 Settings

9.1 Profiles
The phone offers standard mode, silent mode, conference mode and outdoors mode to users.

Select required mode, press left function key, select start, personal settings and rest in main menu. Select start to start the mode, select

reset to restore the mode to default state, select personal settings for related settings:

♦ Prompting type: set prompting type. (Prompting mode: ringtone, vibration, vibration and ringtone, ringtone after vibration)

♦Ringtone type: set ringtone type (repeat and one sound)

♦ Incoming call: set ringtone of incoming call as system ringtone or customize ringtone.

♦ Ringtone volume: adjust ringtone volume.

♦ Message: set message ringtone.

♦Message volume: adjust message volume.

♦ Keypad: set keypad tone to be mute, click or tone.

♦Keypad volume: adjust keypad volume.

♦ Start up: set start-up ringtone.

♦ Shut down: set shut-down ringtone. ♦ System prompt: open or close system prompt.

9.2 Shortcut

Enter this option to add, edit, delete, delete all or modify sequence, etc. (In standby interface, press up navigation key to enter shortcut function)

9.3 Phone settings

♦ Time and date: set time, date and format of local city.

Language: set displayed language of phone.

♦ Primary input method: set default input method of phone.

♦ Standby menu display: whether open display of time and date.
♦ Assigned function key: set function of each navigation key in

*Assigned function key: set function of each navigation key is standby interface.

♦ Flight mode: set phone to be normal mode or flight mode.

9.4 Network settings

Set manual/automatic selective network and precedence mode of GPRS transmission.

9.5 Security settings

♦ Security settings of SIM card: this function allows to open and close coded lock. Once locked, press PIN code to start up. Remark: wrongly input PIN code continuously for 3 times, SIM card will be locked and input correct PUK code to unlock.

♦Phone security settings: after starting phone lock, input phone password to start up and default password is 1122.

♦ Keyboard lock: set time for automatic lock of keyboard. If you don't operate phone, keyboard will lock automatically when reaching set time.

9.6 External connection

♦ Data account: set data account of phone.

9.7 Restore factory settings

This function is used to rest some of the menu settings to their original values. Select restore factory settings and enter security

password (1122), then related parameters restore to original settings.

10 Bluetooth

10 Bluet

♦Turn on/off Bluetooth: you can set whether turn on Bluetooth device.

♦ Visible: show or hide Bluetooth. When setting to hide Bluetooth, others will not scan Bluetooth device of your phone if Bluetooth function starts up. ♦ Device name of phone: when Bluetooth of phone opens, device name will be displayed if others search for Bluetooth.

♦ Search for hand-free device: search for Bluetooth headset, etc.

♦Scan Bluetooth device: enter Bluetooth dialer to scan and link Bluetooth device.

10.2

10.1

Bluetooth dialer

♦ Extension: enter Bluetooth catalogue and start Bluetooth function; Host: enter Bluetooth function and scan Bluetooth device: select Bluetooth to be connected, prompt pairing information, press confirm and order can be sent to extension automatically

Extension: after receiving order, extension prompts whether to connect, confirm, headset symbol will display in main interface of host, which means connection. After connection between extension and host, you can use extension to dial host number.

Dial with SIM card in host: local dialing or Bluetooth dialing will appear when making calls, select BTPHONE in the case of Bluetooth dialing.

Import contacts: extension enters contacts, select Bluetooth, press confirm, contacts of host will import to extension, you can not make or receive calls during import process.

Automatic connection: when extension starts up or leaves host, it will connect to host actively.