


# Portable Signal Jammer

## User's Manual

1. To be charge about 3 hours when you use portable signal jammer for the first time.
2. To click switch "OFF" when jammer are charge, it shows red in power LED; when power is full, power LED will turn off.



3. To connect antenna with output port according to the, indicate for antennas of short and long.
4. To click switch "ON", it is operation and shows green in power LED
5. Effective jamming radius depends on signal strength in given area.
6. Working hours is about 90 minutes, Power LED is turn off when it isn't power.
7. To keep away from metal products or nearby, it affect jamming radius.

Output Port	Frequency Range	RF output power	Channel output Power
GSM	850-960MHZ	30dBm	-2dBm
DCS	1805-1990MHZ	30dBm	+3dBm
3G	2100-2170MHZ	29dBm	+6dBm
Power supply: AC110V/220V-DC12V			
Build-in battery: 2500mAh			
Shielding radius: 1-20m@depends on network signal strength			
Output power: 2.7W Weight: 300g Dimension: 62*32*12mm			

### Importance Note:

1. To keep away from high temperature fire.
2. To keep away from Computer, TV, Radiogram etc when it is operation, otherwise, it makes disturbance.
3. To confirm weather antenna connect with output port well and frequencies is correct before you use cellular jammer, otherwise, it affect jamming radius.
4. The jammer use safe and reliable battery, if the battery can not use after many times charge, pls change a new one battery.
5. The jammer have high quality chargeable battery, please charge new battery if the battery can't charge again as over charge times.