

Installation & Uninstallation Guide of BlazeVideo HDTV Player v2.5a

Install hardware device driver.....	1
Install BlazeVideo HDTV Player	1
Launch BlazeVideo Media Detector	3
Register BlazeVideo HDTV Player	4
Uninstall BlazeVideo HDTV Player	5

Please put the CD disk into the CD-ROM



Install hardware device driver

Double click "Install Driver" (or open driver file in the CD disk and click setup.exe), just follow prompt step you will complete hardware device driver

Install BlazeVideo HDTV Player

The installation of BlazeVideo HDTV Player is very simple, just follow below steps you will complete BlazeVideo HDTV Player installation on your PC.


1. Double click "Install Blaze HDTV Player" to prompt below welcome setup wizard, click

USB 2.0 DVB-T TV Stick


“Next” to continue;



2. Select “I accept the agreement” in the popup License Agreement box, then click “Next”;




3. Click “Browse” to specify installation folder and click “Next”, the default folder is “C:\Program Files\BlazeVideo\BlazeDTV2.5a”;



4. Just click “Next” in the following steps, you will complete BlazeDTV installation on your PC.


Notes:

1. If you have a HDTV hardware device connected to your PC, and its driver has been properly installed, after you launch BlazeVideo HDTV Player, it will prompt you to scan all available channels, after scanning finishes, the player will begin to play the first scanned channels.



2. If no HDTV device connected to your PC yet, and you plan to install a device now, please exit the BlazeVideo HDTV Player firstly.
3. if you want to look operation manual in playing , please click F1.

Launch BlazeVideo Media Detector

After you exit BlazeVideo HDTV Player program, the BlazeVideo Media Detector will auto launch with an icon  appears on the Notification Area of your Task bar. Right click the icon, you will access much more advanced function.

USB 2.0 DVB-T TV Stick




Register BlazeVideo HDTV Player

You will get a serial number from us shortly after you ordered BlazeVideo HDTV Player.

Enter your registration information following these steps:

- 1. Running BlazeVideo HDTV Player.
- 2. Right-click on the video window to show the popup menu. Select the item "Purchase & Register" to show the register dialog box.
- 3. Input the registration information exactly as what you've got.

A screenshot of a Windows-style dialog box titled "Enter registration information" with a red close button in the top right corner. The dialog contains a paragraph of instructions: "Enter your name, E-mail, and the serial number for your copy of the program. The serial number is located on the outside of the CD case, or on the receipt page for web purchases. You can also locate the serial number for web purchases in your online order history." Below this text are three input fields. The first is labeled "User Name :", the second "E-mail :", and the third "Serial Number :". At the bottom of the dialog are three buttons: "Register!", "Cancel", and "Help".

User Name : Enter your full name here.

E-mail: Enter your E-mail address

Serial Number: Enter the registration code here. Please copy and paste the serial number and DON'T type it manually because the serial number is a case-sensitive text string and is difficult to distinguish.

- 4. Press the "Register!" button.

Uninstall BlazeVideo HDTV Player

Before you remove BlazeVideo HDTV Player, please close and exit the program first. There are two ways to uninstall BlazeVideo HDTV Player.

1. Go to "Start->All Programs->BlazeDTV 2.5a ", Run "Uninstall BlazeDTV 2.5a";
2. Or go to "Start->Control Panel->Add or Remove Programs", select "BlazeDTV 2.5" from the program list, then click "Remove" button.

Just follow the instructions that appear on the screen, you will completely remove BlazeVideo HDTV Player from your computer.