



2 ATTENTION

- 2.1Please read this manual carefully before using it.
- 2.2To ensure stable power supply , please use good supply line and outlet with grounding.
- 2.3Please use the power supply indicated on the projector and the wire provided with the projector.
- 2.4Please do not dismantle the projector without authorization; otherwise the supplier bears no responsibility for maintenance service.
- 2.5Do not look into the lens while the projector is on working to prevent eyes from hurting.
- 2.6Do not place the projector on the articles which may become obstacles for ventilation.
- 2.7This projector has no waterproof function; you need to keep it away from water. And vessels with water should not be placed around it .
- 2.8To avoid electric shock, please keep the projector from rain and dampness.
- 2.9Please shut off the projector and unplug the wire if the projector will not be used for a long time.
- 2.10When the projector is transported, please use the plastic foam and other anti-shock materials provided with the projector.
- 2.11If the projector is found to be damaged, please do not try to repair by yourself and please contact the distributor.

1 Production Features

- 1.1 All sealed design, release you from daily internal cleaning.
- 1.2 Using of the 20 thousand hours long life RGB-LED lamp, which makes it more colorful and abundant details.
- 1.3 Professional trouble shooting and protection design.
- 1.4Small in size and light in weight.
- 1.5Free exchange from 16:9 to 4:3 .
- 1.6Low noise design and dust free design , free you from internal cleaning.
- 1.7Power consumption lower to 24W.
- 1.8Multi input interface: AV,VGA,USB,SD,HDMI.
- 1.9Vehicle power supported.
- 1.10The projector designs are extraordinary and attractive

3 Fittings

User manual	1pc	3in 1 AV cable	1pc
Power adaptor	1pc	Remote control	1pc

7 Button function



Up: move up and confirm the Multi-media item
 Left: move left and go down.
 Right: move right and volume up.
 Down: move down and repeat by the Multi-media item
 Menu: OSD Menu.
 Source: choose the signal input source.
 Power: power on and off

8 Remote Button Function

1.Power	2	2 MENU	1
2.Menu	3	3 Photo	4
3.Mute	4	4 mutemenu	5
4.Photo button	5	5	6
5.Music button	6	6	7
6.Movie button	7	7 SOURCE	8
7.Source button	8	8	9
8.Repeat	9	9	10
9.UP/Down/left/right	10	10	11
10.OK button	11	11	12
11.Stop button	12	12	13
12.Exit button	13	13	14
13.Volume plus	14	14	15
14.Volume minus	15	15	16
15.Next	16	16	17
16.Forward	17	17	18
17.Back ward	18	18	19
18.Previous	19	19	20


4 Specifications

Model	Image system	Lcd
Lamp	led	Input Voltage
Language	chinese/English/est	12V
Image size	20-80inches	Projection Distance
Color	1670k	1-4meters
Power waste	24W	Projection mode
		Front projection
		Speaker
		1.0W*2
Weight	0.4kg	Lens
Operation mode	Manual remote control	F=125
Output	Head phone	Size
		137x136x56.6 mm
		Working temp
		-10-35C
		Input terminal
		AVVGA,USB/SD

5 Multi-media support files

File	Format	Sub-fix	Decoding
Audio files	WMA	.wma	
	MP3	.mp3	
	M4A	.m4a	
Image files	JPEG	.jpg	
	BMP	.bmp	
	PNG	.png	
Video files	MPEG1	.dat\mpg\mpc	
	MPEG2	.mpg	
	MPEG4	.avi\mp4	DIVX, XVID
	RM, RMVB	.rm, .rmvb	RV8\9\10
	H264	.mkv\, mov	MPEG1,2,4
	MOV	.avi\mp4	
	MJPEG	.avi	
	FLV	.flv	H264
	VC1	.wmv\asf	VC1
	DIVX	.divx\, avi	MPEG, DIVX

6 Product details



9.3.3 Multi-media menu operation

insert the USB or SD first, and then choose Media from source. Then choose the icon for different files and press OK to confirm.



By this menu, you need to play video, photo and music correspondently with the icon showing.

Remarks: You can only insert the USB or SD on at a time, or the projector can not recognize any of them

9 Function operation

9.1 Switch-on and off

After powering through the power adaptor , then projector is under standby status.

Switch on: Press the power button or the power button on the remote control once ,and then the projector is powered on.

Switch off: When you want to shut the projector ,please press the power button beside the indicate light or the power button on the remote control once, and then the projector is off.

9.2 Image focus

Place the projector vertical to the projector screen ,and then rotate the lens slightly,until the brilliant image presented.

Attention

Please connect the power adapter with the projector first ,then plug the socket into the outlet. Finally power on the projector.

9.3 Menu Operation

9.3.1 Input source selection

Press "source" button on the remote control or "input" on the projector to get the source menu, then press "OK" button on the remote control to confirm the input source you need

9.3.2 Picture menu operation and sub-menu adjustment

Press "OSD MENU" to enter into the main menu and press "◀/▶" "▲/▼" to cash sub-menu
 Picture sub-menu
 Available adjustment: picture mode, color temperature, aspectratio, noise reduction, screen rotate R/L and rotate up or down zoom



Sound sub-menu
 available adjustment: sound mode, balance auto volume sound, SPDIF mode Eq.



Time sub-menu
 available adjustment: clock offtime, Ontime, auto sleep



Setting sub-menu
 OSD Language English, restorefactory default, colorrange, bluescreen, osd Blend.