



zopo


Parts description and preparation

Smart phone Quick Guide

www.zopomobile.cn



Open the notch on the lid,
Then pull lightly along the lid cracks.



Notice: In accordance with the instructions,
you should be prompted to insert,remove the
batteries to avoid unnecessary damage to the
body or battery.


Plug the battery
Keep battery metal contacts and fuselage battery
contactor alignment, then gently press down to
push the battery into the phone smoothly.


More information
You can search our mobile phone models and feature
in our website, and can select more accessory for your
zopo phones.

www.zopomobile.cn

Basic Function

Power On




1. Keep press the power button  , until screen turn on.
2. Please wait for seconds for power on.

Unlock and Lock screen

Unlock






Press  button quickly, and drag the ring to unlock.

Lock Screen

Press the power key  in any interface, then the mobile phone will enter standby model.

Keys



-  Menu Key : Enter for fast setting
-  Home Key : Enter to desktop
-  Home Key : turn back to last menu


Shortcuts

Desktop

Unlock the desktop, you can click the icon to open the corresponding application. Change wallpaper, open the file. Also can slide the desktop to get more applications.



Enter Desktop




Desktop enter key 

Browse Desktop

Slide the screen

More Basic Function

Dial


Press  , through to search contacts or enter the phone number then press  to dial out. If want to delete the number, please press .

Call ends

Press  during the calling.

Incoming call


When have call coming, slide the ring to  to receive.



Desktop Gadgets

Desktop Gadgets is a shortcut to enter the APP. You can use it directly at desktop, eg: desktop weather gadgets can let you know the weather information anytime.

Applications Menu

You can enter the application menu from home key. After unlock the screen, press .

Start Applications

At application menu, touch the APP you want.

Notification Bar

At top of home /main menu, it displays the mobile phone signal. Battery power, new message and other notice.

Checking the notice






One finger pull down from the top of notification bar.

Quick menu




Use 2 finger to pull down from the top of notification bar. You can turn on/off fast for WLAN, Bluetooth, GPS and etc function.

Message

Sent message

1. Press  enter the message menu
2. Press  to create new message
3. Press  to add one or more contacts.
4. Press  to sending text or inserting pictures, face, video, etc
5. Press  to sending when finish edit.

Phones Setting

1. Find  in application menu. Touch it enter the setting menu.
2. Touch  menu key under the home menu, enter the System settings.
3. Enter quick menu, touch  enter system setting.