

A stylized illustration on the left side of the page shows three tablet-like devices. One is at the top, another is partially visible to its left, and a larger one is at the bottom. Thin, curved lines connect these devices, suggesting a network or data flow. The devices are represented by simple black outlines with some shading to give them a three-dimensional appearance.

## Tablet computer series

The user manual

Warm prompt: When using an external card, please boot before plugging in card.

# MID-**android**

## Instruction

Please read the precautions and important tips in the instructions before use.

## Catalog

	<b>Chapter One (overview)</b>
1-1	Appearance
1-2	Buttons
1-3	Open and shut down
1-4	Open and shut down standby mode
1-5	Lock and Unlock the screen
1-6	Homepage information column
1-7	Text input
	<b>Chapter two (Browser)</b>
2-1	Browser
	<b>Chapter three( Applications)</b>
3-1	Camera
3-2	Gallery
3-3	Video player
3-4	Music
3-5	Calendar
3-6	Calculator
3-7	FileBrowser
3-8	Application installation
3-9	Video output
3-10	Simulation Game
3-11	Downloads
3-12	E-mail
	<b>Chapter four (Establishment)</b>
4-1	Sound settings
4-2	Wireless networks settings
4-3	Display settings


## Chapter One Overview


### 1-1 Appearance

Picture for reference only. Please subject to specific products.

### 1-2 Buttons

#### Power button


Long press the button  about 2-3 seconds to open the screen.

When open the tablet, short press this  to enter the off-screen state and short press again to light up the screen.

#### Volume


  this to adjust the volume

#### Set up


This key  to set up the applications.

### 1-3 Open and shut down

#### Open

Long press the power button  on the right side, A9 sign and pictures will show up in turn until to the interface.


#### Shut down

Long press the power button , then the screen shows < would you like to shut down>, press <sure> to shut down.

In charging state, when the tablet is off, press the right upper "power button" it will shows "charging" figure, once again to click "power button", the equipment will be opened.

### 1-4 Open and close standby mode

#### Open the standby mode

In boot mode, you can tap the power button  on the upper right side of the tablet, the system will into the stand by mode which can save power.

#### Close the standby mode

In the stand by mode, light tap of the power button on the right side to wake up the device, enter the normal state.

### 1-5 Lock and unlock the screen


#### Lock


You can set up the sleep time in the system of < display>.

The system will sleep automatically and lock the screen to the standby mode if without any inactivity when reaches the preset of standby time.




#### Unlock

Move the sign  to unlock, show as below.

Drag this  to unlock the screen and enter the application interface.



## 1-6 Homepage information columns



## 1-7 Text input

When use the tablet, you can use the virtual keyboard to enter text, numbers, symbols directly by touching screen. After selecting the Android input method, the default keyboard show as below.



To switch the numbers and letters, please press this

To switch the capital and lowercase letter, please press this


## Chapter two: Internet

### 2-1 Browser

Require network support before using a web browser, if there are network supporting problems, please contact your network operator or the service provider.

Tablet's web browser can connect to the Internet via WIFI to satisfy your business and individual network needs.

Please touch this to set up the WIFI so that can use the browser normally. See as picture:



Touch here in the application list to enter the browser pages; the default homepage is the <Recently Viewed> showing recently viewed pages.

Browser supports the following features



Enter the URL-touch the input area to get the soft keyboard, then text the URL.

Book mark search- click this to add into the bookmark

Touch this to read the favorite website that collected

Touch this to search the internet

Touch this to add new browser.

Touch this to close the browser

## Chapter three: Application

### 3-1 Camera

Touch this in the application list to enter the camera, the views showed on the screen and you can do the following as picture:





## Camera

Click this to get Snap shot.

Setting": to set up white balance, exposure, save, start.

## Video

Click this to video and do the relevant operation.

Setting": white balance setting, delay, save, click this to start video

## View photos and videos

In pictures preview interface, click on the screen to preview photos, also you can set up the pictures to slides.

## 3-2 Photos

Click here in the application list which including all the pictures.



Click this can classify the pictures by time and place. Click this to enter the camera.  
Click this to choose the album to edit or delete.

Click this to enter slides show when you enter the album.

## 3-3 Video player

Touch this to the Video player.

You can see the Videos in nand and sdcard files.

[潘多拉的世界(阿凡达IMAX最新特辑)] The World of Pandora.mov

[红领巾侠] THE RED.avi

[里约大冒险] RIO.2011.04.07.1080p.预告片.mov

There are some control areas at the bottom after you enter the video player.



Information


## 3-4 Music

Touch here to the music player. Music can be played by artists or album classification.

This page displays the songs alphabetically.

Click the songs you want to listen and get into selected state to play.

Click on the <now playing> will display being played album page; there will be lyrics shows under the page right.



Play interface: list, random play, repeat

## Artists

In the <artist> page, it is sorted according to the artist's initials, click on one, you will open the artist's related album and song list, then you can click songs to play.

## Album

The album page shows all albums in the list, sliding it can browse all. Click on the album cover will transfer to the album back automatically. When all music shows, click again on the songs began to play.

## 3-5 Calendar

Touch this to Calendar, the default page shows the months, click this to the day.


**Date views:** long press to the events to rebuild, view, edit, and delete; Click on the blank area can set up new events; long press the blank area, you can build new events or display/not display the lunar day view.

**Week views:** Long presses the event to rebuild, view, edit, and delete events; long press the blank area you can rebuild events or display/not display the lunar weeks view.

**Month view:** long press date to build new calendar items or display/not display the lunar month view

**Agenda:** list all events click to read the details.


In any views, when you switch to other date, week or month, all can be back to today or week or month now by touching <today> button.



You can also click here to search task memo, edit, notation and share.

## 3-6 Calculator

Touch here in the application list to get into the calculator.




## 3-7 Document browsers


Touch here in the application list; it supports the files mutual copy in this two places internal memory and SD card.










Touch the button  when it turn to yellow, you can edit the file.

### Edit


Touch this  to edit the file including cut/copy/paste/delete

Copy, choose one file in the list, click this  to copy when show the 

Then click this  to choose where to put the file, and then click this  to paste.

Delete, choose one file that click here  to delete.


### 3-8 Application installation


Touch here  in the application list, it will install, unload the APK files automatically. It searches the APK file from /mnt/flash or /mnt/sdcard



Touch the selected APK application directly for installation and unloading


### 3-9 Video output

Touch here  in the application list; choose the resolution of the video output.




System has 720P and 1080P two kind of resolutions.

### 3-10 Simulation Game

In the application list click here  to connect the handle to the game, there will be AC, PS, MD, GBA, FC APK file in the Motin Game.

Different equipment installs different simulator



## Handle

: Space, : back, : select, : start

, , , ,

Different keys set different in the game

## 3-11 Downloads

Click here in the application list; you can preview the downloading or done document contents.



Click download file to stop or delete the download contents.

## 3-12 E-mail

Require the internet support before using e-mail, if there are problems in network supporting, please contact your network operator.

### Add account

If you are the first time to use email, get into a mailbox interface directly to set up an account according to instruction.

If you want to add more mailboxes, click <Settings> on the top of the page to add more mailboxes, and then select <add account>.

## Email account

You can set up email for most accounts in just a few steps.

Email address

### Draft e-mail

In <inbox> page, you can click this on the right page top to draft mail quickly.

In the draft mail page, you can:

Add mail recipients quickly.

Enter the recipient address in recipient input box or click on the <contact> in the contact list of recipients to choose mail address; you can copy/close to send input address.

Write email subject and text content (the text area support copy, shear operation);

### Add attachment

Add attachments from the document management, when it succeeds, the name will show one<New e-mail> page; you can click to select to open or remove them.

### Reply, forward mail

Click the right page preview area of the toolbar <reply> <reply all> or <forwarding> choices.

The basic operation is same with the draft e-mail.

## Chapter four: System setting

Click here to enter the system setting interface.

### 4-1 Sound setting

Sound settings, click this to sound setting page. You can choose mute switch which can get more detailed settings if you need. Click the <volume setting> can set up the notice, the media and the alarm of volume and choose the prompt operation sound and the bell and software disk boot switch voice.


### 4-2 Internet setting


This setting module includes: the wireless local area network Settings



#### The wireless local area network Settings

Open wireless LAN switches, the system will scan available wireless network automatically and display the wireless local area network in the list.

Among them, if the local area networks have the sign  behind it, that represents the networks don't need a password, can be connected directly.

This sign  represents the network has been encryption, it needs to enter the password to connection.

You can choose the network from the list you want, click it to connect directly, also you can click the <advanced> option to set up the

<IP> and <agent>, then click <connected to the network>; you can also select <add wireless local area network>, to add by hand.

Network notice: open the switch, it will notice if there any open network.

The wireless local area network certificate: the wireless local area network loading and management.

MAC address: to show the MAC address

#### 4-3 Display setting



Display Settings contains: wallpaper Settings, dormancy time, brightness, automatic rotating Settings

##### Wallpaper setting

In the wallpaper setting, you can set up the wall paper and dynamic wallpaper; the wallpaper can be chosen from gallery.

##### Standby Screen

When the screens in light state a period of time, it will automatically lock to save the power if without any operations.

##### Brightness

The user can adjust brightness manually to get the lightness you want.

##### Font size

You can set up the font size according to individual's favorite, there were respectively: small, ordinary, big, huge.

OS	Android 4.0
CPU	ARM Cortex-A8 1GHz-1.5GHz.
RAM	512M-1GB(optional)
ROM	Nand Flash 4GB/8GB/16GB(Optional).
LCD	7" 8" 9.7" (option) HP display
Touch panel	Capacitive/Resistance Touch panel(Optional).
2D/3D	AMD graphic acceleration, full support.
Graphic	OpenGL ES2.0(AMD Z340)and Open VG1.1(AMD Z160)@27M Tri/sec.
WIFI wireless	Support 802.11b/g/n standard, highest transmission get to 300Mbps, support local WAPI wireless protocol standard.
3G	Built-in 3G Module(option), WCDMA/HSDPA,support calling, message, Wifi ad hoc
TF expansion	for optional 3G module to realize 3G communication.External MICRO SD(TF)slot,Max. 32GB TF card.
USB	USB high speed 2.0 .Can be connected to the computer to copy files.
VPU	Maximum support hardware decoding 720P and 1080i, and 480 video encoding.
Gravity	Built-in 3D gravity sensor, to make screen realize 360 degree rotation.
Audio	support gravity sense operation game. AC'97 full-duplex codec, support AAC\AMR\MP3\WMA\WAV\MIDI and so on.
Video	WMV/ASF/MP4/3GP/AVI/MKV/VC-1/DIVX/MPEG-2/MPEG-4/H.263/ H.264 720P HD 1080i
Game	Support several of entertainment games based on Android platform.

