


HOW TO USE

- ▶ Simply using the attached USB cable to charge the digital product. One end of the USB cable connect with the "out" port of the power bank, another end connect with the digital product with converted tip. Press "ON" button once, it will start to charge and the green LED will indicate the charging process.
- ▶ Finishing charging or without connecting the digital product, the green and blue LED will stop flashing. And the power bank will turn off automatically after 30 seconds.
- ▶ 30%,70%,100% is the three capacity indicators.
- ▶ When the capacity indicator at 30% means Low power and it need to charge the power bank in time.


Note: If the instantaneous current is oversize when charging the digital product, the power bank will turn to protected mode automatically. To relieve the protected mode just charge the power bank.



HOW TO CHARGE THE POWER BANK

- ▶ The "IN 5V" port is the charging port the power bank. The green LED will flash and the blue LED light on when charge the power bank, all the blue and green LED will light on after full charging.

UNIT VIEW DESCRIPTION



1. Turn ON button
2. DC5V input port
3. DC5V LED indicator
4. USB output port
5. Power indicator

PRODUCT SPECIFICATION

Work for	Mobile Phones and digital product
Input voltage	DC 5V
Input current	800mA(MAX)
Output voltage	DC 5V~5.5V
Output current	2.2A(MAX)
Capacity	9000mA(MAX)
Product weight	299g
Product dimension	96(L)×41(W)×41(H)mm
Operating temperate	-10°C~60°C
Storage temperate	-10°C~45°C

MAINTENANCE

Keep your power bank operating to the fullest potential, by following the below steps:

1. Re-charge your power bank once every three months when it is not in use.
2. Keep the power bank away from any moist environment and corrosive material.
3. Never wash the power bank with any chemicals, soaps or detergents.

USER MANUAL

Rechargeable Battery Pack