


*USER MANUAL*  
用戶手冊

**BOOKLIGHT**




# User's Instruction

## 充電注意:

請在木質封面上邊緣位置找到充電插口，並注意 Micro USB 方向，以免損壞充電插口。


## Caution:

Find the charging port from the cover side. Please notice the direction to avoid damage to the port.




本產品可0°~360°開合，請在合適的平面或環境下操作使用。


Booklight can be opened up to 360°, please use it in suitable flat surface and good environment.




90°展開



180°展開



270°展開



360°展開

## 技術參數

功率: 4.4W

重量: 0.7kg

封面材料: 複合板

封皮: 實木貼皮

本體材料: 杜邦環保紙

光源: 高功率LED

亮度: 500流明

續航時間: 連續使用4小時

充電口: Micro USB

## Technical Specifications:

Power: 4.4W

Weight: 0.7kg

Cover material: FSC Plywood

Cover finish: Natural veneer

Body material: DUPONT tyvek


Light source: Hi-output LED

Brightness: 500 lumen


Battery life: 4 hours

Charging: Micro USB charger


## Steps:



①



②



③

## 維護保養

### 木質封面

- 污漬或液體請立即清除。建議使用紙巾、干棉布沿木紋方向輕拭表面。若表面觸感粗糙不光滑，建議使用木蠟或清油進行表面維護。

### 環保紙內頁

- 此材料防水防撕，若有污漬，請立即使用濕棉布進行清潔打理。

## Care

### Wood cover

- Severe dirt and fluids should be removed immediately. We recommend the use of paper tissue, dry cotton cloth or a damp cloth if necessary. Every treatment should be in the direction of the wood's grain.

- If the surface feels dry and rough to the touch, oiling of the surface is recommend.

### Tyvek Pages

- We recommend the use of damp cloth to remove dirt from the pages.

## 注意！ Caution!

使用Booklight之前，請完整閱讀此用戶手冊並詳細閱讀注意事項。因高溫、有毒氣體、火焰或爆炸等不適當使用狀況造成對產品和用戶個人安全損害，責任將由用戶承擔。

- 請閱讀，遵守並保留此用戶手冊。
  - 切勿將產品置放於潮濕環境，切勿將任何部件或包裝內物品淋濕或浸入任何液體中，請於乾燥、常溫環境下保存產品及各個物品。
  - 請勿在高溫環境下，包括高強度陽光照射下存放或使用Booklight產品，切勿在極端高溫、灰塵或震動環境下使用該產品。
  - 切勿掉落，防止木質封面損壞。請勿在產品上堆疊其他物品及重物。
  - 切勿拆解，嘗試改裝或修理此產品。
  - 請遠離各類磁性儲存器（磁盤或磁帶）至少20CM距離，以防儲存器資料丟失。
- 防止電擊傷害，切勿拆解產品。產品內部並無修補替換零件。任何損壞或修復工作請聯繫您購買時的經銷商。

Read all instructions and cautions prior to using this product. Improper use of this product may result in product damage, excess heat, toxic fumes fire or explosion, for which damages will be user's responsibility and not the manufacturer.

- Please read, follow, and keep this user manual.
- Do not expose the fixture to moisture or submerged it in liquid. Keep the fixture dry at all times.
- Do not store Booklight in a high temperature environment, including intense sunlight. Do not expose to temperature or humidity extremes, excessive dust or vibrations.
- Do not drop, apply excessive force on the wood cover spine, or put heavy objects on top.
- Do not disassemble this fixture or attempt to re-purpose or modify it in any manner.
- Keep magnetic storage media (disks and tapes) at least six inches away in order to avoid data loss.
- To reduce the risk of electrocution, do not attempt to open the fixture. There are no user serviceable parts inside. Refer all servicing to qualified service personnel. Servicing is required when the product has been damaged in any way.

## 注意！ Caution!

此產品含有強磁，請遠離磁性會影響的物品，如磁條式銀行卡、指南針、電視機、顯示器、臺式收音機、無防磁設計的手錶、手機等物件。

This product contains Neodymium magnets. Please keep it away from your Credit card, Compass, Television, Screen, Radio or equipments without antimagnetic function like Watch, Mobile phone etc.



# 內裝物品

## Contents Inside


Booklight x1



USB充電線 x1  
Micro USB Cable x1



支撐柱 x1  
Steel Peg x1



### 包裝說明：

請確保您的Booklight包裝中已包含以上圖示所有物品。如果有所缺失，請聯繫您購買時聯繫的經銷商。包裝中應包含以下物件：

- Booklight
- Micro USB充電線
- 鋼制支撐柱

另外，外包裝是非常適合您存放及攜帶Booklight的便攜盒子，我們建議您平時不用或出行時依然沿用此包裝盒以保護您購買的Booklight產品。

### Pakage Instruction:

Please make sure all of the parts shown above are included in your Booklight package. Contact your local dealer if any part is missing. The package contains:

- Booklight
- Micro USB cable
- Steel peg

The outer package also functions as a carrying slip case for your Booklight. It is recommended that you use this case for protection whenever you travel.

## 注意事項！

電池充滿後可供Booklight正常使用4小時。為減少充電時間，建議您使用額定電流為1A標準充電器來為Booklight充電。

請使用包裝盒中的充電線連接您USB接口的充電器來為Booklight充電。充電時LED充電指示燈呈紅色，電池充滿後呈綠色。

建議您在首次使用前充電5小時以保證電池充滿。在首次使用過後，建議充滿電後拔掉插頭防止不良充電器涓流充電損壞電池。

不建議使用電腦USB接口為Booklight充電，電腦USB接口電流太小，可能造成長時間不能充滿電的情況。

### Caution!

Connect Booklight to a power source using the micro USB cable provided in this package. The USB cable can be plugged into any wall-plug style USB power source such as the standard USB wall adaptor. The charger LED will turn red while the device is charging and will turn green when it's fully charged. The battery provides powerful lighting for up to 4 continuous hours. It is recommended to use a 2A power adaptor for charging.

It is recommended that you charge Booklight for a full 5 hours prior to use. After the initial use, it is recommended to unplug the charger when the charging light turns green, to avoid damage to the battery by over charged. It is not recommended to charge Booklight using your computer USB port given its low power output. Charging time for this method could take up to 24 hours.