


The Installation of Visual reversing

1. Line Connection



- A. Camera power supply interface through C and reversing lamp power connector
- B. Camera video AV interface
- C. The camera power supply DC cable
- D. Display Power Interface, by H.DC Line
With the vehicle power supply connection
- E. Reverse video input interface, via G.AV cable
And B.connection (usually white)
- F.Video input interface, and Car DVD AV interface

2. Installation



- A** Monitor
- B** Camera power source
- C** Camera

