

DPFMate Manual

Version 1.0.0

1. Product brief introduction

Mini digital photo frame is mostly for photo view, it can also be gifts and key chain for decoration.
Characters as follows:
1.1~3.5inch CSTN/TFT LCD display.
Slide show pics or manual play.
BMP, JPG, PHG format supported.
Calendar and clock function.
Built in 3.7V rechargeable lithium Battery, and intellectualized lithium charger.

2. There are mainly three key for operation, Menu/Play key "●", UPkey "▲" and Down key "▼". (Notice: As for other key as "reset" key and "delete" key, its function is defined as specific instruction.)

Press key ● "Menu/Play" key to power on/off the terminal and main menu. To press key ● and hold it for 3 sec to start DPF showing pictures after LOGO. In the state of picture showing and clock display, to long press key ● "Menu/Play" will power off the product. When viewing photos, to click key ● will enter main menu.
Press on ▲ "UP" key to previews previous picture or item of Menu.
Press on ▼ "Down" key to previews next picture or item of Menu.
When power on the terminal, into the interface showing up picture, as the following picture, you will get the ability of the power and the index of picture.

3. Main menu instruction:

```
Main Menu
Usb Connect
Slide Show
Auto On/Off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
```

4. USB connection

Connect PC through USB cable, pop USB connection window as follows, or click "Usb Connect" item when in Main Menu to pop usb connection submenu, Press "up" key or "down" key to select "yes" or "no", select "yes" to enter PC connection, and you can update photos through auto-run software in PC. To select "no" to exit.

```
USB Connect
Yes
No
```

5. Configure play pic time, select item of "slide show".

```
Main Menu
Usb Connect
Slide Show
Auto On/Off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
```

Click "Menu/Play" key to enter submenu showing as below:

```
Slide Show
03
Sec
```

Press "up" key or "down" key to setup configuration time, "00~15" seconds are effective, finishing configuration to press "menu/play" key to save setting and exit.

6. Auto power off configuration, select "Auto Off" item.

```
Main Menu
Usb Connect
Slide Show
Auto Off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
```

Click "Menu/Play" key to enter submenu showing as below:

```
Auto Off
08
Min
```

Press "up" key or "down" key to setup Auto-Off time, "00~30" minutes are effective, finishing configuration to press "menu/play" key to save setting and exit. When setting time is "00", users must power off DPF by hand.

7. "LCD Contrast" configure screen, select "LCD Contrast" item.

Click "Menu/Play" key to enter submenu showing as below:

```
LCD Contrast
02
```

Press "up" key or "down" key to setup LCD contrast value. "00~06" are Effective levels, finishing configuration to press "menu/play" key to save setting and exit.

```
Main Menu
Usb Connect
Slide Show
Auto Off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
```

8. "Backlight" configure screen brightness,select "Backlight" item.

```
Main Menu
Usb Connect
Slide Show
Auto Off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
```

Click "Menu/Play key to enter submenu showing as below:

```
Backlight
18
```

Press "up" key or "down" key to setup backlight value, "00~21" are Effective levels, finishing configuration to press "menu/play" key to save setting and exit.

9. "Display Clock" configure clock and calendar,select "Display Clock" item.

```
Main Menu
Usb Connect
Slide Show
Auto Off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
```

Click "Menu/Play key to enter clock showing window:

10. "Set Clock" configure clock and calendar,select "Display Clock" item.

```
Main Menu
Usb Connect
Slide Show
Auto Off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
```

Click "Menu/Play key to enter submenu of clock setting

```
Year-Month-Day
Hour-Min-Sec
week
```

Press "Menu/play" key to Select the item set up, configure value through "up" and "down" key,once finish Setting,press "menu/play" key to exit.

Notice:real-time update clock to USB connect with PC

11.To delete one photo.select "delete one" item.

```
Main Menu
Usb Connect
Slide Show
Auto Off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
```

Click "Menu/Play key to enter submenu showing sa below:

```
Delete One
yes
No
```

To delete one picture, first select the picture which you will delete,press "Menu/play" key into main, select "Delete One" item through "up" key and "down" key,then select "yes" to confirm deletion and "no" to exit

Caution:When picture at auto show mode("slideshow"),maymake wrong deletion,recommend user to close picture browse mode first ("slide Show" time set to be "00"),then to delete the picture.

12. "Delete all" picture,select "delete All" item.

```
Main Menu
Usb Connect
Slide Show
Auto Off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
```

Click "Menu/Play key to enter submenu showing as below:

```
DeleteAll
yes
No
```

To delete all picture, select "Delete All" item through "up" and "down" key in Main menu, select "yes" to confirm deletion and "no" to exit,when deletion Confirmed, all pictures will be deleted.

Notice:For all configuration,if you don't press Menu/Play key to confirm your change,and exit automatically in 5 seconds.the setup will not be effective.

13. "Exit" main menu ,select "EXIT" item.

```
Main Menu
Usb Connect
Slide Show
Auto Off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
```

Press "menu/play" key to exit, and return to photo viewing