

Mobile Bluetooth speaker and speakerphone








Specification

Bluetooth 3.0 CSR chipset
Power: 2*3W Battery: 1150mAh
Frequency Response: 200Hz – 20kHz
Signal-to-Noise Ratio (SNR): >85dB
Battery Charging Voltage: 5V/500mAh
Playback time: 8-10 hours

Charging time: 3-4 hours

Dimension(L*W*H):115*72*62 mm

Weight: 250g



Features

- Status indicator(Power On/Off, Battery, and Pairing)
- 2. Power On/Off
- 3. Micro USB charging port
- 4. Auxiliary-in Jack
- 5. Volume down/Previous track
- 6. Volume up/Nextg track
- 7. Microphone
- 8. Play/Pause or Microphone mute/unmute(in-call)
- 9. Pair or Phone button



Setup

To play audio from a BT device, you need to pair the device with the speaker. You can pair up to eight devices.

1. On your BT device, turn on BT and scan for devices in its BT menu.

2. Turn on the speaker. When powering up for the first time, the speaker is discoverable for 2 mi nutes and is ready for pairing. The status indicator blinks red and blue.

3. When the speaker appears on the device list of your BT device, select the "speaker". (If a pass code is requested, enter 0000.) The BT status light turns solid blue after pairing is established. The speaker

is ready to play music.

Note: If pairing times out(the BT status light stops blinking red and blue), press and hold the Pair or Phone button until the BT status light blinks red and blue again. Repeat step 3.

Pairing additional BT devices
Press and hold the Pair or Phone button until the
BT status light blinks red and blue Repeat steps


NFC Operation

1 and 3 above.

1. On your NFC device, turn on NFC.

2. Turn on the speaker when the Status Indicator blinks red and blue, put your NFC device near the NFC location on the speaker(NFC on the right side).

The Status Indicator turns solid blue after connection, the speaker is ready to play music.



Charging


About once a month, fully charge the speaker (about 4 hours).

 Plug the charging cable into the speaker's charging port and power adapter.

2. Plug the adapter into an AC outlet. Note: You can also use a computer (with the power) for charging. Plug the charging cable into the USB port.

Status indicator: Solid red=Charging Black=Fully charged Blinking red=Very low battery

Battery saving
The speaker enters power saving mode
if no audio is played for 30 minutes.
Slide the power switch off and then on
to wake the speaker.



Troubleshooting

The speaker doesn't work or it won't pair.

- . Try moving your device closer.
- . Is the speaker turned on and charged?
- . Turn the speaker off and then on to wake it
- . Is BT enabled on your device or computer?
- . Try repeating the setup procedure in this guide or pair with a different BT device.
- . The speaker plays music from one device at a time, unpair the device not being used. (Refer to your devicedocumentation for help.) Pair a new device using the setup procedure.
- . If pairing with a computer, specify the speaker as the audio out device on the computer.