

HAMBURGER MINI PALM BASS

User Manual

1.1 Welcome to use

Welcome to choose Hamburger mini speaker, which is with high-quality sound and used for PC, DIGITAL PLAYER, IPOD, GAME PLAYER AND DIGITAL MOBILE. Please pay attention to manual before you using, So that to Exert the best function and to avoid some unnecessary damnify.

Notice

To allow for design and specification improvements, the information in this document is subject to change without prior notice.

Pioneering patented technology: extendable resonance of the bass box technology enables stronger effect.

Standard 3.5mm audio plug, apply with all music player and digital products.

New idea union portable mini design, is the first smallest mini palm bass over the world.

High-capacity inside, could charge for this product directly by USB, don't need to connect exterior power supply.

Warning:

- Please do not throw the product into fire because this will cause personal injury;
- Please do not put the product in any damp or high-temperature areas;
- Please do not short the product out to avoid danger;
- Please do not disassemble by yourselves to avoid electrical shock;
- Please do not put the product within easy reach of children;
- Please do not insert anything conductive into the sound box body.



1.2 Product confirm

1.2.1 Open package

Please check model mark in package (marked in front of this type)


If it is not match model NO, please contact supplier shortly.

*Hamburger mini palm bass article list

Open package, you will find out article as below

1.2.2 Product and part

- ① Hamburger mini palm bass one piece
- ② USB Charging/audio data cable one piece *
- ③ USER GUIDE one piece



* Function and explain

- ① USB Changer/Audio Port
- ② General USB port
- ③ 3.5mm audio plug


⚠ The cable is not fit into others equipment data connection except of this product.

Warning:

This product set power supply equipment inside, read below manual carefully before using, avoid to happen accident.




1.2 Parts confirm



The photo of products just for reference, please follow the fact products that you buy.

- | | |
|---------------------|-----------------------------------|
| ① Closing condition | ⑥ Prevent slip glue mat |
| ② Opening condition | ⑦ Volume control |
| ③ Decoration hole | ⑧ USB Changer/Audio Port |
| ④ Speaker | ⑨ Power supply and volume control |
| ⑤ Power light | |

1.3 Connection equipment and charge



Connect

Please make USB charge/audio union data cable ① connect to USB charge/audio output point ②

3.5mm standard audio plug ③ connect all allowed digital player equipment.



Charge

Standard USB point ④ connect all PC with USB point or USB power supply adapters for charge.

1.4 "Retractable resonator" close



Step1

Each Left hand and right hand hold on side of speaker front and back, make ALIGN KEY face to straight line;



Step2

Press toward to middle direction by hands lightly;



Step3

Make front and back ALIGN KEY accord;



Step4

Left hold front of speaker to circumference toward clockwise direction lightly, so speaker was closed.

*Speaker opening toward reverse direction repeat above steps!

1.5 Specifications

Dimension:(ϕ)52MM \times (H)37MM (Closed Mode)
Net weight:52g
Speaker: ϕ 36MM
Input:L/R320mV
Power Output:2.2W
S/N: \geq 80dB
AMP Freq Range:200Hz-16KHz
Charge Voltage:5V \pm 0.5V
Suitable Temperature:0 $^{\circ}$ C-40 $^{\circ}$ C



Please don't draw extendable resonance of the bass box forcibly, it will be damaged by this!

