




Unit



AUX cable





Power cable



Recharging method

- When it is recharged with red indication light on, when it is fully recharged, the indication light will be green.



Main features

- Living colors: 9 different light modes choice, select any one mode by hand or change the 9 modes circularly automatically
- FM radio with frequency range: 87.5-108MHz or 76-96MHz
- Line-in function: support many kinds of outer music sources with volume adjustable
- Power supply: built-in rechargeable lithium battery 3.7V 180mAh or DC 5V/500mA adapter

Operations

- Keys:
 - open living colors - light modes - FM radio on/off - search upwards - search downwards - search downwards - adjust volume (as picture)



- FM radio:
 - A: Press key one time to turn on or turn off FM radio
 - B: When turn on FM radio, press to search station upwards / downwards
 - C: Scroll the volume button on the right of the unit to adjust the radio volume.
- Living colors:
 - A: Press key to open living colors light, four sets LED lights will be on or off gradually and regularly
 - B: Press key to change the light modes by hand, then the light will be on in the selected mode all the time
- Aux-in function:
 - Insert one end of the enclosed aux-in cable into the unit's Aux-in hole, the other end insert into the outer music source, then it will play music, scroll the volume button on the right of the unit to adjust the music volume.
- Recharging operation:
 - A: Insert one end of the enclosed USB DC cable into the unit's DC hole, the other end insert into the USB part of the outer device, then it will be recharged with red indication light on, when it is fully recharged, the indication light will be green.
 - B: The unit also can be recharged by DC 5V/500mA adapter directly.
 - C: User can use the unit normally during recharging