User Manual

1 Icons

In the standby mode, the following icons may appear in standby screen:

Icon	Description
V	Show missed calls.
200	Receive a new message.
Ī	An application is being downloaded.
<u>Vi</u>	The downloading is over.
©	The alarm clock has been set and activated.
~	A call is in progress.
•	The phone is playing a song.
2	Show battery level.
<u>.</u>	Enable USB.
A	The access is blocked.
*	Get connected to the wireless network
* '	Turn on the Bluetooth.
	No SIM card is installed in the phone.
	No storage card is installed in the phone.

Key	Explanations
Return key	Return to the previous menu.
Menu key	Show options of current menu.
Home key	At any status, press the key to return to the standby screen.

Power key	Hold down this key to turn your phone off and on. Generally, press this key to lock the mobile phone.
Side volume keys	During the conversation, press the two keys to adjust the volume. While playing an audio file, press the two keys to adjust the volume.

2 Functional Menu

2.1 Android Market

Android Market provides direct access to useful applications which you can download and install on your phone.

2.2 Dialing

To dial a number, tap the "Favorites", "Call Register" or "Contacts" on the top of screen. You can enter the number directly from the numerical keypad

2.3 Browser

Browser enables you to surf the web via your phone, as if via a computer. You may create a bookmark on your phone and synchronize the bookmark with your computer. You can quickly go to your favorite websites from the Main screen.

2.4 Calendar

Calendar allows you to view your schedules and events at any time. You may view schedules one by one or at the same time.

Select to show calendar by day, week or month. If "by week", the calendar will be shown by week. This application is convenient for you to add events or view schedule.

2.5 Settings

Reach the menu, customize your phone settings.

Wireless and network: Set and apply the fly mode, wireless network, Bluetooth, virtual private network, and mobile network.

Call settings: Set some advanced features such as fixed dialing number, voicemail box, call diverting, call barring, and call cost, etc. These features depend on the network operator.

Ringtone and display. Customize the ringtone, volume, vibration, orientation, and brightness settings of your phone.

Location and Safety: Activate or deactivate the connection to wireless network and GPS; set unlocking pattern; lock the SIM card; set the SD card.

Applications: View, manage and delete the applications on your phone.

Account and synchronization: Set the synchronization of your phone account with your phone.

Privacy: Set the google services on your phone. Back up the data of settings.

Restore factory settings to clear all personal data on your phone.