


Bluetooth Bracelet incoming call alarm band

User Manual

ENCLOSURES



USB Cable



Bluetooth Bracelet



User manual

Overview

The Bluetooth to remind & antilost is a fashionable devices which can remind the missed call and antilost message for the user using the connection between the phone and the device though Bluetooth. This advanced device provides many functions such as the burglar steal, Vibrate Alert and so on. when you are in noisy downtown or on the The bumpy bus. It can protected you from missing the important calls, which fit for Business people, Senior marketing people, Fashion crowd, tourists and so on for its portable and beautiful appearance.

Principle of operation

After be paired between the device and the phone, it can propose rejecting the call to the user in a certain range, when the range between the device and the phone more than the set range, the device will propose a warning by vibrating that your phone may be lost.

6.ON OFF

ON: Press the function key for 3 seconds, the blue light will flicker three times, then the device is power on successfully.

OFF: Press the shut-down key for about 4 seconds, the blue light will flicker four times, then the device is power off successfully.

Installation and connection

First time connect the device to your phone


1. make sure the device is powered off, and then press the function key for 6 seconds, the blue light will long bright for 6 seconds.
2. open the phone bluetooth function and serach the device named 'WATCHDOG', then press 'YES' to pair the device.
3. the default pairing code of the device is 0000, after input the pairing code, press the 'YES' to connect to the device.
4. if connected successfully, the device will vibrate once, else repeat the 1-3.

Not first time connect the device to the device

1. if the device is powered on, press the function key then the device will connect the phone automatically.
2. if the device is powered off, press the function key for 3 second then the device will connect the phone automatically.

elementary operation

1. when you phone receive a call, the device will vibrate twice in one second, you can cancel the vibrator by press the function key once, or by two times faster to reject the call.
2. effective range/automatically connect: when the distance between the device and the phone beyond the effective range(8-10m),the connection will be close, then the device will be warning by vibrate three times in 10-30 seconds, when the distance back to the effective range, press the function key to rebuilt the connection.



Working performance & requirements

1. Charging

Bluetooth to remind & Antilost has a built-in rechargeable lithium ion battery polymer. Before using the device for the first time, you should charging full for the battery. How to charge the battery: Firstly you should connect the charger line to the device, and then link the usb interface to the compute or special charger which has inserted in the power supply.

2. Charging period

General need to recharge 2 hours, after charging, the LED charging indicator light of the device will be go out.

3. Charging indicator

During the charging, the LED charging indicator light of the device will be flickering to indicate that the battery is in charging.

4. The Standby time

Up to 90 hours.

5. Low-power notice

When low battery, the device will vibrate four times in every 30 seconds.

Product specifications

Model		Bluetooth Version	V2.0
carrier frequency	2402MHz-2480MHz	Through-put Power	0dBm
Effective range	10m	ContinuousTalk Time	90hours
Operating Temperature Range	-10℃ ~ +50℃	Storage Temperature Range	-20℃ ~ +80℃
Charging Voltage	5~5.3V	Charging period	2hours

Announcements

1. Please read this manual and follow the instructions matters flows.
2. Fall from high could cause the device damaged or wrong operation, please be careful.
3. Protect your device from contact with water, moisture and other liquid, if contacted, must shut down the device, for it may lead to shock or make the product severely damaged.
4. The device should avoid the direct-light and be far away from heatproducing device, because those work environments can cause an explosion or the lower performance and reduce battery life.
5. Do not repair the device (especially battery, may cause explosion)
6. Do not put too much weight on the device.
7. Please use the supply and recognized the charger.
8. Replace the device or other service, please consult designated service center or producers.
9. Long time don't use or in lightning weather, please turn off the power.